# Ceybold

# Vacuum Pump Systems

RUTA

Forevacuum Pump Systems

SOGEVAC

Oil Sealed Vacuum Pump Systems Central Vacuum Supply Systems

DRYVAC

Dry Compressing Vacuum Pump Systems

TURBOLAB

High Vacuum Pump Systems

UNIVEX

High Vacuum Experimentation Systems

# **CS** Calibration Systems

250.00.02 Excerpt from the Leybold Full Line Catalog (Edition 2021) Catalog Part Vacuum Pump Systems

# Contents

# Vacuum Pump Systems

Vacuum Pump Systems – oil sealed (RUTA) 6
General
Overview
Types of Pumps Systems
Products
Pump Systems
Oil Sealed Vacuum Pump Systems RUTA         Three-Stage Pump Systems         with Two-Stage TRIVAC Backing Pumps         Adaptor Version.         10         Frame Version       12         with Two-Stage SOGEVAC NEO Backing Pumps         Adaptor Version.       14
Two-Stage Pump Systems         with Single-Stage SOGEVAC Backing Pumps         Adaptor Version         Screener         Yarrian
Frame version       20         RBS - B/BCS Roots Pump Systems (Only available for purchase in North and South America)       20         with Two-Stage TRIVAC Backing Pumps.       24
HTS Close-Coupled Pump Systems (Only available for purchase in North and South America) with Single-Stage SOGEVAC Backing Pumps
Oil Sealed Standard Vacuum Systems SOGEVAC
Central Vacuum Supply Systems with SOGEVAC Pumps
Tank Mounted Medical Vacuum Systems (Only available for purchase in North and South America)
Vacuum Pump Systems – dry compressing (RUTA) 68
Products
Pump Systems
Dry Compressing Vacuum Pump System RUTA with SCREWLINE Backing Pump Adaptor Version without palette
with SCREWLINE Backing Pump Frame Version
SP Close-Coupled Pump Systems (Only available for purchase in North and South America) with SCREWLINE Dry Compressing Backing Pumps
Dry Compressing Vacuum Pump System RUTA Adaptor Version with DRYVAC DV 200 / DV 300 Backing Pump
Frame Version with DRYVAC DV 650 Backing Pump

DRYVAC Pump Systems		
Adaptor Version		
Load Lock Pump Systems		4
Process Pump Systems		6
with RUVAC WH Backing Pump		3
enclosed	100	C

# 

# **Products**

Dry Compressing Pump Systems DRYVAC

Basic System Configuration.	97
Smart System Configuration	108
PowerBoost	120

RUVAC RAV Roots Vacuum Pumps with Pre-Admission Cooling	124
TVD Pump Systems for Drying, Evaporation and Distillation Applications	.126

# Accessories for oil sealed and dry compressing Pump Systems

Sound Proofing	128
Isolation against Vibrations	128
Dust Separators	128
Frequency Converter RUVATRONIC RT 5	128
Electric Controller	129
Pressure Control	129
Dust Filter F-xxx-C	130
Bellows with Vibration Absorbers	132
Bus Interfaces for Monitoring.	133
Miscellaneous to oil sealed and dry compressing Pump Systems	
Checklist for Inquiries (Fax Form)	134

High Vacuum Pump Systems TURBOLAB	135
General	
General High Vacuum Pump Systems	
Applications and Accessories	135
Dry Pump Systems	136
Products	
Turbomolecular Pump Systems	
TURBOLAB 90i, 250i, 350i, 450i	136
Accessories for High Vacuum Pump Systems TMP	
Adsorption Traps with Aluminium Oxide Insert	148

UNIVEX High Vacuum Experimentation Systems	149
General	
General	149
Contents	150
Systems	
Box Coating Systems	151
Glove Box Systems	160
Cluster-Tool Systems	166
Dactyloscopy Systems	168
Space Simulation Systems	169
Process Accessories	170
General Accessories	182
UNIVEX Questionnaire	184

Calibration Systems	186
General	
CS Calibration Systems	186
Products	
CS Calibration Systems	187

# **General to Vacuum Pump Systems**

# Overview

A continually increasing number of applications in industry and research are relying on vacuum technology. Thus widely differing requirements result regarding the vacuum generating systems.

The comprehensive range of vacuum pumps from Leybold offers, in combination with the matching accessories, all options of selecting the optimum pump system for your application in each case.

Based on the longstanding experience in the design and manufacture of vacuum pump systems, Leybold offers standardized pump systems which will match most applications – the RUTA pump systems.

RUTA pump systems excel by being compact, reliable and service-friendly.

The pump systems are equipped as standard with 400 V, 50 Hz three-phase motors.

Motors for special supply voltages, special mains frequencies or explosion protected pumps are available.

## Standards

Leybold pump

systems are rated according to CE, ISO, DIN and VDE regulations. Compliance with other standards is possible upon request.

The technical data of the vacuum pump systems given in this catalog part are based on the PNEUROP Acceptance Specifications for Vacuum Pumps, Part 1, and comply with DIN 28 426. The characteristic curves in our pumping speed diagrams are plotted in accordance with DIN 28 426. The curves represent the mean of several measurements. Our warranty refers to the values indicated in the technical data table.

#### **Designation of Roots Vacuum Pump Systems**

Leybold pump combinations of Roots vacuum pumps with backing pumps are called "RUTA".

In order to identify the standard pump systems the name "RUTA" is followed by the brief designations of the pumps which make up a particular pump system.

Brief designation of the largest Roots vacuum pump (Pumping speed of the pump system)

Brief designation of the smaller Roots vacuum pump

Cooler or condenser (if present)

Brief designation of the backing pump

Type of pump system (adaptor (A) or frame (G))

### **Part Numbers**

The part numbers listed refer in each case to the standard version of the respective systems. Minor deviations are indicated by way of variants. The variant V001 designates in each case the described version of the system.

The pump system RUTA WAU 2001/ SP630 F/G has Part No. 502 511 V001. When using the air-cooled screw pump SCREWLINE SP 630 then the variant will have the Part No. 502 511 V002. Minor deviations are special operating voltage, fitted accessories and custom painting for frame or pumps, for example. The use of a different type of Roots vacuum pump, use of the WS 2001 instead of the WAU 2001, for example, is also treated as a variant. All variants with the same basic number have the same frame dimensions, the same distance between intake flange of the Roots pump and the exhaust flange of the backing pump.

The pump system designation is arranged as follows:

ed RUTA WAU 2001 / WAU 501 / K / D 65 B / G
nps
ots vacuum pump
ots vacuum pump
imp
or frame (G))

# Types of Pump Systems

Typical areas of application for RUTA pump systems are industry, research and chemistry. Here the focus is on processes for metal production and processing, drying and degassing, thermal treatment, coating in the area of solar components and semiconductor manufacture as well as surface refinement. RUTA pump systems are also used as backing pump sets for high vacuum systems in combination with diffusion pumps, turbomolecular pumps and cryo pumps.



RUTA WH7000/4xSV750BF/G

The RUTA pump systems described here have been designed for rough and medium vacuum operation, i.e. for the pressure range from atmospheric pressure down to 10<sup>-4</sup> mbar (0.75 x 10<sup>-4</sup> Torr). RUTA pump systems consist of a combination of individual pumps whereby Roots vacuum pumps are employed on the intake side. Further compression to atmospheric pressure may be performed either by oil sealed or dry compressing vacuum pumps, liquid ring pumps or Roots vacuum pumps with pre-inlet cooling. All combinations may be equipped at suitable places with condensers.

The selection criteria for a RUTA pump system are as follows:

- Pumping speed
- Operating pressure
- Process conditions
- Characteristics of the media
- Standards and regulations which depend on the area of application and the produced products.

#### **Standard RUTA Pump Systems**

Our Roots vacuum pumps WA, WH, WS and RA or WAU and WSU with integrated bypass line are combined with oil sealed backing pumps for conventional generation of the vacuum. Single-stage arrangements are capable of delivering pumping speeds of 250 to 16000 m<sup>3</sup>/h (147.3 to 9424 cfm). Higher pumping speeds can be attained by paralleling several pumps. The attainable operating pressures depend on the number of pumping stages.

For higher pumping speeds or lower ultimate pressures, also three-stage or multi-stage pump systems are available.

### **RUTA Pump Systems with** Condensers

If vacuum systems must pump larger quantities of vapor or vapor gas mixtures, it is economical to insert condensers which are cooled with water or a different coolant at a suitable place within the pump system. Cooled condensers are themselves effective partial pumps which condense most of the vapors from the pumped media. The downstream mechanical pumps will then only need to pump those gases which have not already condensed. The quantity of vapor present in each case determines the size of the condenser and the temperature at which it is operated. The size of the downstream pump is determined by the quantity of non-condensable gases, the required pressure and the required pump-down time for the system.

All pump systems of the WA/WAU, WS/WSU, WH and RA series may be equipped with one or several condensers. These are often used in the chemical industry. Here RUTA vacuum pump systems with condensers are not only used to generate a vacuum, but they are also often employed in the recovery of solvents. When installing one or several Roots pumps upstream of a condenser, low operating pressures and high condensation pressures can be attained. Thus the condenser may in many cases be operated with cooling water instead of brine. The vapor components pumped together with inert gases may be separated once more in an emission condenser on the exhaust side so that the quality of the exhaust gas can be maintained within close tolerance regarding its cleanness.

# Dry Compressing RUTA Vacuum Pump Systems

Increasing environmental awareness, pumping of condensable vapors or high requirements regarding cleanness when pumping high quality media which must not be contaminated by other media for recycling, often requires the use of universal pumps where the pump chamber is free of operating agents (dry pumps). Here Leybold offers two solutions: 1. Pump systems with dry compressing vacuum pumps combined with one or several Roots vacuum pumps. 2. Single-stage RUTA RAV vacuum pump systems, consisting of Roots vacuum pumps with pre-admission cooling.

The operating pressure ranges of the pump systems depend on the number of Roots vacuum pumps, but will extend in any case without interruptions to atmospheric pressure.

Already in connection with one Roots pump, pump systems with a screw pump are capable of attaining base pressures of  $< 1 \times 10^{-3}$  mbar (7.5 x 10<sup>-4</sup> Torr).

Single-stage RAV combinations attain an ultimate pressure of 150 mbar (112.5 Torr).

Multi-stage combinations with Roots vacuum pumps of all systems are capable of attaining pressures below  $10^{-4}$  mbar (7.5 x  $10^{-5}$  Torr).

# **RUTA Custom Pump Systems**

Most users will be able to select the right pump system for their application from our range of standard pump systems. In special cases a custom design may be required for special processes and high pumping speeds.

We are prepared to design and manufacture custom pump systems according to customers specifications. If required we will use – besides oilsealed and dry compressing backing pumps – liquid ring and ejector pumps.

# RUTA Pump Systems for the Metal Producing and Processing Industry

In common vacuum furnace processes such as hardening, annealing, brazing, melting and casting, preferably oil sealed or dry compressing standard vacuum pump systems are usually used.

The oil sealed systems consist of a combination of Roots vacuum pumps with a single or two-stage rotary vane or rotary piston pump.

In the dry compressing systems our screw vacuum pump SCREWLINE is used as the backing pump.

The vacuum pumps are mounted in a rugged frame. The design of the pump systems is service-friendly, modular and can be easily upgraded with additional equipment.

On smaller furnaces RUVAC WAU Roots vacuum pumps are the most suitable because these may be cut-in at a higher operating pressure, while on larger furnaces and particularly where short pump-down cycles are required, the use of RUVAC WH Roots vacuum pumps with suitably sized backing pumps is advisable. For special processes, e.g. fusion or degassing of molten masses, due to the high dust contents, the additional use of a dust separator is required as well as equipping the backing pumps with oil filtering units.

These additional units ensure utmost operational reliability of the pump systems even under the toughest operating conditions.



Pump system for the field of steel degassing

# RUTA Pump Systems for the Photovoltaic and Coating Industry

In photovoltaic coating processes reactive, toxic and corrosive substances are generally used.

Frequently large quantities of dust for the pump system need to be expected. For such applications, Leybold has developed process pump combinations consisting of pumps from the DRYVAC line and Roots pumps from the RUVAC WS/WH line with optionally integrated controller.

The integrated electronics and sensor systems permit easy integration of the pump systems within the plant control system.

(For information on possible applications, see Catalog Part "Dry Compressing Screw Vacuum Pumps DRYVAC").

## **RUTA Pump Systems for the** Chemical Industry

In chemical processes it is often necessary to remove corrosive, condensable and reactive gases and vapors. Leybold designs and manufactures custom-built pump systems for specific process applications. Depending on the type of application, either a rotary vane pump, or a dry compressing screw vacuum pump (SCREWLINE, for example), a liquid ring pump or a combination of gas jet pump and liquid ring pump may be used as the backing pump.

To ensure dependable monitoring of the system, the following monitoring devices, among others, may be installed:

- Temperature sensors to monitor the gas temperatures between the pump stages and the pump body temperature,
- Water flow monitors for the cooling water supply to pumps and condensers,
- Differential pressure indicator with control setpoint to monitor the exhaust filters of the rotary vane vacuum pump.

# Pump Systems for Drying, Evaporation and Distillation Applications (TVD)

More and more vacuum applications are finding their way into the areas of environmental protection, recycling and waste disposal. "Waste disposal of used oil and aromatic compounds" and "Cleaning processes in metal-processing factories" demonstrate that the combination of vacuum know-how, innovative engineering and applications know-how is in-dispensable for the successful application of vacuum technology in most widely differing applications.



TVD pump system, mobile with control cabinet

The product is no longer in the foreground, solutions to problems are demanded instead.

Leybold has developed some continuously operating vacuum pump systems for these applications. These systems basically

consist of a rotary vane pump with a condenser unit. Upon request the condenser arrangement may also be equipped with a cold water set. This version will then be independent of any cooling water connections and - being a mobile system - it is well-suited for operation at varying locations.

# **Products**

# Oil Sealed RUTA Pump Systems – Three-Stage, with Two-Stage TRIVAC Backing Pumps, Adaptor Version



RUTA WAU501/D65B/A

### **Standard Equipment**

- Exhaust filter
- Oil collecting pan
- Manually operated gas ballast
- Crane eyes on the frame
- Floor mounting
- The oil is supplied with the pump
- CE approval

#### Options

- Frequency converter RUVATRONIC RT for controlling the speed of the Roots pump
- Oil filter
- 24 V DC gas ballast valve
- Sound proofing box
- Vibration absorbers

- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Exhaust filter with oil return line
- Special motors
- Electric control systems



Dimensional drawing for the pump systems with TRIVAC D40/65 B backing pumps on pallet; dimensions in brackets () are in inch

Technical Data, 50 Hz		RUTA WAU				
		251/D40B/A	251/D65B/A	501/D65B/A		
RUVAC (WA/WAU/WS/WSU possible)	P2	251	251	501		
Backing pump TRIVAC	P1	D 40 B	D 65 B	D 65 B		
Pumping speed, 50 Hz at $10^{-1}$ mbar (7.5 x $10^{-2}$ Torr)	m³/h (cfm)	200.0 (117.8) 210.0 (123.7) 380.0 (22		380.0 (223.8)		
Ultimate partial pressure	mbar (Torr)		< 2 x 10 <sup>-5</sup> (< 1.5 x 10 <sup>-5</sup> )			
Ultimate total pressure with gas ballast	mbar (Torr)	< 8 x 10 <sup>-4</sup> (< 6 x 10 <sup>-4</sup> )				
Installed motor power 400 V, 50 Hz	kW (hp)	2.6 (3.5) 3.3 (4.5) 4.4 (6.0)				
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	2.0 (2.7)	2.5 (3.4)	2.7 (3.7)		
Noise level max. without gas ballast at 1 mbar (0.75 Torr)	dB(A) dB(A)	64 62	65 63	67 63		
Oil filling, total, approx.	l (qt)	3.3 (3.49)	4.0 (4.23)	4.3 (4.55)		
Weight, total, approx.	kg (lbs)	245.0 (540.2)	260.0 (573.3)	305.0 (627.5)		
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>		63 ISO-K 40 ISO-KF			

# **Ordering Information**

		251/D40B/A	251/D65B/A	501/D65B/A
		Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible)	P2	WAU 251	WAU 251	WAU 501
Backing pump TRIVAC	P1	D 40 B	D 65 B	D 65 B
Pump system, complete (adaptor version), pallet mounted, with Roots vacuum pump RUVAC WAU		023 06	023 07	023 08
Frequency converter RUVATRONIC (see description in Chapter "Accessories")		RT 5/251 500 001 381	RT 5/251 500 001 381	RT 5/501 500 001 382





**RUTA WAU** 

Pump-down time diagram for a 1000 I tank at 50 Hz

# Oil Sealed RUTA Pump Systems – Three-Stage, with Two-Stage TRIVAC Backing Pumps, Frame Version



RUTA WAU501/D65B/G

### **Standard Equipment**

- Exhaust filter
- Oil collecting pan
- Manually operated gas ballast
- Crane eyes on the frame
- Floor mounting
- The oil is supplied with the pump
- CE approval

### Options

- Frequency converter RUVATRONIC RT for controlling the speed of the Roots pump
- Oil filter
- 24 V DC gas ballast valve
- Sound proofing box
- Vibration absorbers

- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Exhaust filter with oil return line
- Special motors
- Electric control systems



Dimensional drawing for the pump systems with TRIVAC D40/65 B backing pumps in a frame; dimensions in brackets () are in inch

# Technical Data, 50 Hz

# **RUTA WAU**

		251/D40B/G	251/D65B/G	501/D65B/G	1001/D65B/G
RUVAC (WA/WAU/WS/WSU possible)	P2	251	251	501	1001
Backing pump TRIVAC	P1	D 40 B	D 65 B	D 65 B	D 65 B
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	185.0 (109.0)	205.0 (120.7)	340.0 (200.3)	620.0 (365.2)
Ultimate partial pressure	mbar (Torr)	< 2 x 10 <sup>-5</sup> (< 1.5 x 10 <sup>-5</sup> )			
Ultimate total pressure with gas ballast	mbar (Torr)	< 8 x 10 <sup>-4</sup> (< 6 x 10 <sup>-4</sup> )			
Installed motor power 400 V, 50 Hz	kW (hp)	2.6 (3.5)	3.3 (4.5)	4.4 (6.0)	6.2 (8.4)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	2.0 (2.7)	2.5 (3.4)	2.7 (3.7)	3.0 (4.1)
Noise level max. without gas ballast at 1 mbar (0.75 Torr)	dB(A)	64	65	67	77
Oil filling, total, approx.	L (at)	3.3 (4.5)	4.0 (4.23)	4.3 (4.55)	5.3 (5.60)
Weight, total, approx.	kg (lbs)	280.0 (617.4)	310.0 (683.6)	350.0 (771.8)	460.0 (1014.3)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	63 ISO-K 40 ISO-KF	63 ISO-K 40 ISO-KF	63 ISO-K 40 ISO-KF	100 ISO-K 40 ISO-KF

# **Ordering Information**

# **RUTA WAU**

	251/D40B/G	251/D65B/G	501/D65B/G	1001/D65B/G
	Part No.	Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible) P2	WAU 251	WAU 251	WAU 501	WAU 1001
Backing pump TRIVAC P1	D 40 B	D 65 B	D 65 B	D 65 B
Pump system, complete (frame version), frame mounted, with Roots vacuum pump RUVAC WAU	023 16	023 17	023 18	023 19
Frequency converter RUVATRONIC (see description in Chapter "Accessories")	RT 5/251 500 001 381	RT 5/251 500 001 381	RT 5/501 500 001 382	RT 5/1001 500 001 383



Pump-down time diagram for a 1000 l tank at 50 Hz





# Oil Sealed RUTA Pump Systems – Three-Stage, with Two-Stage SOGEVAC NEO Backing Pumps, Adaptor Version

## **Standard Equipment**

- RUVAC WAU with air cooling
- SOGEVAC SOGEVAC NEO 40 / 65 D with air cooling
- Exhaust filter with oil return
- Oil filter
- Oil collecting pan
- With manual gas ballast with three positions: closed, low flow and standard flow
- Crane eyes on the frame
- Floor mounting

# Technical Data, 50 Hz

- The oil is supplied with the pump

### Options

- Frequency converter RUVATRONIC RT for controlling the speed of the Roots pump
- 24 V DC gas ballast valve
- Sound proofing box
- Vibration absorbers
- Castors

- Different floor mountings
- Oil drain tap on each pump
- Special motors
- Electric controls

**RUTA WAU** 

- The SOGEVAC NEO pump can be equipped with a thermal oil level or exhaust filter overpressure switch

		251/NEO D40/A	251/NEO D65/A	501/NEO D65/A		
Ordering Information *	Part No.	505048V001	505049V001	505050V001		
RUVAC (WA/WAU/WS/WSU possible)	P2	251	251	501		
Backing pump SOGEVAC NEO	P1	D 40	D 65	D 65		
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar	m³/h	200	210	380		
Ultimate total pressure	mbar		< 8 · 10 <sup>-4</sup>			
Ultimate total pressure with gas ballast	mbar	< 1 · 10 <sup>-2</sup>				
Installed motor power 400 V, 50 Hz	kW	2.6	3.3	4.4		
Electrical power consumption at 10 <sup>-1</sup> mbar	kW	2.0	2.5	2.7		
Noise level without gas ballast 1 mbar	dB(A)	63	63	66		
Oil filling, total, approx.	I	4.2	4.6	4.8		
Weight, total, approx.	kg	260	265	310		
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	63 ISO-K 40 ISO-KF				

\* For suitable RUVATRONIC frequency inverters, see section "Accessories"

## Notes

# Oil Sealed RUTA Pump Systems – Two-Stage, with Single-Stage SOGEVAC Backing Pumps, Adaptor Version



RUTA WAU1001/SV200/A

### **Standard Equipment**

- Exhaust filter with oil return line
- Oil filter
- Oil collecting pan
- Gas ballast valve: SV 200/300 B manually operated SV 630 BF 24 V DC
- SV 200/300 B with air cooling
- SV 630 BF with water cooling
- Floor mounting

- The oil is supplied with the pump
- CE approval

### Options

- Frequency converter RUVATRONIC RT for controlling the speed of the Roots pump
- 24 V DC gas ballast valve or manually operated

- Sound proofing box
- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Special motors
- Electric control systems



Туре	RUTA	501/SV200/A	1001/SV200/A	1001/SV300B/A	2001/SV630BF/A
RUVAC WA/WAU/WS/WSU	P2	501	1001	1001	2001
Backing pump SOGEVAC	P1	SV 200	SV 200	SV 300 B	SV 630 BF
	DN <sub>1</sub>	63 ISO-K	100 ISO-K	100 ISO-K	160 ISO-K
	DN <sub>2</sub>	2"	2"	2"	100 ISO-K
	1	962 (37.87)	1050 (41.34)	1030 (40.55)	1896 (74.65)
	L,	242 (9.53)	303 (11.93)	298 (11.73)	987 (38.86)
	I <sub>2</sub>	70 (2.76)	77 (3.03)	88 (3.47)	40 (1.56)
	b	700 (27.56)	700 (27.56)	700 (27.56)	1000 (39.37)
	b,	230 (9.06)	230 (9.06)	230 (9.06)	456 (17.95)
	b,	499 (19.65)	499 (19.65)	520 (20.47)	764 (30.08)
	h	873 (34.37)	923 (36.34)	929 (36.58)	1340 (52.76)
	h,	468 (18.43)	468 (18.43)	480 (18.90)	720 (28.35)
	c	100 (3.94)	100 (3.94)	100 (3.94)	100 (3.94)

Dimensional drawing for the pump systems with SOGEVAC SV 200 and 300 B backing pumps [left], SOGEVAC SV 630 BF [right]; dimensions in brackets () are in inch

# leybold

# Technical Data, 50 Hz

# **RUTA WAU**

		501/SV200/A	1001/SV200/A	1001/SV300B/A	2001/SV630BF/A
RUVAC (WA/WAU/WS/WSU possible)	P2	501	1001	1001	2001
Backing pump TRIVAC	P1	SV 200	SV 200	SV 300 B	SV 630 BF
Pumping speed, 50 Hz at $10^{-1}$ mbar (7.5 x $10^{-2}$ Torr)	m³/h (cfm)	365.0 (215.0)	715.0 (421.0)	730.0 (430.0)	1690.0 (995.4)
Ultimate partial pressure	mbar (Torr)		< 8 x 10 <sup>-3</sup>	(< 6 x 10 <sup>-3</sup> )	
Ultimate total pressure with gas ballast	mbar (Torr)	< 4 x 10 <sup>-2</sup> (< 3 x 10 <sup>-2</sup> )			
Installed motor power 400 V, 50 Hz	kW (hp)	6.2 (8.4)	8.0 (10.9)	9.5 (12.9)	22.5 (30.6)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	3.0 (4.1)	3.5 (4.8)	4.0 (5.4)	16.5 (22.4)
Noise level without gas ballast at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	70	75	76	80
Oil filling, total, approx.	l (qt)	6.0 (6.34)	7.0 (7.4)	11.0 (11.63)	26.0 (27.47)
Weight, total, approx.	kg (lbs)	335.0 (738.7)	430.0 (948.2)	480.0 (1058.4)	1140.0 (2513.7)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	63 ISO-K 2"	100 ISO-К 2"	100 ISO-К 2"	160 ISO-K 100 ISO-K

-----

# **Ordering Information**

# **RUTA WAU**

	501/SV200/A	1001/SV200/A	1001/SV300B/A	2001/SV630BF/A
	Part No.	Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible)	<b>2</b> WAU 501	WAU 1001	WAU 1001	WAU 2001
Backing pump SOGEVAC F	<b>SV 200</b>	SV 200	SV 300 B	SV 630 BF
Pump system, complete (adaptor version), pallet mounted,				
with Roots vacuum pump RUVAC WAU	022 06	022 08	502 462 V001	502 463 V001
Frequency converter RUVATRONIC	RT 5/501	RT 5/1001	RT 5/1001	RT 5/2001
(see description in Chapter "Accessories")	500 001 382	500 001 383	500 001 383	500 001 384



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

# Oil Sealed RUTA Pump Systems – Two-Stage, with Single-Stage SOGEVAC Backing Pumps, Adaptor Version



RUTA WH4400/SV630BF/A

## **Standard Equipment**

- RUVAC WH with water cooling
- Exhaust filter with oil return line
- Oil filter
- Oil collecting pan
- Gas ballast valve: SV 100 to 300 manually operated SV 630 BF 24 V DC
- SV 100 to 300 with air cooling
- SV 630 BF with water cooling

- Floor mounting
- The oil is supplied with the pump
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

### Options

- 24 V DC gas ballast valve or manually operated
- Sound proofing box
- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Special motors
- Electric control systems









Туре	RUTA	700/SV100B/A	700/SV200/A	700/SV300B/A	4400/SV630BF/A
RUVAC WH	P2	700	700	700	4400
Backing pump SOGEVAC	P1	SV 100 B	SV 200	SV 300 B	SV 630 BF
	DN <sub>1</sub>	100 ISO-K	100 ISO-K	100 ISO-K	250 ISO-K
	$DN_2$	G 1 1/4"	G 2"	G 2"	100 ISO-K
	I.	710 (27.95)	950 (37.40)	950 (37.40)	1896 (74.65)
	l,	217 (8.54)	262 (10.32)	335 (13.19)	947 (37.28)
	l <sub>2</sub>	85 (3.35)	84 (3.31)	125 (4.92)	40.5 (1.59)
	I <sub>3</sub>	41 (1.61)	-	45 (1.77)	-
	I <sub>4</sub>	17 (0.67)	-	95 (3.74)	-
	b	500 (19.69)	700 (27.56)	700 (27.56)	1000 (39.37)
	b <sub>1</sub>	175 (6.89)	230 (9.06)	230 (9.06)	456 (17.95)
	b <sub>2</sub>	384 (15.12)	499 (19.65)	520 (20.47)	764 (30.08)
	С	100 (3.94)	100 (3.94)	100 (3.94)	100 (3.94)
	h	708 (27.87)	829 (32.64)	827 (32.56)	1450 (57.09)
	h,	365 (14.37)	468 (18.43)	480 (18.90)	720 (28.35)

Dimensional drawing for the pump systems with SOGEVAC SV 100 B, 200 and 300 B backing pumps [left], SOGEVAC SV 630 BF [right]; dimensions in brackets () are in inch

## Technical Data, 50 Hz

# **RUTA WH**

**RUTA WH** 

		700/SV100B/A	700/SV200/A	700/SV300B/A	4400/SV630BF/A
RUVAC WH	P2	700	700	700	4400
Backing pump SOGEVAC	P1	SV 100 B	SV 200	SV 300 B	SV 630 BF
Pumping speed, 50 Hz at $10^{-1}$ mbar (7.5 x $10^{-2}$ Torr)	m³/h (cfm)	520 (306)	570 (335)	600 (353)	3332 (1961)
Ultimate pressure without gas ballast	mbar (Torr)	< 5 x 10 <sup>-3</sup> (< 3.75 x 10 <sup>-3</sup> )	< 2 x 10 <sup>-3</sup> (< 1.5 x 10 <sup>-3</sup> )	< 3 x 10 <sup>-3</sup> (< 2.25 x 10 <sup>-3</sup> )	< 3 x 10 <sup>-3</sup> (< 2.25 x 10 <sup>-3</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	4.4 (5.9)	6.2 (8.3)	7.7 (10.3)	26.0 (34.9)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	1.6 (2.2)	2.9 (3.9)	6.0 (8.0)	9,68 (12.98)
Noise level at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	62	69	70	73
Oil filling, total, approx.	l (qt)	2.9 (2.6.)	9.9 (8.7)	12.4 (10.9)	27.0 (23.8)
Weight, total, approx.	kg (lbs)	350 (722)	415 (915)	465 (1025)	1 330 (2932)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	100 ISO-K G 1 1/4"	100 ISO-K G 2"	100 ISO-К G 2"	250 ISO-K 100 ISO-K

# **Ordering Information**

#### 700/SV100B/A 700/SV200/A 700/SV300B/A 4400/SV630BF/A Part No. Part No. Part No. Part No. RUVAC WH P2 700 700 700 4400 Backing pump SOGEVAC P1 air-cooled SV 100 B SV 200 SV 300 B P1 SV 630 BF water-cooled \_ \_ \_ Pump system, complete (adaptor version), pallet mounted, with Roots vacuum pump RUVAC WH 503155V001 <sup>1)</sup> 503156V001 <sup>1)</sup> 503157V001 <sup>1)</sup> 503164V001 <sup>1)</sup>

<sup>1)</sup> Including external frequency converter



Pump-down time diagram for a 10 m<sup>3</sup> tank at 50 Hz



Pumping speed diagram at 50 Hz

# Oil Sealed RUTA Pump Systems – Two-Stage, with Single-Stage SOGEVAC Backing Pumps, Frame Version



RUTA WAU2001/SV300B/G

## **Standard Equipment**

- RUVAC WAU with air cooling
- SOGEVAC SV 300 B with air cooling
- Exhaust filter with oil return line
- Oil filter
- Oil collecting pan
- Gas ballast valve: SV 300 B manually operated
- Crane eyes on the frame
- Floor mounting

- The oil is supplied with the pump
- CE approval

### Options

- Frequency converter RUVATRONIC RT for controlling the speed of the Roots pump
- 24 V DC gas ballast valve or manually operated
- Sound proofing box

- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Special motors
- Electric control systems



Dimensional drawing for the pump systems with SOGEVAC SV 300 B backing pumps; dimensions in brackets () are in inch

# Technical Data, 50 Hz

# **RUTA WAU**

		1001/SV300B/G	2001/SV300B/G
RUVAC (WA/WAU/WS/WSU possible)	P2	1001	2001
Backing pump SOGEVAC	P1	SV	300 B
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	730 (430)	1445 (850)
Ultimate partial pressure	mbar (Torr)	< 8 x 10	<sup>-3</sup> (< 6 x 10 <sup>-3</sup> )
Ultimate total pressure with gas ballast	mbar (Torr)	< 4 x 10	-² (< 3 x 10 <sup>-2</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	9.5 (12.9)	13.0 (17.7)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	4.0 (5.4)	4.5 (6.1)
Noise level without gas ballast at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	75	79
Oil filling, total, approx.	l (qt)	11 (11.63)	13 (13.74)
Weight, total, approx.	kg (lbs)	560.0 (1234.8)	740.0 (1631.7)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	100 ISO-K 2"	160 ISO-K 2"

# **Ordering Information**

# RUTA WAU

	1001/SV300B/G	2001/SV300B/G	
	Part No.	Part No.	
RUVAC (WA/WAU/WS/WSU possible) P2	WAU 1001	WAU 2001	
Backing pump SOGEVAC P1	SV 300 B		
Pump system, complete (frame version), frame mounted, with Roots vacuum pump RUVAC WAU	502 452 V001	502 453 V001	
Frequency converter RUVATRONIC (see description in Chapter"Accessories")	RT 5/1001 <b>500 001 383</b>	RT 5/2001 <b>500 001 384</b>	



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

# Oil Sealed RUTA Pump Systems – Two-Stage, with Single-Stage SOGEVAC Backing Pumps, Frame Version



RUTA WH2500/SV630BF/G

### **Standard Equipment**

- RUVAC WH with water cooling
- Exhaust filter with oil return line
- Oil filter
- Oil collecting pan
- Gas ballast valve: SOGEVAC SV 630 BF 24 V DC
- SOGEVAC SV 630 BF with water cooling
- SOGEVAC SV 1200 with air cooling

- Crane eyes on the frame
- Floor mounting
- The oil is supplied with the pump
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

## Options

- Frequency converter for controlling the speed of the Roots pump (only RUVAC WA/WS)
- 24 V DC gas ballast valve or manually operated
- Sound proofing box
- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Special motors

100 (3.94)

- Electric control systems



100 (3.94)

Dimensional drawing for the pump systems with SOGEVAC SV backing pumps

С

100 (3.94)

# Technical Data, 50 Hz

# **RUTA WH**

		2500/ SV630BF/G	4400/ SV630BF/G	7000/ SV630BF/G
RUVAC WH <sup>1)</sup>	P2	2500	4400	7000
Backing pump SOGEVAC	P1		SV 630 BF	
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	1902 (1119)	3332 (1961)	4990 (2937)
Ultimate total pressure with gas ballast	mbar (Torr)	< 5 · 10 <sup>-3</sup> (< 3.7 x 10 <sup>-3</sup> )		
without gas ballast	mbar (Torr)		< 5 · 10 <sup>-3</sup> (< 3.7 x 10 <sup>-3</sup> )	< 5 · 10 <sup>-3</sup> (< 3.7 x 10 <sup>-3</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	21.5 (28.8)	26.0 (34.9)	26.0 (34.9)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	8.5 (11.4)	9.68 (12.98)	9.84 (13.20)
Noise level without gas ballast at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)		73	
Oil filling, total, approx.	l (qt)	16.2 (17.1)	27.0 (4.6)	27.0 (4.6)
Weight, total, approx.	kg	1360 (2998)	1530 (3373)	1590 (3505)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	250 ISO-K 100 ISO-K	250 ISO-K 100 ISO-K	320 ISO-K 100 ISO-K

# **Ordering Information**

#### **RUTA WH**

		2500/ SV630BF/G	4400/ SV630BF/G	7000/ SV630BF/G		
		Part No.	Part No.	Part No.		
RUVAC WH <sup>1)</sup>	P2	2500	4400	7000		
Backing pump SOGEVAC	P1	SV 630 BF				
Pump system, complete (frame version), frame mounted, with Roots vacuum pump RUVAC WH		503161V001 <sup>1), 2)</sup>	503165V001 <sup>1), 2)</sup>	503169V001 <sup>1), 2)</sup>		

<sup>1)</sup> Including external frequency converter

<sup>2)</sup> With this combination, continuous operation of the Roots pump is not possible at atmospheric pressure







Vacuum Pump Systems

# Pump Systems (Only available for purchase in North and South America)

RBS – B/BCS Roots Pump Systems with Two-Stage TRIVAC Backing Pumps



RBS - B/BCS Roots pumping system, shown with optional AF exhaust filter

# **Standard Equipment**

- System consists of TRIVAC dualstage B or BCS direct drive vane pump and RUVAC blower
- Complete air-cooled system
- 18" wide frame base equipped with caster wheels and leveling pads
- Compact construction with quiet operation
- Manual operation of gas ballast
- Close-coupled RUVAC blower with ANSI inlet flange

## Options

- All TRIVAC accessories, Exhaust filter, 24 V DC gas ballast valve, chemical oil filter, and electrical limit switch system
- Full frame drip pan
- Oil drain valves
- Special motor voltages and frequencies
- Special oil for unique applications
- Full electrical controls for control start/stop and monitoring of system



Pumping speed diagram for the RBS systems with WSU series Roots blowers at 60 Hz



Dimensional drawing for the RBS – B/BCS Roots pumping systems 18" with TRIVAC D 40/65 B backing pumps, close-coupled package; dimensions in brackets () are in mm

		251/D40B	251/D65B	501/D40B	501/D65B
RUVAC (WA/WAU/WS/WSU possib	ole)	251	251	501	501
TRIVAC backing pump		D 40 B/BCS	D 65 B/BCS	D 40 B/BCS	D 65 B/BCS
Pumping speed at 0.1 Torr	cfm (m <sup>3</sup> /h)	140 (237)	150 (254)	232 (394)	267 (453)
Ultimate total pressure	Torr (mbar)		< 2 x 10 <sup>-4</sup>	(< 4 x 10 <sup>-4</sup> )	
Connecting flanges					
Inlet port					
WSU	DN		3" A	ANSI	
Outlet port	DN		40 IS	O-KF	
Operating voltage	v		208/23	30/460	
Phase / Frequency 1)	– / Hz		3 /	60	
Full load amps 2)					
RUVAC WSU		5.5/5.5/3.2	5.5/5.5/3.2	9.0/9.0/5.2	9.0/9.0/5.2
TRIVAC		9.0/8.8/4.5	9.0/8.8/4.5	9.0/8.8/4.5	9.0/8.8/4.5
Displacement					
RUVAC	cfm (m <sup>3</sup> /h)	179 (304)	179 (304)	357 (606)	357 (606)
TRIVAC	cfm (m <sup>3</sup> /h)	32 (54)	53 (90)	32 (54)	53 (90)
Maximum differential pressure	Torr (mbar)		60	(80)	
Normal starting pressure 3)	Torr (mbar)	20 (27)	30 (40)	12 (16)	16 (21)
Oil capacity					
RUVAC WSU	at (I)	0.75 (0.7)	0.75 (0.7)	1.1 (1.0)	1.1 (1.0)
TRIVAC	qt (l)	2.7 (2.6)	3.4 (3.2)	2.7 (2.6)	3.4 (3.2)
Nominal rotation speed			1		
RUVAC WSU	rpm (min⁻¹)	3600 (3600)			
TRIVAC	rpm (min <sup>-1</sup> )	1800 (1800)			
Motor power					
RUVAC WSU	hp (kW)	1.9 (1.4)	1.9 (1.4)	3.3 (2.4)	3.3 (2.4)
TRIVAC	hp (kW)	3.0 (2.2)	3.0 (2.2)	3.0 (2.2)	3.0 (2.2)
	• • • •	× /		1	

# **Ordering Information**

**Technical Data** 

# **RBS – B/BCS Roots Pump Systems**

**RBS – B/BCS Roots Pump Systems** 

	251/D40B	251/D65B	501/D40B	501/D65B
	Part No.			
RUVAC WH RBS – B/BCS Roots pump system				
(supplied with hydrocarbon oil)		Ordering Informat	ion see right page	

<sup>1)</sup> For 50 Hz systems, consult the factory

<sup>2)</sup> Determined by operating voltage

<sup>3)</sup> WSU pumps permit start-up at atmospheric pressure (760 Torr)

# **Ordering Information**

Blower / TRIVAC pump WSU 251 / D 40 B WSU 251 / D 40 BCS-LVO 400 WSU 251 / D 65 B WSU 251 / D 65 B-LVO 400 WSU 501 / D 40 BCS-LVO 400 WSU 501 / D 65 B WSU 501 / D 65 BCS-LVO 400 Reserved Electrical Control Panel None 208 V

230 V

460 V



Vacuum Pump Systems

# Pump Systems (Only available for purchase in North and South America)

# HTS Close-Coupled Systems with Single-Stage SOGEVAC Backing Pumps



HTS close-coupled system

# **Standard Equipment**

- System consists of single-stage SOGEVAC vane pump
- Complete air-cooled system
- Close-coupled RUVAC blower
- Compact construction with quiet operation
- Manual operation of gas ballast
- Spin-on type oil filter

## Options

- SOGEVAC accessories: oil level monitoring, exhaust case gauge, 24 V DC gas ballast purge, water cooling
- Frame base mounted caster wheels
- Frame base mounted leveling pads
- Oil drain valves
- Inlet dust filter

- Special motor voltages and frequencies
- Special oil for unique applications
- Full NEMA12 electrical controls for stand/stop operation and monitoring of system from remote and local locations
- 24 V DC gas ballast valve



Pumping speed diagram for the HTS close-coupled systems with WSU series Roots blowers and SOGEVAC SV 200/300B at 60 Hz



Pumping speed diagram for the HTS close-coupled systems with WSU series Roots blowers and SOGEVAC SV 630B at 60 Hz



Dimensional drawing for the HTS close-coupled system with single-stage SOGEVAC backing pumps; dimensions in brackets () are in mm

Technical Data	HTS Close-Coupled Systems				
		501/SV200	501/SV300B	1001/SV200	1001/SV300B
RUVAC		WSU 501	WSU 501	WSU 1001	WSU 1001
SOGEVAC		SV 200	SV 300 B	SV 200	SV 300 B
Pumping speed at 0.1 Torr	cfm (m³/h)	277 (470)	285 (483)	504 (855)	545 (925)
Ultimate total pressure	Torr (mbar)	< 8 x 10 <sup>-3</sup> (< 1 x 10 <sup>-2</sup> )			
Connecting flanges Inlet port WSU Exhaust port SOGEVAC	DN DN	3" ANSI 2" NPT			
Operating voltage	v	208/230/460			
Phase / Frequency <sup>1)</sup>	– / Hz	3 / 60			
Full load amps <sup>2)</sup> RUVAC WSU SOGEVAC		7.8/10.0/5.8 21.0/18.0/9.0	7.8/10.0/5.8 29.0/25.0/12.5	13.0/14.7/8.5 21.0/18.0/9.0	13.0/14.7/8.5 29.0/25.0/12.5
Displacement RUVAC SOGEVAC	cfm (m³/h) cfm (m³/h)	357 (606) 130 (606)	357 (606) 200 (340)	707 (1200) 130 (606)	707 (1200) 200 (340)
Oil capacity RUVAC WSU SOGEVAC	qt (l) qt (l)	1.1 (1.0) 5.3 (5.0)	1.1 (1.0) 9.0 (8.5)	2.1 (2.0) 5.3 (5.0)	2.1 (2.0) 9.0 (8.5)
Nominal rotation speed RUVAC WSU SOGEVAC	rpm (min⁻¹) rpm (min⁻¹)	3600 (3600) 1800 (1800)			
Motor power RUVAC WSU SOGEVAC	hp (kW) hp (kW)	3.3 (2.4) 7.5 (5.5)	3.3 (2.4) 10.0 (7.4)	6.0 (4.4) 7.5 (5.5)	6.0 (4.4) 10.0 (7.4)

# **Ordering Information**

# **HTS Close-Coupled Systems**

	501/SV200	501/SV300B	1001/SV200	1001/SV300B
	Part No.			
HTS - close-coupled systems		Ordering Information see right page		

<sup>1)</sup> For 50 Hz systems, consult the factory

<sup>2)</sup> Determined by operating voltage

Technical Data		<b>HTS Close-Coupled Systems</b>			
		1001/SV630B	2001/SV630B		
RUVAC		WSU 1001	WSU 2001		
SOGEVAC		SV 6	330 B		
Pumping speed at 0.1 Torr	cfm (m³/h)	610 (1035)	1186 (2031)		
Ultimate total pressure	Torr (mbar)	< 8 × 10 <sup>-3</sup> (< 1 × 10 <sup>-2</sup> )			
Connecting flanges Inlet port WSU Exhaust port SOGEVAC	DN DN	4" ANSI 4" ANSI	6" ANSI 4" ANSI		
Operating voltage	v	460			
Phase / Frequency 1)	– / Hz	3 / 60			
Full load amps <sup>2)</sup> RUVAC WSU SOGEVAC		8.5 29.5	5.0 29.5		
Displacement RUVAC WSU SOGEVAC	cfm (m³/h) cfm (m³/h)	707 (1200) 495 (840)	1449 (2460) 495 (840)		
Oil capacity RUVAC WSU SOGEVAC	qt (l) qt (l)	2.1 (12.0) 37.0 (35.0)	4.2 (4.0) 37.0 (35.0)		
Nominal rotation speed RUVAC WSU SOGEVAC	rpm (min <sup>-1</sup> ) rpm (min <sup>-1</sup> )	3600 (3600) 1170 (1170)			
Motor power RUVAC WSU SOGEVAC	hp (kW) hp (kW)	6.1 (4.5) 25.0 (13.4)	11.4 (8.4) 25.0 (13.4)		

# **Ordering Information**

Blower / TRIVAC pump	
WSU 501 / SV 200	5
WSU 501 / SV 300 B	5
WSU 1001 / SV 200	1
WSU 1001 / SV 300 B	1
WSU 1001 / SV 630 B	1
WSU 2001 / SV 630 B	2
Casters & Levelers (SV 200 & SV 300 only)	-
None	0
Casters & Levelers	1
Casters only	2
Levelers only	3
Electrical Control Panel	-
None	0
208 V (SV 200 & SV 300 only)	1
230 V (SV 200 & SV 300 only)	2
460 V	3
	1



Part No. 180036V-

# Oil Sealed Standard Vacuum Systems SOGEVAC



SOGEVAC Standard Vacuum Systems (SVS), configuration examples

Systems based on SOGEVAC rotary vane pumps in combination with Roots blowers from the RUVAC WA, WS or WH families are the industrial standard for all moderately demanding processes.

Vacuum systems based on oil-sealed SOGEVAC pumps deliver the best cost vs. performance ratio for a broad base of industrial applications.

#### Advantages to the User

- Fully modular system design with standard component combinations
- Smart combinations of SOGEVAC rotary vane pumps and RUVAC roots blowers
- Fast response times for quotations
- Shorter lead times compared to customized pump systems
- Well thought-out service concept
- Standard electrical cabinet with an identical operating concept
- Standard I/O interface
- Additional features like emergency stop switch "EMS"

#### Design

The two-stage SOGEVAC SYSTEMS consist of a combination of dry compressing Roots pumps and oil-sealed rotary vane pumps. The Roots pump installed on top of the backing pump serves as a booster for increasing the pumping speed in lower pressure ranges. Various types of pumps may be used with SOGEVAC SYSTEMS:

#### Roots pumps

RUVAC WA / WAU RUVAC WS / WSU RUVAC WH / WHU

#### Backing pumps

SOGEVAC SV

All SOGEVAC SYSTEMS described hereinafter are delivered as basic versions. The basic version can be customized according to individual requrirements with an electrical system control, gas ballast system, a shut-off valve, and / or an inlet filter.

The pumps are air- and/or watercooled and will be delivered either with mineral (LVO 1x0) or synthetic oil (LVO 210).



Naming conventions for SOGEVAC SYSTEMS

#### **Naming conventions**

The product designations of SOGEVAC SYSTEMS are rather obvious and indicate directly which pumps were combined for a specific system:

- The first three letters "SVS" stand for "SOGEVAC SYSTEM"
- The next (up to 4 alphanumeric) characters stand for the RUVAC version
- The following 4 characters stand for the SOGEVAC's pumping speed and version
- The last two characters give hints on the features of the pump system

Vacuum Pump Systems



Pumping speed characteristics SVS xxxA20 50Hz, without gas ballast







Pumping speed characteristics SVS xxxA63 50Hz, without gas ballast



Pumping speed characteristics SVS xxxU75 50Hz, without gas ballast















Pumping speed characteristics SVS xxxF75 50Hz, without gas ballast

leybold



Dimensional drawing for SVS 07H 30B A / SVS 07H 30B AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 05AU 20 G / SVS 05AU 20 GE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 07H 30B A / SVS 07H 30B AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 07HF 30B G / SVS 07HF 30B GE with all configuration options (dimensions in mm)


Dimensional drawing for SVS 10AU 30B A / SVS 10AU 30B AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 10AU 30B G / SVS 10AU 30B GE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 10AU 30B G / SVS 10AU 30B GE with filter valve combination with all configuration options (dimensions in mm)



Dimensional drawing for SVS 44HF 63BF A ~ / SVS 44HF 75BF A and SVS 44HF 63BF AE ~ / SVS 44HF 75BF AE with filter combination with all configuration options (dimensions in mm)



Dimensional drawing for SVS 20AU 63BF A / SVS 20AU 75BF A / SVS 20AU 63BF AE / SVS 20AU 75BF AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 20AU 30B G /SVS 20AU 30B GE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 25H 63BF A / SVS 25H 75BF A / SVS 25H 63BF AE / SVS 25H 75BF AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 25H 63BF G / SVS 25H 75BF G / SVS 25H 63BF GE / SVS 25H 75BF GE with all configuration options (dimensions in mm)

leybold



Dimensional drawing for SVS 44HF 63BF A / SVS 44HF 75BF A / SVS 44HF 63BF AE / SVS 44HF 75BF AE with all configuration options (dimensions in mm)



Dimensional drawing for SVS 44H 63BF G  $\sim$  / SVS 44H 75BF G / SVS 44H 63BF GE  $\sim$ / SVS 44H 75BF GE with filter valve combination with all configuration options (dimensions in mm)



Dimensional drawing for SVS 70H 63BF G GE / SVS 70H 75BF G/GE / SVS 70HU 63BF G/GE / SVS 70HU 75BF G/GE SVS 70HF 63BF G/GE / SVS 70HF 75BF G/GE with all configuration options (dimensions in mm)

#### **Technical Data**

#### SOGEVAC SYSTEM SVS

	05A(U) 20	05S(U) 20	05A(U) 30B	05S(U) 30B		
Nom. pump speed (50/60Hz)	505 / 606 m³/h					
Max. effective pumping speed (50/60Hz)	410 / 4	90 m³/h	424 / 5	05 m³/h		
Ult. total pressure w/o gas ballast		≤ 8.0 x 1	10 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast default (7 – 7.5 Nm <sup>3</sup> /h) electromagnetic (7 – 10 Nm <sup>3</sup> /h) large (15 – 18 Nm <sup>3</sup> /h)	$\leq 4.0 \times 10^{-1}$ $\leq 4.0 \times 10^{-1}$	10 <sup>-2</sup> mbar 10 <sup>-2</sup> mbar	$\leq 4.0 \times 10^{-1}$ $\leq 4.0 \times 10^{-1}$	10 <sup>-2</sup> mbar 10 <sup>-2</sup> mbar		
Maximum permissible inlet pressure		1 013	mbar			
Maximum permissible discharge pressure (relative to ambient)	+150 mbar					
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	3.4 / 5.4 kg * h <sup>-1</sup> 1.3 / 1.8 kg * h <sup>-1</sup> 3.4 / 5.4 kg * h <sup>-1</sup> 1.3 / 1.8 kg * h <sup>-1</sup>					
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) 6) SOGEVAC (50/60Hz)	$\leq 69 / \leq 73 \text{ dB(A)} \leq 72 / \leq 76 \text{ dB(A)}$					
Roots (50/60Hz)	≤ 67 dB(A)	≤ 63 dB(A)	≤ 67 dB(A)	≤ 63 dB(A)		
Relative atmospheric humidity		95 %, non-	condensing			
Installation location		up to 2 000	) m (NHN) <sup>2)</sup>			
Mains voltages and frequencies		400V 50Hz .	/ 460V 60Hz			
Phases		3-	ph			
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	4 kW 2.2 kW 6.2 kW	4 kW 2.2 / 2.4 kW 6.2 / 6.4 kW	6 / 7.2 KW 2.2 KW 8.2 / 9.4 KW	6 / 7.2 KW 2.2 / 2.4 KW 8.2 / 9.6 kW		
Max. speed Roots		3 60	0 rpm			
Min. permissible speed Roots (off) 4)			off			
Protection class	IP54	IP20	IP54	IP20		
Lubricant filling SOGEVAC Roots	LVO 130 / 210 LVO 100	LVO 130 / 210 LVO 100 / 210	LVO 130 / 210 LVO 100	LVO 130 / 210 LVO 100 / 210		
Intake flange		DN 63	ISO-K			
Discharge flange	G2					

 Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line (",U"-pumps).

- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.
  The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	SOGEVAC SYSTEM SVS					
	07H 20	07HF 20	07H 30B	07HF 30B		
Nom. pump speed (50/60Hz)	700 / 840 m³/h	1 680 m <sup>3</sup> /h	700 / 840 m <sup>3</sup> /h	1 680 m³/h		
Max. effective pumping speed (50/60Hz)	601 / 715 m³/h	1164 / 1192 m <sup>3</sup> /h	621 / 735 m³/h	1209 / 1228 m <sup>3</sup> /h		
Ult. total pressure w/o gas ballast		≤ 8.0 x 1	0 <sup>-3</sup> mbar	-		
Ult. total pressure w/ gas ballast default (7 – 7.5 Nm <sup>3</sup> /h) electromagnetic (7 – 10 Nm <sup>3</sup> /h) large (15 – 18 Nm <sup>3</sup> /h)	$\leq 4.0 \times 1$ $\leq 4.0 \times 1$	10 <sup>-2</sup> mbar 10 <sup>-2</sup> mbar	≤ 4.0 x ≤ 4.0 x	10 <sup>-2</sup> mbar 10 <sup>-2</sup> mbar		
Maximum permissible inlet pressure		1013	mbar			
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	3.4 / 5.4 3.4 / 5.4	4 kg * h <sup>-1</sup> 4 kg * h <sup>-1</sup>	1.3 / 1.8 kg * h <sup>-1</sup> 1.3 / 1.8 kg * h <sup>-1</sup>			
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) <sup>6)</sup> SOGEVAC (50/60Hz)	≤ 69 / ≤	73 dB(A)	≤ 72 / ≤ 76 dB(A)			
Roots (50/60Hz)	≤ 56 dB(A)	$\leq$ 56 dB(A) $\leq$ 60 dB(A)		$\leq$ 60 dB(A)		
Relative atmospheric humidity		95 %, non-c	condensing			
Installation location	up to 2 000 m	up to 1 000 m	up to 2 000 m	up to 1 000 m		
Mains voltages and frequencies (tolerances included w/ given values)		400V 50Hz /	460V 60Hz			
Phases		3-p	ph			
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	4 kW 2.2 / 2.6 kW 6.2 / 6.6 kW	4 kW      6 / 7.2 KW        xW      3.5 kW      2.2 / 2.6 KV        xW      7.5 kW      8.2 / 9.8 kV		6 / 7.2 KW 3.5 KW 9.5 / 10.7 kW		
Max. speed Roots	3 600 rpm	7 200 rpm	3 600 rpm	7 200 rpm		
Min. permissible speed Roots (off) 4)	off	1 200 rpm	off	1 200 rpm		
Protection class		IP5	54			
Lubricant filling SOGEVAC Roots		LVO 130 / 210 LVO 210				
Intake flange		DN 100	ISO-K			
Discharge flange		G	2			

 Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).

- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>

 4) The minimum permissible frequency for the RUVAC is 20 Hz.
 The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.

- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data SOGEVAC SYSTEM SVS						
	10A(U) 20	10S(U) 20	10A(U) 30B	10S(U) 30B		
Nom. pump speed (50/60Hz)		1 000 / 1	200 m³/h			
Max. effective pumping speed (50/60Hz)	760 / 9	909 m³/h	796 / 9	948 m³/h		
Ult. total pressure w/o gas ballast		≤ 8.0 x 1	0 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast default (7 – 7.5 Nm <sup>3</sup> /h) electromagnetic (7 – 10 Nm <sup>3</sup> /h) large (15 – 18 Nm <sup>3</sup> /h)	≤ 4.0 x ≤ 4.0 x	10 <sup>.2</sup> mbar 10 <sup>.2</sup> mbar	≤ 4.0 x ≤ 4.0 x	10 <sup>-2</sup> mbar 10 <sup>-2</sup> mbar		
Maximum permissible inlet pressure		1 013 mbar				
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	3.4 / 5. 3.4 / 5.	4 kg * h <sup>-1</sup> 4 kg * h <sup>-1</sup>	1.3 / 1. 1.3 / 1.	1.3 / 1.8 kg * h <sup>-1</sup> 1.3 / 1.8 kg * h <sup>-1</sup>		
Permissible ambient temperature		+12 + 40 °C				
Storage temperature	-10 + 60 °C					
Noise level (rigid exhaust pipe) <sup>6)</sup> SOGEVAC (50/60Hz)	≤ 69 / ≤	$\leq 69 / \leq 73 \text{ dB(A)} \leq 72 / \leq 76 \text{ dB(A)}$				
Roots (50/60Hz)	≤ 75 dB(A)	≤ 68 dB(A)	≤ 75 dB(A)	≤ 68 dB(A)		
Relative atmospheric humidity		95 %, non-	condensing			
Installation location		up to 2 000	) m (NHN) <sup>2)</sup>			
Mains voltages and frequencies		400V 50Hz /	/ 460V 60Hz			
Phases		3-	ph			
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	4 kW 4 kW 8 kW	4 kW 4 / 4.4 KW 8 / 8.4 kW	6 / 7.2 KW 4 KW 10 / 11.2 kW	6 / 7.2 KW 4 / 4.4 KW 10 / 11.6 kW		
Max. speed Roots		3 60	0 rpm			
Min. permissible speed Roots (off) 4)		(	off			
Protection class	IP54 IP20 IP54		IP54	IP20		
Lubricant filling SOGEVAC Roots	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210		
Intake flange		DN 100	) ISO-K			
Discharge flange	G2					

- 1) Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.
- 4) The minimum permissible frequency for the RUVAC is 20 Hz. The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	SOGEVAC SYSTEM SVS					
	20A(U) 63B	20S(U) 63B	20A(U) 63BF	20S(U) 63BF		
Nom. pump speed (50/60Hz)		2 000 / 2	2 400 m³/h			
Max. effective pumping speed (50/60Hz)	1 750 / 2	080 m³/h	1 760 / 2	090 m³/h		
Ult. total pressure w/o gas ballast		≤ 5.0 x <sup>-</sup>	10 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast manual (22.5 – 27.5 Nm <sup>3</sup> /h) electromagnetic (17.55 – 21.45 Nm <sup>3</sup> /h) large		$\leq 5.0 \times 10^{-2}$ $\leq 5.0 \times 10^{-2}$	10 <sup>-1</sup> mbar 10 <sup>-1</sup> mbar			
Maximum permissible inlet pressure		1 013	3 mbar			
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	17 / 24 17 / 24	17 / 24 kg * h <sup>-1</sup> 17 / 24 kg * h <sup>-1</sup> 17 / 24 kg * h <sup>-1</sup> 11 / 14 kg * h <sup>-1</sup>				
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) 6) SOGEVAC (50/60Hz)	≤ 72 / ≤	$\leq$ 72 / $\leq$ 75 dB(A) $\leq$ 72 dB(A)				
Roots (50/60Hz)	≤ 80 dB(A)	≤ 72 dB(A)	≤ 80 dB(A)	≤ 72 dB(A)		
Relative atmospheric humidity		95%, non-	condensing			
Installation location		up to 2 000	0 m (NHN) <sup>2)</sup>			
Mains voltages and frequencies		400V 50Hz	/ 460V 60Hz			
Phases		3-	ph			
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	15 / 17 kW 7.5 kW 22.5 / 24.5 kW	15 / 17 kW 7.5 / 8.5 KW 22.5 / 25.5 kW	15 / 17 KW 7.5 / 7.5 KW 22.5 / 24.5 kW	15 / 17 KW 7.5 / 8.5 KW 22.5 / 25.5 kW		
Max. speed Roots		3 000 /	3 600 rpm			
Min. permissible speed Roots (off) 4)			off			
Protection class	IP54 IP20 IP54		IP54	IP20		
Lubricant filling SOGEVAC Roots	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210		
Intake flange		DN 16	0 ISO-K			
Discharge flange		DN 10	0 ISO-K			

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.
  The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	SOGEVAC SYSTEM SVS					
	20A(U) 75B	20S(U) 75B	20A(U) 75BF	20S(U) 75BF		
Nom. pump speed (50Hz)		2 000	m³/h			
Max. effective pumping speed (50Hz)		1 780	m³/h			
Ult. total pressure w/o gas ballast		≤ 5.0 x 1	0 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast manual (22.5 – 27.5 Nm <sup>3</sup> /h) electromagnetic (17.55 – 21.45 Nm <sup>3</sup> /h) large		≤ 5.0 × 1 ≤ 5.0 × 1	0 <sup>-1</sup> mbar 0 <sup>-1</sup> mbar			
Maximum permissible inlet pressure		1 013 mbar				
Maximum permissible discharge pressure (relative to ambient)		+150	mbar			
Water vapor capacity w/ gas ballast default (50 Hz) electromagnetic (50 Hz) large (50 Hz)	24 kg 24 kg	24 kg * h <sup>-1</sup> 24 kg * h <sup>-1</sup>				
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) 6) SOGEVAC (50 Hz)		≤ 72 dB(A)				
Roots (50 Hz)	≤ 80 dB(A)	≤ 72 dB(A)	≤ 80 dB(A)	≤ 72 dB(A)		
Relative atmospheric humidity		95 %, non-c	condensing			
Installation location		up to 2 000	m (NHN) 2)			
Mains voltages and frequencies		400V	50Hz			
Phases		3-p	bh			
Rated power (400V 50Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	18.5 kW 7.5 kW 26 kW					
Max. speed Roots		3 000 / 3	8 600 rpm			
Min. permissible speed Roots (off) 4)		С	off			
Protection class	IP54	IP20	IP54	IP20		
Lubricant filling SOGEVAC Roots	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210	LVO 130 LVO 100	LVO 130 / 210 LVO 100 / 210		
Intake flange		DN 160	ISO-K			
Discharge flange		DN 100 ISO-K				

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line (",U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	Inical Data SOGEVAC SYSTEM SVS					
	25H(U) 63BF	25HF 63BF	25H(U) 75BF	25HF 75BF		
Nom. pump speed (50/60Hz)	2500/3000 m <sup>3</sup> /h	5000/5000 m <sup>3</sup> /h	2 500 m³/h / –	5 000 m³/h / –		
Max. effective pumping speed (50/60Hz)	2100/2540 m <sup>3</sup> /h	3700/3790 m <sup>3</sup> /h	2 180 m³/h / –	3 800 m³/h / –		
Ult. total pressure w/o gas ballast		≤ 5.0 x 1	0 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast manual (22.5 – 27.5 Nm <sup>3</sup> /h) electromagnetic (17.55 – 21.45 Nm <sup>3</sup> /h) large		$\leq 5.0 \times 10^{-1} \text{ mbar}$ $\leq 5.0 \times 10^{-1} \text{ mbar}$				
Maximum permissible inlet pressure		1 013 mbar				
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	11 / 14 11 / 14	11 / 14 kg * h <sup>-1</sup> 11 / 14 kg * h <sup>-1</sup> 11 / 14 kg * h <sup>-1</sup> 14 kg * h <sup>-1</sup> / –				
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) 6) SOGEVAC (50/60Hz)		≤ 72 dB(A)				
Roots (50/60Hz)		≤ 63 (	dB(A)			
Relative atmospheric humidity		95%, non-c	condensing	1		
Installation location	up to 2 000 m	up to 1 000 m	up to 2 000 m	up to 1 000 m		
Mains voltages and frequencies	400V 50Hz /	460V 60Hz	400V	50Hz		
Phases		3-p	bh	1		
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	15 / 17 kW 6.2 / 7.4 kW 21.2 / 24.4 kW	15 / 17 kW 11 KW 26 / 38 kW	18.5 KW / – 6.2 KW / – 24.7 kW / –	18.5 KW / – 11 KW / – 29.5 kW / –		
Max. speed Roots	3 000 / 3 600 rpm	6 000 / 6 000 rpm	3 000 / 3 600 rpm	6 000 / 6 000 rpm		
Min. permissible speed Roots (off) 4)	off	1 200 / 1 200 rpm	off	1 200 / 1 200 rpm		
Protection class		IP5	54			
Lubricant filling SOGEVAC Roots		LVO 130 / 210 LVO 210				
Intake flange		DN 250	ISO-K			
Discharge flange		DN 100 ISO-K				

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.
  The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	SOGEVAC SYSTEM SVS					
	44H(U) 63BF	44HF 63BF	44H(U) 75BF	44HF 75BF		
Nom. pump speed (50/60Hz)	4400/5280 m <sup>3</sup> /h	7040/7040 m <sup>3</sup> /h	4 400 m <sup>3</sup> /h	7 040 m³/h		
Max. effective pumping speed (50/60Hz)	3610/4250 m <sup>3</sup> /h	5120/5220 m <sup>3</sup> /h	3 680 m³/h	5 230 m³/h		
Ult. total pressure w/o gas ballast		<u>≤</u> 5.0 x 1	0 <sup>-3</sup> mbar	,		
Ult. total pressure w/ gas ballast manual (22.5 – 27.5 Nm <sup>3</sup> /h) electromagnetic (17.55 – 21.45 Nm <sup>3</sup> /h) large		$\leq 5.0 \times 10^{-1} \text{ mbar}$ $\leq 5.0 \times 10^{-1} \text{ mbar}$				
Maximum permissible inlet pressure		1 013 mbar				
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	11 / 14 11 / 14	11 / 14 kg * h <sup>-1</sup> 14 kg * h <sup>-1</sup> /    11 / 14 kg * h <sup>-1</sup> 14 kg * h <sup>-1</sup> /				
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) <sup>6)</sup> SOGEVAC (50/60Hz)		≤ 72 dB(A)				
Roots (50/60Hz)		≤ 63 (	dB(A)			
		95%, non-c	condensing	1 4 000		
	up to 2 000 m		up to 2 000 m			
Mains voltages and frequencies	400V 50Hz /	460V 60Hz	4000	50Hz		
Phases		3-p	bh	1		
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	15 / 17 kW 11 kW 18.5 / 18.5 kW 26 / 28 kW 33.5 / 35.5 kW	15 / 17 kW 11 kW 26 / 28 kW	18.5 KW / – 11 KW / – 18.5 KW / – 29.5 kW / – 37 kW / –	18.5 KW / – 11 KW / – 29.5 kW / –		
Max. speed Roots	3 000 / 3 600 rpm	4 800 / 4 800 rpm	3 000 / 3 600 rpm	4 800 / 4 800 rpm		
Min. permissible speed Roots (off) 4)	off	1 200 / 1 200 rpm	off	1 200 / 1 200 rpm		
Protection class		IPS	54	1		
Lubricant filling SOGEVAC Roots		LVO 130 LVO	0 / 210 210			
Intake flange		DN 250	ISO-K			
Discharge flange		DN 100	ISO-K			

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line (",U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.
  The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than
  1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.

Technical Data	SOGEVAC SYSTEM SVS					
	70H(U) 63BF	70HF 63BF	70H(U) 75BF	70HF 75BF		
Nom. pump speed (50/60Hz)	7000/8400 m <sup>3</sup> /h	9800/9800 m <sup>3</sup> /h	7 000 m³/h	9 800 m³/h		
Max. effective pumping speed (50/60Hz)	5030/6000 m <sup>3</sup> /h	6460/6720 m <sup>3</sup> /h	5 260 m³/h	6 800 m³/h		
Ult. total pressure w/o gas ballast		≤ 5.0 x 1	0 <sup>-3</sup> mbar			
Ult. total pressure w/ gas ballast manual (22.5 – 27.5 Nm <sup>3</sup> /h) electromagnetic (17.55 – 21.45 Nm <sup>3</sup> /h) large		$\leq 5.0 \times 10^{-1} \text{ mbar}$ $\leq 5.0 \times 10^{-1} \text{ mbar}$				
Maximum permissible inlet pressure		1 013	mbar			
Maximum permissible discharge pressure (relative to ambient)		+150 mbar				
Water vapor capacity w/ gas ballast default (50/60 Hz) electromagnetic (50/60 Hz) large (50/60 Hz)	11 / 14 kg * h <sup>-1</sup> 11 / 14 kg * h <sup>-1</sup> 14 kg * h <sup>-1</sup> / –					
Permissible ambient temperature		+12 + 40 °C				
Storage temperature		-10 + 60 °C				
Noise level (rigid exhaust pipe) 6) SOGEVAC (50/60Hz)		≤ 72 dB(A)				
Roots (50/60Hz)		≤ 63 (	dB(A)			
Relative atmospheric humidity		95%, non-c	condensing	1		
Installation location	up to 2 000 m	up to 1 000 m	up to 2 000 m	up to 1 000 m		
Mains voltages and frequencies	400V 50Hz /	460V 60Hz	400V	50Hz		
Phases		3-r	bh	1		
Rated power (400V 50Hz / 460V 60Hz) SOGEVAC Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	15 / 17 kW 11 kW 18.5 / 18.5 kW 26 / 28 kW 33.5 / 35.5 kW	15 / 17 kW 11 kW 26 / 28 kW	18.5 KW / – 11 KW / – 29.5 kW / –	18.5 KW / – 11 KW / – 29.5 kW / –		
Max. speed Roots	3 000 / 3 600 rpm	4 200 / 4 200 rpm	3 000 / 3 600 rpm	4 200 / 4 200 rpm		
Min. permissible speed Roots (off) 4)	off	1 200 / 1 200 rpm	off	1 200 / 1 200 rpm		
Protection class		IP5	54			
Lubricant filling SOGEVAC Roots		LVO 130 / 210 LVO 210				
Intake flange		DN 320	ISO-K			
Discharge flange		DN 100 ISO-K				

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1,000 m. If the altitude exceeds 1,000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling, and permanent operation at nominal power, the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency for the RUVAC is 20 Hz.
  The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than
  1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.
- 7) In the EU, the drive's energy efficiency is equal to IE3 during RUVAC operations with a frequency converter. During RUVAC WH operations w/o frequency converter the energy efficiency is equal to IE2.



Configuration matrix for ordering SOGEVAC SYSTEMS

#### **Configuration matrix**

Part numbers for SOGEVAC SYSTEMS are based on the matrix shown in the figure above and give hints on the individual configuration and features of the pump combination in question.

#### **Ordering Information**

#### **SOGEVAC SYSTEMS**

Part No.	Description	Short name	name SOGEVAC SV 400 V RUVAC Motor Type 400 V		RUVAC 400 V	Lubricant
SVS013021A0000	SVS 05AU20-A	SVS 0520	SV200	Wide Range	WAU501H	1x0
SVS011021A0000	SVS 05AU20-A	SVS 0520	SV200 Wide Range WAU501		WAU501	1x0
SVS023041A0000	SVS 10AU30B-A	SVS 1030	SV300B	Wide Range	WAU1001H	1x0
SVS021041A0000	SVS 10AU30B-A	SVS 1030	SV300B	Wide Range	WAU1001	1x0
SVS050041A0000	SVS 10S30B-A	SVS 1030	SV300B	Wide Range	WS1001	1x0
SVS033041G0000	SVS 20AU30B-G	SVS 2030	SV300B	Wide Range	WAU2001H	1x0
SVS031031G0000	SVS 20AU30B-G	SVS 2030	SV300B	Wide Range	WAU2001	1x0
SVS033071A0000	SVS 20AU63BF-A	SVS 2063	SV630BF	EU	WAU2001H	1x0
SVS033081A0000	SVS 20AU63BF-A	SVS 2063	SV630BF	Wide Range	WAU2001H	1x0
SVS031071A0010	SVS 20AU63BF-A	SVS 2063	SV630BF	EU	WAU2001	1x0
SVS031081A0010	SVS 20AU63BF-A	SVS 2063	SV630BF	Wide Range	WAU2001	1x0
SVS033071G0000	SVS 20AU63BF-G	SVS 2063	SV630BF	EU	WAU2001H	1x0
SVS033081G0000	SVS 20AU63BF-G	SVS 2063	SV630BF	Wide Range	WAU2001H	1x0
SVS080072A0010	SVS 25H63BF-A	SVS 2563	SV630BF	EU	WH2500	210
SVS090072A0010	SVS 44H63BF-A	SVS 4463	SV630BF	EU	WH4400	210
SVS100072G0010	SVS 70H63BF-G	SVS 7063	SV630BF	EU	WH7000	210

Additional systems in preparation. All SOGEVAC-SYSTEMS described here are delivered as basic models. Basic versions can be extended with an electric control unit, gas ballast, a shut-off valve and/or inlet filter if required.

#### Accessories

	Part No.
Mineral oil	
LEYBONOL LVO 100, 1 litre	L10001
LEYBONOL LVO 100, 5 litres	L10005
LEYBONOL LVO 130, 1 litre	L13001
LEYBONOL LVO 130, 5 litres	L13005
LEYBONOL LVO 130, 20 litres	L13020
Synthetic oil	
LEYBONOL LVO 210, 1 litre	L21001
LEYBONOL LVO 210, 5 litres	L21005
LEYBONOL LVO 210, 20 litres	L21020
Gearbox evacuation kit (GBE) WSU / WAU	155184V
Gearbox evacuation kit (GBE) WH4400/7000	155183V
Ground fixation	503637V001

#### Notes

## Central Vacuum Supply Systems with SOGEVAC Pumps



Central vacuum supply systems: CVS500 with 3 SOGEVAC SV 100 B, CVS 160 with 2 SOGEVAC SV 100 B, CVS 60 with 1 SOGEVAC SV 40 B

Central vacuum supply systems are frequently used in those cases where a large number of minor requirements for vacuum need to be economically covered. Moreover, the systems serve the purpose of compensating for large variations in the number of vacuum consumers and increase the availability of the vacuum service.

A typical central vacuum supply system from Leybold consists chiefly of one or more SOGEVAC rotary vane vacuum pumps, a buffer vessel, an electrical cabinet with controller as well as the corresponding connection components. The systems are supplied by us fully assembled, tested as plug and play units.

#### Standard Equipment

#### Typically consisting of

- up to 3 SOGEVAC pumps
- buffer vessel
- manual valve (basic control) or electropneumatic valve (PLC control)
- dust filter at the pump inlet
- pressure sensor
- two-stage pressure controller
- electrical cabinet with controller
- all connecting components

#### Advantages to the User

- Industrial grade vacuum generator consisting of proven SOGEVAC single-stage rotary vane vacuum pumps
- Covers the demands of numerous small vacuum consumers
- Modular design, customized to customer specific processes
- Simple to operate
- Space-saving system solution
- High return on investment, excellent price-to-performance ratio
- Energy saving capabilities
- Low cost of ownership
- Cycle time reduction due to the buffer volume
- Complete turn-key systems, ready for operation

#### **Typical Applications**

## General applications demanding vacuum:

- Transportation
- Handling / lifting
- Degassing
- Automation (pick and place)

#### Automotive industry

- Thermoforming
- Break filling, degassing

#### Composites manufacturing

- Resin Transfer Moulding (RTM)

### Vacuum pressing, like rubber, plastics, gaskets

#### Food packaging/food processing

- Vacuum filling
- Thermoforming
- Vacuum transportation, handling, lifting
- Tray sealing / MAP packaging
- Degassing

#### Hospitals/Medical engineering

- Bacteriological filters

## Controller Types for the Central Vacuum Supply Systems from Leybold

Generally a difference is made between the controller types **BASIC** and **FF** (Full Featured).

Differing custom solutions are available upon request.

#### **BASIC Controller**

The Basic controller provides for two freely selectable switching thresholds, through which an individual vacuum pump or alternatively a blocking valve (optional) can be driven. Moreover, the controller includes an electronic pressure display and an operating hours counter.

This type of controller is suited for systems equipped with a single pump up to a nominal pumping speed of  $100 \text{ m}^3/\text{h} (58.9 \text{ cfm}).$ 



Basic control with one pump

#### Operating Principle of the BASIC Controller

Starting at atmospheric pressure, the central vacuum supply system is evacuated down to the intended "lower operating pressure" S0. As soon as the pressure has attained the level of S0, the vacuum pump is switched off automatically, respectively the optional blocking valve is closed. When switching on the consumers, the pressure in the system rises again until the "upper operating pressure" is reached thereby tripping the switch-on threshold S1 of the pump, respectively attaining the opening pressure of the valve.

Provided pumping speed of the pump and vacuum consumption are balanced, the operating pressure will change between S0 and S1. At reduced consumption, the system pressure will reduce until the switching threshold S0 is reached again causing the pump to switch off, respectively the valve to close etc.

#### **FF Controller**

Basically the FF controller provides for four freely selectable switching thresholds and has thus been designed to operate two pumps running in parallel. Depending on the design rating and current demand, the base load or master pump will operate alone or jointly together with the spare pump. In order to spread the number of operating hours equally between the pumps, master pump and spare pump are interchanged in regular intervals. In case a pump fails, the controller effects an automatic change to the spare pump.

For operating vacuum pumps having a nominal pumping speed of over 100 m<sup>3</sup>/h (58.9 cfm), a delayed shutdown facility has been integrated which will restrict the number of switching cycles to 6 per hour.

Through the use of a Programmable Logic Controller (PLC), the FF controller permits flexible coverage of quite differing requirements.



FF controller with two pumps and an example for delayed shutdown (pumps over 100 m³/h (58.9 cfm))

#### Operating Principle of the FF Controller

Just as for the Basic controller, the system is, upon switching on, evacuated down to the lower operating pressure S0. This is effected with both pumps running in parallel (master pump and spare pump) until the shutdown threshold for the spare pump S2 is reached. Thereafter, the master pump alone will ensure that the lower operating pressure is reached and is then also switched off. When the system pressure increases due to the number of consumers or leaks to the level of S1, then the master pump will be switched on automatically etc. In the case of vacuum pumps having a pumping speed of over 100 m<sup>3</sup>/h (58.9 cfm) and a running time of the pump of less than 10 minutes, then the standard switch off delay can be responsible for the pressure to drop below S0. This will prevent too frequent switching on and off of the pumps.

If for process reasons the pressure is not allowed to drop below the lower operating pressure, we recommend the use of electropneumatic or solenoid blocking valves.

If the current vacuum demand cannot be met by the master pump alone, the system pressure will increase to the upper switching pressure S3 upon which the spare pump is automatically started.

With both pumps running in parallel, the system is then again evacuated until the switch off threshold S2 for the spare pump is reached again etc.



Dimensional drawing CVS60 with SV25B

CVS-System *	Α	В	С	D	Е	F	G	н
CVS60 1xSV25B	973	1163	280	G 1¼"	G ¾"	G ½"	656	653
CVS60 1xSV40B	973	1163	280	G 1¼"	G 1¼"	G ½"	656	697

\* Dimensions in mm



Dimensional drawing CVS160 with SV65B

CVS-System *	Α	В	С	D	Е	F	G	н
CVS160 1xSV65B	1542	1045	325	G 1¼"	G 1¼"	G ½"	766	787
CVS300 1XSV65B	1819	1155	385	G2"	G 1¼"	G ½"	826	897
CVS160 1XSV100B	1542	1050	325	G 1¼"	G 1¼"	G ½"	766	791
CVS300 1XSV100B	1819	1160	385	G2"	G 1¼"	G ½"	826	901
CVS500 1XSV100B	1976	1310	485	G2"	G 1¼"	G 1¼"	927	1051
CVS500 1XSV200	1976	1509	485	G2"	G2"	G 1¼"	927	1149
CVS1000 1XSV200	2395	1719	585	G2"	G2"	G 1¼"	1136	1359
CVS500 1XSV300B	1976	1514	485	G2"	G2"	G 1¼"	927	1161
CVS1000 1XSV300B	2395	1724	585	G2"	G2"	G 1¼"	1136	1371

\* Dimensions in mm



Dimensional drawing CVS160 with 2x SV65B

CVS-System *	Α	в	С	D	Е	F	G	н
CVS500 2xSV100B	1976	1310	485	G 2"	G 1¼"	G 1¼"	940	1051
CVS500 2xSV200	1976	1509	485	G 2"	G2"	G 1¼"	1107	1149
CVS1000 2xSV200	2395	1719	585	G 2"	G2"	G 1¼"	1223	1359
CVS500 2xSV300B	1976	1514	485	G 2"	G2"	G 1¼"	1107	1161
CVS1000 2xSV300B	2395	1724	585	G 2"	G2"	G 1¼"	1189	1371

 $\boldsymbol{\star}$  Dimensions in mm

#### **Technical Data and Ordering Information**

#### **CVS BASIC Systems**

Part No.	Designation	Nominal	Weight,	Connection	Noise	Motor	Nominal	Power
		pumping	approx.	Inlet / Exhaust	level**	power	current	connection
		speed*					max.	
		m³/h	kg	G or NPT	dB(A)	kW	Α	
504309V001	$CVS60 = 1 \times SV25B$	26	1/15	11/4" / 3/4"	64	0,9	2,3	400 V / 50 Hz
0040034001	00000 1 x 00200	20	140	1/4 / /4	04	1,1	2,6	460 V / 60 Hz
504309V002	CVS60 – 1 x SV40B	44	165	11⁄4" / 11⁄4"	58	1,1	2,8	400 V / 50 Hz
						1,5	2,7	460 V / 60 Hz
504310V001	CVS160 - 1 x SV65B	59	255	11⁄4" / 11⁄4"	60	1,5	3,8	400 V / 50 HZ
						2.2	4.5	400 V / 50 Hz
504310V004	CVS160 – 1 x SV100B	97,5	295	11⁄4" / 11⁄4"	61	3,5	5,3	460 V / 60 Hz
E04244V004		FO	240	0"/11/"	60	1,5	3,8	400 V / 50 Hz
5043110001	CVS300 - 1 X SV65B	59	340	2 / 1 /4	60	1,8	3,7	460 V / 60 Hz
504311V004	$CVS300 = 1 \times SV100B$	97 5	335	2" / 11/4"	61	2,2	4,5	400 V / 50 Hz
0040110004		57,0	000	2 / 1/4	01	3,5	5,3	460 V / 60 Hz
504312V006	CVS500 - 1 x SV100B	97.5	415	2" / 1¼"	61	2,2	4,5	400 V / 50 Hz
		- /-				3,5	5,3	460 V / 60 Hz
504312V007	CVS500 - 2 x SV100B	195	550	2" / 1¼"	64	4,4	9,0	400 V / 50 Hz
						7,0	10,0	400 V / 60 HZ
504312V011	CVS500 - 1 x SV200	180	460	2" / 2"	69	4,0	10.0	460 V / 60 Hz
				o.u. / o.u		8.0	17.8	400 V / 50 Hz
504312V012	CVS500 – 2 x SV200	360	630	2" / 2"	72	9,2	20,0	460 V / 60 Hz
50/212/01/	CV/9500 1 x 9V/2008	280	500	0"/0"	70	5,5	10,5	400 V / 50 Hz
5045120014	CV3500 - 1 X 3V500D	200	500	212	12	6,3	9,3	460 V / 60 Hz
504312V015	CVS500 - 2 x SV300B	560	725	2"/2"	75	11,0	21,0	400 V / 50 Hz
			0	_ / _		12,6	18,6	460 V / 60 Hz
504313V011	CVS1000 - 1 x SV200	180	600	2" / 2"	69	4,0	8,9	400 V / 50 Hz
						4,6	10,0	460 V / 60 Hz
504313V012	CVS1000 - 2 x SV200	360	775	2" / 2"	72	8,U 9,2	20.0	400 V / 50 HZ
						5.5	10.5	400 V / 50 Hz
504313V016	CVS1000 - 1 x SV300B	280	640	2" / 2"	72	6.3	9.3	460 V / 60 Hz
5040401645	0.101000 0.010000	500	000	01 ( 01	75	11,0	21,0	400 V / 50 Hz
5043130017	CVS1000 - 2 X SV300B	560	860	2"/2"	15	12,6	18,6	460 V / 60 Hz

\* 50 Hz

 $^{\star\star}$  At ultimate pressure without gas ballast, free-field measurement, distance 1 m  $\,$ 

Beyond the equipment which is supplied as standard, the modular design of the central vacuum supply systems from Leybold allows for customization according to your specific requirements.

Optionally available are, for example:

- Higher pumping speeds and larger buffer volumes
- Electropneumatic or solenoid blocking valves
- Mobile construction on castors
- Other mains voltages
- Additional pumps, filters, fittings etc.

#### **Technical Data and Ordering Information**

#### **CVS FF Systems**

Part No.	Designation	Nominal	Weight,	Connection	Noise	Motor	Nominal	Power
		pumping	approx.	Inlet / Exhaust	level**	power	current	connection
		speed*					max.	
		m³/h	kg	G or NPT	dB(A)	kW	Α	
504310V050	CVS160 – 2 x SV65B	118	350	11⁄4" / 11⁄4"	63	3,0 3,6	7,6 7,4	400 V / 50 Hz 460 V / 60 Hz
504310V051	CVS160 – 2 x SV100B	195	430	11⁄4" / 11⁄4"	64	4,4 7,0	9,0 10,6	400 V / 50 Hz 460 V / 60 Hz
504311V050	CVS300 – 2 x SV65B	118	410	2" / 1¼"	63	3,0 3,6	7,6 7,4	400 V / 50 Hz 460 V / 60 Hz
504311V051	CVS300 – 2 x SV100B	195	470	2" / 1¼"	64	4,4 7,0	9,0 10,6	400 V / 50 Hz 460 V / 60 Hz
504312V050	CVS500 – 3 x SV65B	177	560	2" / 1¼"	65	4,5 5,4	11,4 11,1	400 V / 50 Hz 460 V / 60 Hz
504312V051	CVS500 - 2 x SV100B	195	550	2" / 1¼"	64	4,4 7,0	9,0 10,6	400 V / 50 Hz 460 V / 60 Hz
504312V052	CVS500 - 3 x SV100B	292,5	680	2" / 1¼"	66	6,6 10,5	13,5 15,9	400 V / 50 Hz 460 V / 60 Hz
504312V053	CVS500 - 2 x SV200	360	630	2" / 2"	72	8,0 9,2	17,8 20,0	400 V / 50 Hz 460 V / 60 Hz
504312V054	CVS500 - 2 x SV300B	560	725	2" / 2"	75	11,0 12,6	21,0 18,6	400 V / 50 Hz 460 V / 60 Hz
504313V050	CVS1000 – 3 x SV65B	177	700	2" / 1¼"	65	4,5 5,4	11,4 11,1	400 V / 50 Hz 460 V / 60 Hz
504313V051	CVS1000 - 2 x SV300B	195	690	2" / 1¼"	64	4,4 7,0	9,0 10,6	400 V / 50 Hz 460 V / 60 Hz
504313V052	CVS1000 - 3 x SV100B	292,5	820	2" / 1¼"	66	6,6 10,5	13,5 15,9	400 V / 50 Hz 460 V / 60 Hz
504313V053	CVS1000 - 2 x SV200	360	775	2" / 2"	72	8,0 9,2	17,8 120,0	400 V / 50 Hz 460 V / 60 Hz
504313V054	CVS1000 – 3 x SV200	540	950	2" / 2"	74	12,0 13,8	26,7 230,0	400 V / 50 Hz 460 V / 60 Hz
504313V055	CVS1000 - 2 x SV300B	560	860	2" / 2"	75	11,0 12,6	21,0 18,6	400 V / 50 Hz 460 V / 60 Hz
504313V056	CVS1000 - 3 x SV300B	840	1080	2" / 2"	77	16,5 18,9	31,5 27,9	400 V / 50 Hz 460 V / 60 Hz

\* 50 Hz

\*\* At ultimate pressure witout gas ballast, free-field measurement, distance 1 m

Beyond the equipment which is supplied as standard, the modular design of the central vacuum supply systems from Leybold allows for customization according to your specific requirements.

Optionally available are, for example:

- Higher pumping speeds and larger buffer volumes
- Electropneumatic or solenoid blocking valves
- Mobile construction on castors
- Other mains voltages
- Additional pumps, filters, fittings etc.

# Only available for purchase in North and South America

## **Central Vacuum Supply Systems**



Central vacuum supply system, simplex



Central vacuum supply system, duplex



Central vacuum system, triplex

#### **Standard Equipment**

- ASME<sup>®</sup> rated receiver tank
- Flexible configurations for one, two, or three SOGEVAC pumps
- Manual isolation valves
- Simple operation, high reliability, easy maintenance
- Complete package with gauges and NEMA12 controls
- Standard "ON/OFF/AUTO" switch
- Elapsed time meters
- Inlet particulate filters
- Lead/Lag or continuous operation of pumps
- Adjustable pressure switch for control of vacuum level
- Air-cooled SOGEVAC pumps with built-in "anti-suckback" valves

#### Options

- Tank or stack mounted pumps
- Larger receiver tank
- Special inlet filters
- Automatic isolation valves
- Special design controls per customer specification



Central vacuum supply systems, tank mounted [left] and stack mounted [right]; dimensions in inch, dimensions in brackets () are in mm

#### **Technical Data**

#### **Performance Characteristics**

		SV 16	SV 25	SV 40 B	SV 65 B	SV 100 B	SV 200	SV 300
Free air displacement	cfm (m <sup>3</sup> /h)	11 (18.6)	17.0 (29.0)	31.2 (53.0)	41.8 (71.0)	68.9 (117.0)	129.5 (219.8)	200.3 (340.0)
Actual pumping speed	cfm (m <sup>3</sup> /h)	10 (16.9)	15 (25.5)	27.7 (47.0)	37.7 (64.0)	61.8 (105.0)	117.8 (200.0)	170.8 (289.9)
Guaranteed base pressure	Torr	0.4	0.4	0.4	0.4	0.4	0.06	0.06
Base pressure with gas ballast	Torr	1.1	1.1	1.1	1.1	1.0	0.5	0.5
Water vapor tolerance	Torr	30.0	30.0	22.5	22.5	22.5	30.0	30.0
Water vapor pumping with gas ballast	qt/hr	0.32	0.48	0.95	1.32	1.8	5.7	7.8
Noise level at 3 feet with 1 pump running without gas ballast	dB(A)	56	56	63	64	64	73	74
Motor	hp	1.0	1.5	2.0	2.5	4.0	7.5	10.0
Pump rotational speed	rpm	1750	1500	1750	1750	1750	1750	1750
Oil capacity	qt	2.0	2.0	1.05	2.1	2.1	5.5	9.0
Inlet / exhaust - NPT	in.	1/2 / 1/2	1/2 / 1/2	1–1/4 / 1–1/4	1–1/4 / 1–1/4	1–1/4 / 1–1/4	2/2	2/2
Pump weight	lbs	50.7	52.9	99.3	114.8	194.3	341.8	430.0

Technical Data		Tank Mount	Tank Mount	Stack Mount
		Simplex	Duplex	<b>Duplex and Simplex</b>
SV 16, SV 25	Tank size (gal)	30	60	60
SV 40 B	Tank size (gal)	60	80	80
SV 65 B	Tank size (gal)	60	120	120
SV 100 B	Tank size (gal)	80	120	120
SV 200	Tank size (gal)	120	240	200
SV 300	Tank size (gal)	120	240	200

С

Part No.

#### **Ordering Information**





Pumping speed characteristics for the central vacuum supply systems at 60 Hz

<u>XX</u>

#### Notes

# Only available for purchase in North and South America

## Tank Mounted Medical Vacuum Systems

NFPA 99C compliant and designed for use in medical applications – hospitals, out-patient surgical and other medical facilities



Leybold tank mounted systems are completely assembled with interconnecting piping, are factory tested and leak-checked prior to shipment. Some items may be disassembled for protection during shipment. Required mechanical re-assembly requirements will be clearly noted, as well as needed electrical connections, and are the responsibility of the installer.

Tank mounted medical vacuum system

#### **System Features**

Key features for these duplex systems include two SOGEVAC series oil sealed rotary vane vacuum pumps with displacements up to 69 cfm each, an ultimate vacuum of better than 29.95" Hg, and automatic oil recirculation system with integral coalescing exhaust demisters as standard. ASME rated receiver tanks, NEMA12 / UL listed electrical enclosure and inter-connecting hardware. Each turn-key system is fully assembled and tested at Leybold Vacuum's factory and includes an operation manual and 12 month warranty.

#### **Other System Features**

#### Vacuum pumps and systems:

- Direct-coupled TEFC, IP 55 rated motors
- Integral gas ballast
- Anti suck back valve
- Air-cooled design
- NPT type inlet and exhaust connections
- Inlet protection
  - particulate filters rated for 10 micron retention
  - Isolation ball valves
- Pump check valves
- Vacuum gauge, 0 30" Hg
- Vertical receiver, ASME coded, manual drain valve and tank bypass

#### Local duplex motor control center:

- 2x magnetic motor starters with overload protection
- Main fused disconnect switch
- 2x through the door disconnect switches
- 2x individual control transformers
- 2x elapsed time meters
- 2x hand-off-auto switches
- Lag pump audible alarm with indicator light
- Automatic alternation
  Lead / Lag operation
- 2x dual set-point vacuum switches
- Emergency stop
- NEMA12, UL listed enclosure
- System wired for either 208/230/460 V, 3 phase, 60 Hz operation



Tank mounted medical vacuum systems; dimensions in inch, dimensions in brackets () are in mm

#### **Technical Data**

#### VTMD-25-M VTMD-40-M VTMD-65-M VTMD-100-M

Displacement (per pump)	cfm	18.3	31.2	41.8	69.0
Capacity 19" HG (VAC) (per pump)	scfm	6.7	11.4	15.3	25.1
Motor (per pump)	hp (W)	1.5 (2.0)	2.0 (2.7)	3.0 (4.1)	5.0 (6.8)
Vacuum tank	gal	80	80	120	120
Vacuum inlet	NPT		1.	5"	
Vacuum outlet 1)	NPT		1.2	25"	
Weight	lbs (kg)	700 (305)	750 (340)	1125 (510)	1300 (589)

#### **Ordering Information**

#### VTMD-25-M VTMD-40-M VTMD-65-M VTMD-100-M

Part No.	Part No.	Part No.	Part No.
S 170 530	S 170 533	S 170 499	S 170 490
S 170 531	S 170 534	S 170 536	S 170 538
S 170 532	S 170 535	S 170 537	S 170 539
	<b>Part No.</b> S 170 530 S 170 531 S 170 532	Part No.      Part No.        S 170 530      S 170 533        S 170 531      S 170 534        S 170 532      S 170 535	Part No.      Part No.      Part No.        S 170 530      S 170 533      S 170 499        S 170 531      S 170 534      S 170 536        S 170 532      S 170 535      S 170 537

<sup>1)</sup> System consists of two outlet flanges

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE Backing Pump, Adaptor Version, without palette



RUTA WAU2001/SP630/A

#### **Standard Equipment**

- RUVAC WAU with air cooling
- RUVAC WH with water cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- Gear oil collecting pan integrated within the screw pump
- Gear oil supplied with the pump
- Screw pump SCREWLINE SP 630 F with water cooling

- Screw pump SCREWLINE SP 250 with air cooling
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

#### Options

 Frequency converter for controlling the speed of the Roots pump (only RUVAC WA/WS)

- Condensate drain valve at the silencer
- Sound proofing box
- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve
- Screw pump SCREWLINE SP 630 with air cooling



Dimensional drawing of the pump systems with dry compressing SCREWLINE SP backing pump, adaptor version, without palette. Left with WAU pumps, right with WH pump. Dimensions in brackets () are in inch

#### Technical Data, 50 Hz

#### RUTA

		WAU 501/SP250/A	WAU 1001/SP250/A	WAU 2001/SP630(F)/A	WH 700/SP250/A
RUVAC (WA/WAU/WS/WSU possible)	P2	501	1001	2001	-
RUVAC WH	P2	-	-	-	700
Backing pump SCREWLINE	P1	SP 250	SP 250	SP 630 (F)	SP 250
Pumping speed, 50 Hz at $10^{-1}$ mbar (7.5 x $10^{-2}$ Torr)	m³/h (cfm)	445.0 (262.1)	830.0 (488.9)	1745.0 (1027.8)	635 (374)
Ultimate total pressure without gas ballast	mbar (Torr)		< 1 x 10 <sup>-3</sup> (<	< 7.5 x 10 <sup>-4</sup> )	
Installed motor power 400 V, 50 Hz	kW (hp)	9.7 (13.0)	11.5 (15.6)	22.5 (30.6)	9.7 (13.0)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	6.3 (8.6)	6.7 (9.1)	12.0 (16.3)	6.6 (8.9)
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	75	77	79	75
Total weight with palette, approx.	kg (lbs)	720 (1187)	850 (1876)	1100 (2428)	720 (1587)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	63 ISO-K 63 ISO-K	100 ISO-K 63 ISO-K	160 ISO-К 100 ISO-К	100 ISO-K 63 ISO-K

#### **Ordering Information**

#### RUTA

		WAU 501/SP250/A	WAU 1001/SP250/A	WAU 2001/SP630(F)/A	WH 700/SP250/A
		Part No.	Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible)	P2	WAU 501	WAU 1001	WAU 2001	_
RUVAC WH	P2	-	-	-	WH 700
Backing pump	P1	SP 250	SP 250	SP 630 (F)	SP 250
Pump system, complete (adaptor version), without pallet					
with water-cooled SCREWLINE		502 465 V001	502 467 V001	502 471 V001	503153V001 <sup>1)</sup>
Frequency converter RUVATRONIC		RT 5/501	RT 5/1001	RT 5/2001	_
(see description in Chapter "Accessories")		500 001 382	500 001 383	500 001 384	-

<sup>1)</sup> Including external frequency converter







Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE Backing Pump, Adaptor Version, with palette



RUTA WAU2001/SP630/A

#### **Standard Equipment**

- RUVAC WAU with air cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- Gear oil collecting pan integrated within the screw pump
- Gear oil supplied with the pump
- Screw pump SCREWLINE SP 630 F with water cooling

- Screw pump SCREWLINE SP 250 with air cooling
- CE approval

#### Options

- Condensate drain valve at the silencer
- Sound proofing box
- Vibration absorbers

- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve
- Screw pump SCREWLINE SP 630 with air cooling





Туре			with palette	
	RUTA	501/SP250/A	1001/SP250/A	2001/SP630F/A
RUVAC WA/WAU/WS/WSU	P2	501	1001	2001
Backing pump SCREWLINE	P1	SP 250	SP 250	SP 630 F
	DN <sub>1</sub>	63 ISO-K	100 ISO-K	160 ISO-K
	DN <sub>2</sub>	63 ISO-K	63 ISO-K	100 ISO-K
	1	1448 (57.01)	1488 (58.58)	1850 (72.84)
	l,	287 (11.30)	327 (12.87)	379 (14.92)
	I <sub>2</sub>	581 (22.87)	621 (24.45)	894 (35.20)
	b	923 (36.34)	923 (36.34)	1056 (41.58)
	b <sub>1</sub>	400 (15.75)	400 (15.75)	400 (15.75)
	b <sub>2</sub>	438 (17.24)	438 (17.24)	546 (21.50)
	b <sub>3</sub>	800 (31.50)	800 (31.50)	800 (31.50)
	h	1377 (54.21)	1403 (55.24)	1509 (59.41)
	h1	1121 (44.13)	1121 (44.13)	1388 (54.65)

Dimensional drawing of the pump systems with dry compressing SCREWLINE SP backing pump, adaptor version; left and middle with palette, right on castors Dimensions in brackets () are in inch

Technical Data, 50 Hz		RUTA WAU			
		501/SP250/A	1001/SP250/A	2001/SP630(F)/A	
RUVAC (WA/WAU/WS/WSU possible)	P2	501	1001	2001	
Backing pump SCREWLINE	P1	SP 250	SP 250	SP 630 (F)	
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	445.0 (262.1)	830.0 (488.9)	1745.0 (1027.8)	
Ultimate total pressure without gas ballast m	nbar (Torr)	< 1 x 10 <sup>-3</sup> (< 7.5 x 10 <sup>-4</sup> )			
Installed motor power 400 V, 50 Hz	kW (hp)	9.7 (13.2)	11.5 (15.6)	22.5 (30.6)	
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	6.3 (8.6)	6.7 (9.1)	12.0 (16.3)	
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	75	77	79	
Total weight with palette, approx.	kg (lbs)	720.0 (1589.4)	850.0 (1876.4)	1100.0 (2428.3)	
Connecting flange Inlet port Outlet port	DN <sub>1</sub>	63 ISO-K 63 ISO-K	100 ISO-K 63 ISO-K	160 ISO-K	

### **Ordering Information**

### **RUTA WAU**

	501/SP250/A	1001/SP250/A	2001/SP630(F)/A
	Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible)	WAU 501	WAU 1001	WAU 2001
Backing pump F	SP 250	SP 250	SP 630 (F)
Pump system, complete (adaptor version), pallet mounted, with water-cooled SCREWLINE with air-cooled SCREWLINE	_ 502 466 V001	- 502 468 V001	502 472 V002 502 472 V003
Frequency converter RUVATRONIC (see description in Chapter "Accessories")	RT 5/501 500 001 382	RT 5/1001 500 001 383	RT 5/2001 500 001 384



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE Backing Pump, Adaptor Version, with palette



RUTA WH4400/SP630/A

#### **Standard Equipment**

- RUVAC WH with water cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- Gear oil collecting pan integrated within the screw pump
- Gear oil supplied with the pump
- Screw pump SCREWLINE SP 630 F with water cooling
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

#### Options

- Condensate drain valve at the silencer

- Sound proofing box
- Vibration absorbers
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve
- Screw pump SCREWLINE SP 630 with air cooling



Dimensional drawing of the pump systems with dry compressing SCREWLINE SP backing pump, adaptor version; with palette. Dimensions in brackets () are in inch
### **RUTA WH**

### 4400/SP630F/A

RUVAC WH	P2	4400
Backing pump SCREWLINE	P1	SP 630 F
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar		
(7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	3380 (1990)
Ultimate total pressure		
without gas ballast	mbar (Torr)	< 1 x 10 <sup>-3</sup> (< 7.5 x 10 <sup>-4</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	26.0 (34.9)
Electrical power consumption		
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	12.93 (17.34)
Noise level with silencer		
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	73
Total weight		
with palette, approx.	kg (lbs)	1350 (2932)
on castors, approx.	kg (lbs)	1980 (4365)
Connecting flange		
Inlet port	DN <sub>1</sub>	250 ISO-K
Outlet port	$DN_2$	100 ISO-K

#### **Ordering Information**

## 4400/SP0SUP/A Part No. Part No. RUVAC (WA/WAU/WS/WSU possible) P2 4400 Backing pump P1 SP 630 F Pump system, complete (adaptor version), with water-cooled SCREWLINE pallet mounted 503 162 V001 ¹)

750 Torr

10<sup>2</sup>

10<sup>1</sup>

10<sup>0</sup>

10<sup>-1</sup>

18 min

WH 4400 + SP630

Pump-down time

Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz

<sup>1)</sup> Including external frequency converter

10<sup>3</sup>

10<sup>2</sup>

10<sup>1</sup>

10<sup>0</sup>

10<sup>-1</sup> 0 2 4 6 8 10 12 14 16

mbar

Pressure



#### 4400/SP630F/A

	10**	10-3	10**	10 '	100	10 '	TOR	750
1								
3	1							
m°∙h								c
						+		H _ 1000
<b>P</b>	03			NILL		N		
bed								500
0 D								
idi								+++
nn								1100
ш 1	10 <sup>2</sup>							<u> </u>
					ТН МН	4400 +	SP630	
								10
1	01							
	10 <sup>-4</sup> .	10 <sup>-3</sup>	10 <sup>-2</sup>	10 <sup>-1</sup>	10 <sup>0</sup>	10 <sup>1</sup>	$10^2$ mba	r 10 <sup>3</sup>
				Pre	essure		The	u

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE SP 250 Backing Pump, Frame Version



RUTA WAU2001/SP630/G

#### **Standard Equipment**

- RUVAC WH with water cooling
- RUVAC WAU with air cooling
- SCREWLINE SP 250 with air cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- SECUVAC valve 24 V DC
- Gear oil collecting pan integrated within the screw pump

- Crane eyes on the frame
- Floor mounting
- Gear oil supplied with the pump
- Screw pump with air cooling
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

#### Options

- Condensate drain valve at the silencer
- Sound proofing box
- Vibration absorbers
- Castors
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve







Туре	RUTA	501/SP250/G	1001/SP250/G	2001/SP250/G	700/SP250/G	2500/SP250/G
RUVAC WA/WAU/WS/WSU	P2	501	1001	2001	-	-
RUVAC WH	P2	-	-	-	700	2500
Backing pump SCREWLINE	P1	SP 250				
	DN <sub>1</sub>	63 ISO-K	100 ISO-K	160 ISO-K	100 ISO-K	250 ISO-K
	DN <sub>2</sub>	63 ISO-K				
	1	1650 (64.96)	1650 (64.96)	1650 (64.96)	1650 (64.96)	1650 (64.96)
	L,	565 (22.24)	565 (22.24)	565 (22.24)	564 (22.21)	664 (26.14)
	l,	678 (26.69)	678 (26.69)	678 (26.69)	678 (26.69)	678 (26.69)
	b	863 (33.98)	863 (33.98)	863 (33.98)	863 (33.98)	863 (33.98)
	b,	340 (13.39)	340 (13.39)	340 (13.39)	340 (13.39)	340 (13.39)
	b <sub>2</sub>	438 (17.24)	438 (17.24)	438 (17.24)	438 (17.24)	438 (17.24)
	b <sub>3</sub>	680 (26.77)	680 (26.77)	680 (26.77)	680 (26.77)	680 (26.77)
	ĥ	1670 (65.75)	1771 (69.72)	1947 (76.65)	1580 (62.21)	1739 (68.47)
	h,	1101 (43.35)	1101 (43.35)	1101 (43.35)	1101 (43.35)	1081 (42.56)
	h <sub>2</sub>	1330 (52.36)	1375 (54.13)	1417 (55.79)	1290 (5079)	1315 (51.77)

Dimensional drawing of the pump systems with dry compressing SCREWLINE SP 250 backing pump, frame version; dimensions in brackets () are in inch

Technical Data, 50 Hz			RUTA			
		WAU 501/ SP250/G	WAU 1001/ SP250/G	WAU 2001/ SP250/G	WH 700/ SP250/G	WH 2500/ SP250/G
RUVAC (WA/WAU/WS/WSU possible	) P2	501	1001	2001	-	-
RUVAC WH	P2	_	-	-	700	2500
Backing pump SCREWLINE	P1			SP 250	·	
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	445 (262)	830.0 (489)	1530 (901)	635 (374)	1680 (988)
Ultimate total pressure without gas ballast	mbar (Torr)	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 3 x 10 <sup>-3</sup> (< 2.2 x 10 <sup>-3</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	9.7 (13.2)	11.5 (15.6)	15.0 (20.4)	9.7 (13.2)	13.5 (18.1)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	6.3 (8.6)	6.7 (9.1)	7.6 (10.3)	6.6 (8.9)	7.3 (9.8)
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	74	77	80	75	70
Weight, total, approx.	kg (lbs)	860 (1896)	950 (2097)	1140 (2517)	860 (1896)	1000 (2205)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	63 ISO-K 63 ISO-K	100 ISO-К 63 ISO-К	160 ISO-К 63 ISO-К	100 ISO-К 63 ISO-К	250 ISO-K 63 ISO-K

#### **Ordering Information**

	WAU 501/ SP250/G	WAU 1001/ SP250/G	WAU 2001/ SP250/G	WH 700/ SP250/G	WH 2500/ SP250/G
	Part No.	Part No.	Part No.	Part No.	Part No.
RUVAC (WA/WAU/WS/WSU possible)	WAU 501	WAU 1001	WAU 2001	-	-
RUVAC WH P2	_	-	-	700	2500
Backing pump SCREWLINE P1			SP 250		
Pump system, complete (adaptor version), frame mounted, with Roots vacuum pump					
RUVAC WAU	502 531 V001	502 532 V001	502 533 V001	-	-
RUVAC WH	-	-	-	503 154 V001 <sup>1)</sup>	503 158 V001 <sup>1) 2)</sup>
Frequency converter RUVATRONIC	RT 5/501	RT 5/1001	RT 5/2001	-	-
(see description in Chapter "Accessories")	500 001 382	500 001 383 <sup>2</sup>	500 001 384 <sup>2)</sup>	-	-

<sup>1)</sup> Including external frequency converter

 $^{\scriptscriptstyle 2)}\,$  With this combination, continuous operation of the Roots pump is not possible at atmospheric pressure



Pump-down time diagram for a 10 m³ tank at 50 Hz



**RUTA** 

Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE SP 630 F Backing Pump, Frame Version



RUTA WAU2001/SP630F/G

#### **Standard Equipment**

- RUVAC WH with water cooling
- RUVAC WAU with air cooling
- SCREWLINE SP 630 F with water cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- SECUVAC valve 24 V DC
- Gear oil collecting pan integrated within the screw pump
- Crane eyes on the frame

- Floor mounting
- Gear oil supplied with the pump
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- CE approval

#### Options

 Frequency converter for controlling the speed of the Roots pump (only RUVAC RA/WA/WS)

- Condensate drain valve at the silencer
- Sound proofing box
- Vibration absorbers
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve
- Screw pump with air cooling

leybold



Dimensional drawing of the pump systems RUTA with dry compressing SCREWLINE SP 630 F backing pump, frame version; dimensions in brackets () are in inch

#### **RUTA**

#### WAU 2001/SP630F/G WH 2500/SP630F/G WH 4400/SP630F/G WH 7000/SP630F/G

RUVAC (WA/WAU/WS/WSU possible	e) P2	2001	-	-	-
RUVAC WH	P2	-	2500	4400	7000
Backing pump SCREWLINE	P1		SP 6	30 F	
Pumping speed, 50 Hz at $10^{-1}$ mbar (7.5 x $10^{-2}$ Torr)	m³/h (cfm)	1745 (1028)	1956 (1151)	3380 (1990)	5093 (2998)
Ultimate total pressure without gas ballast	mbar (Torr)	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 5 x 10 <sup>-3</sup> (< 3.7 x 10 <sup>-3</sup> )	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )	< 1 x 10 <sup>-3</sup> (< 0.75 x 10 <sup>-3</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	22.5 (30.0)	21.5 (28.8)	26.0 (34.9)	26.0 (34.9)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	12.0 (16.3)	11.7 (16.7)	12.93 (17.34)	13.11 (17.58)
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	79	73	73	73
Weight, total, approx.	kg (lbs)	1300 (2866)	1300 (2866)	1550 (3417)	1600 (3527)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	160 ISO-K 100 ISO-K	250 ISO-K 63 ISO-K	250 ISO-K 100 ISO-K	320 ISO-K 100 ISO-K

#### **Ordering Information**

#### **RUTA**

#### WAU 2001/SP630F/G WH 2500/SP630F/G WH 4400/SP630F/G WH 7000/SP630F/G Part No. Part No. Part No. Part No. WAU 2001 RUVAC (WA/WAU/WS/WSU possible) \_ \_ \_ RUVAC WH 2500 4400 7000 P2 \_ SP 630 F P1 Backing pump SCREWLINE Pump system, complete (adaptor version), frame mounted, with Roots vacuum pump RUVAC WAU 502 511 V001 with Roots vacuum pump RUVAC WH 503 159 V001 <sup>1), 2)</sup> 503 163 V001 <sup>1), 2)</sup> 503 168 V001 <sup>1), 2)</sup> Frequency converter RUVATRONIC RT 5/2001 500 001 384 (see description in Chapter "Accessories") \_ \_

<sup>1)</sup> Including external frequency converter

<sup>2)</sup> With this combination, continuous operation of the Roots pump is not possible at atmospheric pressure





Pump-down time diagram for a 10 m³ tank at 50 Hz

Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with SCREWLINE SP 630 F Backing Pump, Adaptor Version



RUTA WH2500/SP630F/A

#### **Standard Equipment**

- RUVAC WH with water cooling
- SCREWLINE SP 630 F with water cooling
- Silencer
- SP-GUARD
- Manually operated gas ballast
- SECUVAC valve 24 V DC
- Gear oil collecting pan integrated within the screw pump
- Crane eyes on the frame

- Floor mounting
- Gear oil supplied with the pump
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)

#### Options

- Condensate drain valve at the silencer

- Sound proofing box
- Vibration absorbers
- Different types of floor mounts
- Oil drain valve on each pump
- Electric control systems
- Non-return valve
- Screw pump with air cooling



Dimensional drawing of the pump system with dry compressing SCREWLINE SP 630 F backing pump, adaptor version; dimensions in brackets () are in inch



### RUTA WH

#### 2500/SP630F/A RUVAC WH P2 2500 Backing pump SCREWLINE P1 SP 630 F Pumping speed, 50 Hz at 10<sup>-1</sup> mbar (7.5 x 10<sup>-2</sup> Torr) m<sup>3</sup>/h (cfm) 1956 (1151) Ultimate total pressure without gas ballast mbar (Torr) < 5 x 10<sup>-3</sup> (< 3.7 x 10<sup>-3</sup>) Installed motor power 400 V, 50 Hz kW (hp) 21.5 (28.8) Electrical power consumption at 10<sup>-1</sup> mbar (7.5 x 10<sup>-2</sup> Torr) kW (hp) 11.7 (16.7) Noise level with silencer at 10<sup>-1</sup> mbar (7.5 x 10<sup>-2</sup> Torr) dB(A) 73 1200 (2645) Weight, total, approx. kg (lbs) Connecting flange 250 ISO-K Inlet port DN, DN, 100 ISO-K Outlet port

#### **Ordering Information**

## RUVAC WHP22500Backing pump SCREWLINEP1SP 630 FPump system, complete (adaptor version),<br/>pallet mounted,<br/>with Roots vacuum pump RUVAC WH503 160 V001 1)

<sup>1)</sup> Including external frequency converter



Pump-down time diagram for a 10  $\ensuremath{m^{\scriptscriptstyle 3}}$  tank at 50 Hz

#### RUTA WH

#### 2500/SP630F/A



Pumping speed diagram at 50 Hz

## Pump Systems (Only available for purchase in North and South America)

## SP Close-Coupled Systems with SP Dry Compressing Backing Pumps



SP close-coupled system

#### Advantages to the User

- Reduced maintenance and lower operating costs
- Compact close-coupled design without frame
- Oil-free compression in multiple pump stages
- Optimum leak tightness with WSU boosters
- Air-cooled
- Assembled and tested

#### **Standard Equipment**

- SCREWLINE SP 630 / WSU 1001
   close-coupled pump system offering
   645 ACFM at 0.3 Torr vacuum
- SCREWLINE SP 630 / WSU2001 close-coupled pump system offering 1235 ACFM at 0.3 Torr vacuum

#### Options

- Electrical controls
- Exhaust silencer (loose)
- Inlet filter (loose)

The screw pump SCREWLINE SP 630 dry compressing screw-type vacuum pump is an environmentally friendly alternative to traditional oil sealed rotary piston and vane vacuum pumps. This innovative and robust vacuum pump produces a pumping speed of 371 cfm and better than 0.0075 Torr vacuum. SP 630 major advantages include improved environment, reduced maintenance, lower operating costs through less disposal and the elimination of expensive water cooling all with no oil contamination as the need for lubricating oil in the pumps' compression stage has been eliminated.

When used in conjunction with the Leybold WSU

booster pumps, pumping speeds can be significantly increased while achieving oil-free compression in multiple vacuum pump stages.

#### Leybold WSU

boosters offer a canned motor design, which eliminates the need for shaft seals and flanged-on motors. A vacuum tight can separates the motor rotor and stator coils. This unique Leybold design provides the advantage of a more leak tight vacuum system. The WSU version booster incorporates a by-pass valve feature, which allows

for automatic adjustment to varying pressure differentials between the inlet and outlet of the pump. The result is elimination of costly pressure switches/ amplifiers and faster pump down while starting at atmospheric pressure with the aforementioned SP 630 vacuum pump.



Dimensional drawing for the SP close-coupled system with SCREWLINE SP 630 dry compressing backing pumps; dimensions in brackets () are in mm









#### SP Close-Coupled Systems

		1001/SP630	2001/SP630	
RUVAC (WSU possible)	P2	1001	2001	
Backing pump SCREWLINE	P1	SP (	630 F	
Pumping speed 60 Hz at 0.3 Torr	m³/h (cfm)	1.092 (643)	2.085 (1,227)	
Ultimate total pressure without gas ballast	mbar (Torr)	< 1 x 10 <sup>-3</sup> (< 7.5 x 10 <sup>-4</sup> )		
Installed motor power	kW (hp)	16.2 (21.6)	22.5 (30.0)	
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	78	79	
Weight, total, approx.	kg (lbs)	870 (1922)	1100 (2430)	
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	160 100	ISO-K ISO-K	

#### **Ordering Information**

#### SP Close-Coupled Systems

		1001/SP630	2001/SP630			
		Part No.				
RUVAC (WSU possible)	P2	1001	2001			
Backing pump SCREWLINE	P1	SP 630 F				
Pump system, complete (adaptor version), pallet mounted, with Roots vacuum pump RUVAC WAU		180 038 V1600	180 038 V2600			

#### Notes

## Dry Compressing Vacuum Pump System RUTA with DRYVAC DV 200 / DV 300 Backing Pump, Adaptor Version



RUTA WSU1001/DV300/A

#### **Standard Equipment**

- RUVAC WSU or RUVAC WH and DRYVAC
- DRYVAC DV 200 or DV 300 with built-in frequency converter and indirect water cooling
- Hermetically sealed
- Integrated vacuum-side valve 24C DC for supplying purge gas to the shaft seal of the DV 200 / DV 300
- 24V DC controlled gas ballast
- Integrated bypass valve for fast pump down
- Integrated temperature sensors
- All DRYVAC models are compatible with numerous field bus protocols
- The integrated frequency converter together with three sensors monitors all electrical, thermal and mechanical components. The sensors determine the exhaust gas pressure, the

engine temperature and the water outlet temperature and trigger an alarm if necessary

- All DRYVAC models offer serial I/O connections including an RS485 interface
- Profibus, Ethernet/IP, ProfiNet and EtherCAT are optionally available
- RUVAC with integrated bypass valve for fast pump down
- The pump system provides a very low noise level

leybold



		WSU501/ DV200/A	WH700/ DV200/A	WH700FC/ DV200/A	WSU1001/ DV200/A	WSU2001/ DV200/A	WSU501/ DV300/A	WH700/ DV300/A	WH700FC/ DV300/A	WSU1001/ DV300/A	WSU2001/ DV300/A	WH2500FC/ DV300/A
RUVAC	P1	501	700	700 FC	1001	2001	501	700	700 FC	1001	2001	2500
DRYVAC	P2	200	200	200	200	200	300	300	300	300	300	300
Inlet	DN 1	63 ISO-K	100 ISO-K	100 ISO-K	100 ISO-K	160 ISO-K	63 ISO-K	100 ISO-K	100 ISO-K	100 ISO-K	160 ISO-K	250 ISO-K
Outlet	DN 2	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF	40 KF
	1	1330	1330	1330	1330	1330	1330	1330	1330	1330	1330	1330
	I,	910	910	910	910	910	910	910	910	910	910	910
	b	806	806	806	806	806	806	806	806	806	806	806
	b,	726	726	726	726	726	726	726	726	726	726	726
	h	1031	956	956	1056	1233	1031	956	956	1056	1233	956

Dimensioned drawing of the pump system with dry compressing backing pump DRYVAC DV 200 (left) and DV 300 (right), adapter version (all dimensions in mm)

Technical Data				RUTA		
		WSU501/ DV200/A	WH700/ DV200/A	WH700FC/ DV200/A	WSU1001 DV200/A	WSU2001 DV200/A
Ordering Information	Part No	. 505058V001	505059V001	505059V002	505060V001	505061V001
RUVAC	Р	2 WSU501	WH700	WH700FC	WSU1001	WSU2001
Backing pump DRYVAC I	DV P	1 DV200	DV200	DV200	DV200	DV200
Pumping speed, 50 Hz	h 505	710	710	1000	2050	
Ultimate total pressure w	/o gas ballast mba	ır		< 5 · 10 <sup>-3</sup>		
Installed motor power	400 V, 50 Hz kV 460 V, 60 Hz kV	V 9.7 V 9.9	9.7 9.9	11 11	11.5 11.9	15 16
Noise level with silencer at 10 <sup>-1</sup> mbar	dB(A	) < 66	< 66	< 66	< 66	< 69
Weight, total, approx.	k	g 600	610	650	650	1000
Connecting flange	Inlet port Di Outlet port Di	N         63 ISO-K           N         40 ISO-K	100 ISO-К 40 ISO-К	100 ISO-K 40 ISO-K	100 ISO-K 40 ISO-K	160 ISO-К 40 ISO-К

Те	chi	nica	al C	)ata

			WSU501/ DV300/A	WH700/ DV300/A	WH700FC/ DV300/A
Ordering Information	Р	art No.	505062V001	505063V001	505063V002
RUVAC		P2	WSU501	WH700	WH700FC
Backing pump DRYVAC	DV	P1	DV300	DV300	DV300
Pumping speed, 50 Hz		m³/h	505	710	710
Ultimate total pressure v	v/o gas ballast	mbar		< 5 · 10 <sup>-3</sup>	
Installed motor power	400 V, 50 Hz 460 V, 60 Hz	kW kW	9.7 9.9	9.7 9.9	11 11
Noise level with silencer at 10 <sup>-1</sup> mbar		dB(A)	< 66	< 66	< 66
Weight, total, approx.		kg	600	610	650
Connecting flange	Inlet port Outlet port	DN DN	63 ISO-K 40 ISO-K	100 ISO-K 40 ISO-K	100 ISO-К 40 ISO-К

**RUTA** 

**RUTA** 

#### **Technical Data**

leybold

			WSU1001 DV300/A	WSU2001 DV300/A	WH2500FC DV300/A
Ordering Information	Part N	lo.	505064V001	505065V001	505066V001
RUVAC		P2	WSU1001	WSU2001	WH2500FC
Backing pump DRYVAC	DV	P1	DV200	DV200	DV200
Pumping speed, 50 Hz	m	³/h	1000	2050	2500
Ultimate total pressure w	/o gas ballast ml	oar		< 5 · 10 <sup>-3</sup>	
Installed motor power	400 V, 50 Hz 460 V, 60 Hz	<w <w< th=""><th>11.5 11.9</th><th>15 16</th><th>18.5 18.5</th></w<></w 	11.5 11.9	15 16	18.5 18.5
Noise level with silencer at 10 <sup>-1</sup> mbar	dB	(A)	< 66	< 69	< 67
Weight, total, approx.		kg	650	1000	910
Connecting flange	Inlet port Outlet port	DN DN	100 ISO-K 40 ISO-K	160 ISO-K 40 ISO-K	250 ISO-K 40 ISO-K

Vacuum Pump Systems

## Dry Compressing Vacuum Pump System RUTA with DRYVAC DV 650 Backing Pump, Adaptor Version



RUTA WH4400/DV650/A

#### **Standard Equipment**

- RUVAC WH and DRYVAC with water cooling
- DRYVAC DV with built-in frequency converter
- DRVAC DV-r including external frequency converter
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- Hermetically sealed
- Integrated protection functions (discharge pressure, temperatures and current consumption)

- Innovative motor design with efficiency class IE2
- Gas ballast with manual valve
- Leak detection port
- Lubricant: synthetic oil (LVO 210)

#### Options

- Exhaust silencer
- Bus interface
- Non-return valve for DRYVAC

- Seal gas connection
- Gear chamber evacuation RUVAC WH
- Frequency converter for RUVAC pump
- Electrical controller
- Oil drain tap
- Cooling water monitoring
- Quick couplings for water connections, blocking on both sides
- Frame



Dimensional drawing of the pump system with dry compressing DRYVAC DV 650 (left) and DV 650-r (right) backing pump, adaptor version; dimensions in brackets () are in inch

#### **RUTA WH**

**RUTA WH** 

		4400/DV650/A	4400/DV650-r/A
RUVAC WH	P2	4400	0
Backing pump DRYVAC DV	P1	650	650-r
Pumping speed, 50 Hz		· · · · · · · · · · · · · · · · · · ·	
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	3400 (2	000)
Ultimate total pressure			
without gas ballast	mbar (Torr)	< 5.0 x 10 <sup>-4</sup> (	3.8 x 10 <sup>-4</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	26.0 (3	4.9)
Electrical power consumption			
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	9.3 (12	2.5)
Noise level with silencer			
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	< 68	3
Weight, total, approx.	kg (lbs)	1550 (3	417)
Connecting flange			
Inlet port	DN <sub>1</sub>	250 IS	Э-К
Outlet port	DN <sub>2</sub>	100 IS(	Э-К

#### **Ordering Information**

## 4400/DV650/A 4400/DV650-r/A Part No. Part No. RUVAC WH P2 4400/DV650/A Backing pump DRYVAC DV 650 650-r Pump system, complete (adaptor version), pallet mounted, with Roots vacuum pump RUVAC WH 503 166 V001 1) 503 167 V001 1)

<sup>1)</sup> Including external frequency converter



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with DRYVAC DV 650 Backing Pump, Frame Version



RUTA WH7000/DV650/G

#### **Standard Equipment**

- RUVAC WH and DRYVAC with water cooling
- DRYVAC DV with built-in frequency converter
- DRYVAC DV-r including external frequency converter
- RUVAC WH including external frequency converter (frequency converter permits pumping speed control)
- Hermetically sealed
- Integrated protection functions (discharge pressure, temperatures and current consumption)

- Innovative motor design with efficiency class IE2
- Gas ballast with manual valve
- Leak detection port
- Lubricant: synthetic oil (LVO 210)
- SECUVAC valve 24 V DC

#### Options

- Exhaust silencer
- Bus interface
- Non-return valve for DRYVAC
- Seal gas connection

- Gear chamber evacuation RUVAC WH
- Electrical controller
- Oil drain tap
- Cooling water monitoring
- Quick couplings for water connections, blocking on both sides



Dimensional drawing of the pump system with dry compressing DRYVAC DV 650 (left) and DV 650-r (right) backing pump, frame version; dimensions in brackets () are in inch; (shown with optional silencer)

leybold

#### RUTA WH

**RUTA WH** 

		7000/DV650/A	7000/DV650-r/A		
RUVAC WH	P2	70	00		
Backing pump DRYVAC DV	P1	650	650-r		
Pumping speed, 50 Hz					
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	5100	(3001)		
Ultimate total pressure					
without gas ballast	mbar (Torr)	< 5.0 x 10 <sup>-4</sup>	- (3.8 x 10 <sup>-4</sup> )		
Installed motor power 400 V, 50 Hz	kW (hp)	26.0 (34.9)			
Electrical power consumption					
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	9.36 (	12.56)		
Noise level with silencer					
at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	< (	68		
Weight, total, approx.	kg (lbs)	1600	(3527)		
Connecting flange					
Inlet port	DN,	320	SO-K		
Outlet port	DN <sub>2</sub>	100 1	SO-K		

#### **Ordering Information**

#### 7000/DV650/A 7000/DV650-r/A Part No. Part No. RUVAC WH 7000 P2 650 650-r Backing pump DRYVAC DV P1 Pump system, complete (frame version), frame mounted, 503 170 V001 <sup>1)</sup> 503 171 V001 <sup>1)</sup> with Roots vacuum pump RUVAC WH

<sup>1)</sup> Including external frequency converter



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

## Dry Compressing Vacuum Pump System RUTA with DRYVAC DV 1200 Backing Pump, Frame Version



RUTA WH7000/DV1200/G

#### **Standard Equipment**

- RUVAC WH and DRYVAC with water cooling
- DRVAC DV 1200 with built-in frequency converter
- RUVAC WH with water cooling and external frequency converter
- Hermetically sealed
- Integrated protection functions (discharge pressure, temperatures and current consumption)
- Innovative motor design with efficiency class IE2

- Gas ballast with electropneumatic valve 24 V DC
- Integrated valve 24 V DC for seal gas supply
- Leak detection port
- Control via Profibus (DRYVAC)
- Lubricant: synthetic oil (LVO 210)

#### Options

- Exhaust silencer
- Bus interface
- Non-return valve for DRYVAC
- Seal gas connection
- Gear chamber evacuation
- Electrical controller
- Oil drain tap
- Cooling water monitoring
- Quick couplings for water connections, blocking on both sides





Туре	RUTA	WH7000/DV1200/G
RUVAC WH	P2	7000
Backing pump DRYVAC DV	P1	1200
	DN <sub>1</sub>	320 ISO-K
	DN <sub>2</sub>	100 ISO-K
		1700 (66.93)
	I,	752 (29.61)
	I,	81 (3.19)
	b	870 (34.25)
	b,	870 (34.25)
	b <sub>2</sub>	122 (4.80)
	b <sub>3</sub>	489 (19.25)
	h	2043 (80.43)
	h,	1638 (64.49)
	h	546 (21.50)

Dimensional drawing of the pump system with dry compressing DRYVAC DV 1200, frame version; dimensions in brackets () are in inch



### **RUTA WH**

#### 7000/DV1200/G

**RUTA WH** 

RUVAC WH	P2	7000
Backing pump DRYVAC DV	P1	1200
Pumping speed, 50 Hz at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	m³/h (cfm)	5537 (3259)
Ultimate total pressure without gas ballast	mbar (Torr)	< 6.0 x 10 <sup>-4</sup> (4.5 x 10 <sup>-4</sup> )
Installed motor power 400 V, 50 Hz	kW (hp)	41.0 (55)
Electrical power consumption at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	kW (hp)	16.2 (21.7)
Noise level with silencer at 10 <sup>-1</sup> mbar (7.5 x 10 <sup>-2</sup> Torr)	dB(A)	< 68
Weight, total, approx.	kg (lbs)	2450 (5410)
Connecting flange Inlet port Outlet port	DN <sub>1</sub> DN <sub>2</sub>	320 ISO-K 100 ISO-K

#### **Ordering Information**

# T000/DV1200/G PIUVAC WH P2 Part No. Backing pump DRYVAC DV P1 1200 Pump system, complete (frame version), frame mounted, with Roots vacuum pump RUVAC WH 503 172 V001 1)

<sup>1)</sup> Including external frequency converter



Pump-down time diagram for a 10  $m^{\scriptscriptstyle 3}$  tank at 50 Hz



Pumping speed diagram at 50 Hz

## Dry Compressing Pump Systems DRYVAC



DRYVAC SYSTEM: Basic System Configuration (left), Smart System Configuration (middle), PowerBoost (right)

Leybold has refined its DRYVAC vacuum pump systems, making them adaptable for a variety of applications — The recipe is simple and efficient: Take a dry compressing screw vacuum pump and a roots pump, combine both of the proven technologies along with pressure measurement, shut-off devices and electrical control, creating a turn-key smart vacuum system that is cost-effective and completely ready for use by the customer.

For more than five years, the fore vacuum systems of the DRYVAC pump series by Leybold are already being used successfully in various processes, which can be simple or very challenging. The pumping systems are known for their maximum suction capacity while operating at minimum operating costs.

Now, Leybold has developed the systems further: The new two-stage DRYVAC systems distinguish themselves particularly by their modular design and the resulting improved user friendliness

and easy servicing. All equipment features are aligned to the requirements of the different markets.

#### Advantage to the User

- Extremely compact design provides more space in production areas
- Very low noise level improves working environment conditions
- Significant cost reduction because of high energy efficiency
- Clean technology with no oil emissions
- Optimized for fast cycle / load lock applications
- Fastest pump down times by high throughput pump mechanisms
- Highest pumping speed for dry and booster pumps
- Pumping speed from 2,000 m<sup>3</sup>/h up to 9,800 m<sup>3</sup>/h

- Integrated smart monitoring of major parameters
- Standard Digital I/O interface and Profibus (optional) for the whole product family
- Platform based product design proven in a huge installed base
- Tolerance to misuse
- Optimized design and screw profile
- Lowest power consumption
- Low cost of ownership
- minimized foot print

#### **Typical Applications**

- Glas Coating
- Crystal Pulling
- Sputtering / Decorative Layers
- Furnaces
- Protective Coating
- Battery
- Solar
- Display

#### **Basic System Configuration**

Pre-assembled vacuum pump systems (basic version). Monitoring, control, programming, and power electronic components to be provided by the customer.

#### Standard Configuration:

- exhaust to the side
- triple purge gas module

#### **Optional Configurations:**

Double purge gas module, gas ballast system, non-return valve, quick-access couplings (water), mating connector for power & signal supply, relay board (digital I/O)

#### **Advantages**

- high performance with excellent cost-performance ratio
- worldwide service & spare parts availability
- rapid response times

#### **Smart System Configuration**

The smart pump system versions are characterized by integrated power electronics, monitoring devices for the purge gas system and key parameters, easy and user-friendly operation handling (local / remote), and additional features, e.g. connecting a gauge head.

#### Standard Configuration:

- digital I/O interface
- prepared for connecting a variety of different gauge heads (CTR, DU, TTR)
- Emergency Stop (EMS)
- compensation for voltage drops (≤ 2s)
- triple purge gas module
- exhaust to the side

#### **Optional Configurations:**

Double purge gas module, gas ballast system, non-return valve, quick-action couplings, Profibus, Ethernet or Profinet interfaces.

#### **Advantages**

- high performance at attractive prices
- autonomous vacuum pump system
- worldwide service & spare parts availability
- rapid response times



Pumping speed characteristics DV 450 (without bypass line)



Pumping speed characteristics DV 450 (with bypass line)



Pumping speed characteristics DV 650 (without bypass line)



Pumping speed characteristics DV 650 (with bypass line)



Pumping speed characteristics DV 650 (without bypass line)



Pumping speed characteristics DV 650 (with bypass line)

## Dry Compressing Pump Systems DRYVAC Basic System Configuration



The two-stage DRYVAC SYSTEMS consist of a combination of dry compressing Roots pumps and screw pumps. The Roots pump installed on top of the backing pump serves as a booster for increasing the pumping speed.

Various types of pumps may be used with DRYVAC SYSTEMS:

#### **Roots Pumps**

RUVAC WA RUVAC WAU RUVAC WH RUVAC WHU RUVAC WS RUVAC WSU

#### **Backing Pumps**

DRYVAC DV S DRYVAC DV C All DRYVAC SYSTEMS (b versions) described hereinafter are delivered as basic versions. The basic version can be customized according to individual requrirements with accessories (e.g. Harting plug or gas ballast system).

The pumps are water-cooled and lubricated either with synthetic oil or PFPE.

leybold



Dimensional drawing for DS 20A(U) 45(S/C) b, DS 20A(U) 65(S/C) b, DS 20S(U) 45(S/C) b, DS 20S(U) 65(S/C) b (Dimensions in mm)



Dimensional drawing for DS 25H(U) 45(S/C) b, DS25H(U) 65(S/C) b, DS 25HF 45(S/C) b, DS 25HF 65(S/C) b (Dimensions in mm)



Dimensional drawing for DS 44H(U) 45(S/C) b, DS 44H(U) 65(S/C) b, DS 44HF 65(S/C) b (Dimensions in mm)



Dimensional drawing for DS 70H(U) 65(S/C) b, DS 70HF 65(S/C) b (Dimensions in mm)

Technical Data	DRYVAC SYSTEMS DS					
	20A(U) 45(S/C) b(T)	20S(U) 45(S/C) b(T)	20A(U) 65(S/C) b(T)	20S(U) 65(S/C) b(T)		
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)		2000 / 24	400 m³/h			
Max. effective pumping speed (50/60 Hz) (± 5 %)	1600 / 18	350 m³/h	1750 / 2	050 m³/h		
Ult. total pressure w/o rotor and inlet purge (± 10 %)		≤ 5 x 10	) <sup>-3</sup> mbar			
Maximum permissible inlet pressure		1013	mbar			
Maximum permissible discharge pressure (relative to ambient)		+200	mbar			
Integral leak rate	<5 x 10 <sup>-4</sup> mbar x l/s	<1 x 10 <sup>-4</sup> mbar x l/s	<5 x 10 <sup>-4</sup> mbar x l/s	s <1 x 10 <sup>-4</sup> mbar x l/s		
Water vapor tolerance with purge gas (SV40)	60 mbar ≥ 20 NI/min					
Water vapor capacity	15 k	:g/h	25	kg/h		
Permissible ambient temperature		+5 +	- 35 °C			
Storage temperature		-10 +	- 60 °C			
Noise level (rigid exhaust pipe) 6) Screw		65 dB(A) (l	K <sub>p4</sub> = 3dB)			
Roots	< 80 dB(A)	< 72 dB(A)	< 80 dB(A)	< 72 dB(A)		
Relative atmospheric humidity	95%, non-condensing					
Installation location	up to 2000 m (NHN) 2)					
Cooling	Water / air					
Mains voltages and frequencies	380 – 440V 50Hz / 420 – 480V 60Hz					
Frequency (± 5 %)		50 / 6	60 Hz			
Phases		3-1	oh			
Rated power (400 V 50 Hz / 460 V 60 Hz) (± 0,8 kW) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	11 kW 7.5 kW 18.5 kW	11 kW 7.5 / 8.5 kW 18.5 / 19.5 kW	15 kW 7.5 kW 22.5 kW	15 kW 7.5 / 8.5 kW 22.5 / 23.5 kW		
Rated current (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	24 / 21 A 13.6 / 12 A 37.6 / 33 A	24 / 21 A 15 A 39 / 36 A	31 / 27 A 13.6 / 12 A 44.6 / 39 A	31 / 27 A 15 A 46 / 42 A		
Power consumption at ultimate pressure (50/60 Hz)						
Motor efficiency class, calculated and configured acc. to EN 60034-30		IE	2			
Electrical power rating (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	17 / 14.9 kVA 9.8 / 8.7 kVA 26.8 / 23.6 kVA	17 / 14.9 kVA 10.7 kVA 27.7 / 25.6 kVA	21.8 / 19.1 kVA 9.8 / 8.7 kVA 31.6 / 27.8 kVA	21.8 / 19.1 kVA 10.7 kVA 32.5 / 29.8 kVA		
Speed Screw / Roots (50 Hz) Screw / Roots (60 Hz)		7200 / 3 7200 / 3	3000 rpm 3600 rpm			
Min. permissible speed Screw <sup>3)</sup> Min. permissible speed Roots (off) <sup>4)</sup>		1200 o	rpm ff			
Protection class	IP54	IP20	IP54	IP20		

Technical Data	DRYVAC SYSTEMS DS				
	20A(U) 45(S/C) b(T)	20S(U) 45(S/C) b(T)	20A(U) 65(S/C) b(T)	20S(U) 65(S/C) b(T)	
Lubricant filling					
Screw	LVO 210 / 410	LVO 210 / 410	LVO 210 / 410	LVO 210 / 410	
Roots	LVO 210	LVO 210 / 400	LVO 210	LVO 210 / 400	
Total lubricant quantity (± 5 %)					
Screw LVO 210	1.2	1.2	1.2	1.2	
Screw LVO 410	1.2	1.2	1.2	1.2	
Roots LVO 210	3.6	3.6	3.6	3.61	
Roots LVO 400		2.7		2.7	
Roots LVO 410					
Intake flange		DN 160	) ISO-K		
Discharge flange		DN 63	ISO-K		
Materials (components in contact with gas in the pump chamber)	Grey cast iron /	graphite cast iron / ste	eel/stainless steel /ep	oxy paint / FKM	
Materials sealing the pump off in the pump chamber towards the outside		FKM, grey	v cast iron		
Weight, approx. (± 40 kg)	1156 kg	1215 kg	1156 kg	1215 kg	
Dimensions (L x W x H) Conn. flange, w/o acc., side exhaust Conn. flange, w/o acc., rear exhaust w acc., side exhaust (cf. hint <sup>2</sup> ) w acc., rear exhaust (cf. hint <sup>3</sup> )	1349 x 700 x 1124 mm 1355 x 660 x 1124 mm				
Water					
Water connection		G1/2"	(female)		
Water temperature					
pumps with LVO 210		5 – 3	5 °C		
pumps with LVO 400 / 410		5 – 2	25 °C		
Minimum supply pressure (unobstructed dischar- ge, no backpressure)		2 ba	r(g) <sup>5)</sup>		
Maximum supply pressure		6 ba	r(g) <sup>5)</sup>		
Nominal flow					
Screw	6 l/min	6 l/min	7.5 l/min	7.5 l/min	
Roots					
total	6 l/min	6 l/min	7.5 l/min	7.5 l/min	
Purge gas					
Connection		plug-in conr	nection D10		
Nominal setting pressure "Purge gas"		2.8 bar(g)	<sup>5)</sup> (± 5 %)		
(at nominal flow, valves open)					
Permissible setting pressure "Purge gas"		2.8 to 4.5 ba	r(g) <sup>5)</sup> (± 5 %)		
(at purge gas flow)					
Permissible supply pressure "Purge gas"		4.0 to 10.0 b	ar(g) <sup>5)</sup> (± 5 %)		
Purge gas flow shaft seal 2.8 bar(q)					
nozzle out- / inlet (d = $0.9 / 2.0$ mm)		22 / 92 slr	n (± 10 %)		
Rotor purge gas flow 2.8 bar(g)					
nozzle inlet (d = 1.0 mm)		28 slm (	± 10 %)		

Technical Data	DRYVAC SYSTEMS DS					
	25H(U) 45(S/C) b(T)	25H(U) 65(S/C) b(T)	25HF 45(S/C) b(T)	25HF 65(S/C) b(T)		
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)	2500 / 3000	) m³/h ± 5 %	5000 m <sup>3</sup>	/h ± 5 %		
Max. effective pumping speed (50/60 Hz) (± 5 %)	2100 / 2400 m <sup>3</sup> /h	2150 / 2500 m³/h	3500 m³/h	3750 m³/h		
Ult. total pressure w/o rotor and inlet purge (± 10 %)	< 5 x 10 <sup>-3</sup> mbar					
Maximum permissible inlet pressure		1013	mbar			
Maximum permissible discharge pressure (relative to ambient)		+200	mbar			
Integral leak rate		< 1 x 10-	<sup>1</sup> mbar x l/s			
Water vapor tolerance with purge gas (SV40)		60 r ≥ 20 l	nbar NI/min			
Water vapor capacity	15 kg/h	25 kg/h	15 kg/h	25 kg/h		
Permissible ambient temperature		+5 +	- 35 °C			
Storage temperature		-10	+ 60 °C			
Noise level (rigid exhaust pipe) <sup>6)</sup> Screw Roots	65 dB(A) (K <sub>pA</sub> = 3dB) < 63 dB(A)					
Relative atmospheric humidity		95 %, non-	condensing			
Installation location	up to 2000 m (NHN) <sup>2)</sup> up to 1000 m (		) m (NHN) <sup>2)</sup>			
Cooling		Wa	iter			
Mains voltages and frequencies	380 – 440 V 50 Hz / 420 – 480 V 60 Hz 380 – 480 V 50/60 Hz					
Frequency (± 5 %)		50 /	60 Hz			
Phases		3-	ph			
Rated power (400 V 50 Hz / 460 V 60 Hz) (± 0,8 kW) Screw	11 kW 6 2 / 7 4 kW	15 kW 6 2 / 7 4 kW	11 kW	15 kW 11 kW		
Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	17.2 / 18.4 kW	21.2 / 22.4 kW	22 kW	26 kW		
Rated current (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling	24 / 21 A 11.6 A 35.6 / 32.6 A	31 / 27 A 11.6 A 42 / 38.6 A	24 / 21 A 20 / 17 A 44 / 38 A	31 / 27 A 20 / 17 A 51 / 44 A		
totalling with 18.5 kW (U)						
Power consumption at ultimate pressure (50/60Hz)	5.6 / 5.7 kW	7.8 / 7.9 kW	6.2 / 6.2 kW	8.4 / 8.4 kW		
Motor efficiency class, calculated and configured acc. to EN 60034-30		IE	2			
Electrical power rating (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	17 / 14.9 kVA 8.4 kVA 25.4 / 23.3 kVA	21.8 / 19.1 kVA 8.4 kVA 30.2 / 27.5 kVA	17 / 14.9 kVA 14.2 / 12.1 kVA 31.2 / 27 kVA	21.8 / 19.1 kVA 14.2 / 12.1 kVA 36 / 31.2 kVA		
Speed Screw / Roots (50 Hz) Screw / Roots (60 Hz)	7200 / 3 7200 / 3	000 rpm 600 rpm	7200 / 6	6000 rpm 6000 rpm		
Min. permissible speed Screw <sup>3)</sup> Min. permissible speed Roots (off) <sup>4)</sup>	1200 0	ff	1200 1200	) rpm ) rpm		
Protection class	IP54					

Technical Data	DRYVAC SYSTEMS DS				
	25H(U) 45(S/C) b(T)	25H(U) 65(S/C) b(T)	25HF 45(S/C) b(T)	25HF 65(S/C) b(T)	
Lubricant filling					
Screw		LVO 210	) / 410		
Total lubricant quantity (+ 5 %)		LVO 210	57410		
Screw LVO 210		1.2	21		
Screw LVO 410		1.2	21		
Roots LVO 210		1.2	21		
Roots LVO 400 Boots LVO 410	121				
Discharge flange	DN 63 ISO-K				
Materials (components in contact with gas in the	Grey cast iron /graphite cast iron / steal/steinless steal /apoxy paint / EKM				
pump chamber)					
Materials sealing the pump off in the pump chamber towards the outside		FKM, grey	cast iron		
Weight, approx. (± 40 kg)	1160	) kg	1190	) kg	
Dimensions (L x W x H)			·		
Conn. flange, w/o acc., side exhaust	1349 x 700 x 1074 mm				
Conn. flange, w/o acc., rear exhaust	1355 x 660 x 1074 mm				
w acc., rear exhaust (cf. hint <sup>3</sup> )					
Water					
Water connection		G1/2" (1	female)		
Water temperature					
pumps with LVO 210		5 - 3	5 °C 5 °C		
Minimum supply pressure (unobstructed dischar-		0 – 2. 2 har	(a) <sup>5)</sup>		
ge, no backpressure)		2 041	(9)		
Maximum supply pressure		6 bar	(g) <sup>5)</sup>		
Nominal flow					
Screw	6 l/min	7.5 l/min	6 l/min	7.5 l/min	
Roots	2.2 l/min	2.2 l/min	2.2 l/min	2.2 l/min	
total	0.2 //11/11	9.7 //11111	0.2 //11/11	9.7 1/11111	
Purge gas					
Connection		plug-in conn	ection D10		
Nominal setting pressure "Purge gas"		2.8 bar(g)	<sup>5)</sup> (± 5 %)		
(at nominal flow, valves open)					
Permissible setting pressure "Purge gas"		2.8 to 4.5 bar	(g) <sup>5)</sup> (± 5 %)		
(at purge gas flow)		1 0 to 10 0 bo	$r(\alpha) 5) (1 - 5 - 0(1))$		
Pure see flow shott and 0.0 hout )		4.0 to 10.0 ba	ι(y) <sup>∞</sup> (± ο %)		
Purge gas flow snaπ seal 2.8 bar(g) nozzle, out- / inlet (d = 0.9 / 2.0 mm)		99 / 99 elm	n (+ 10 %)		
Rotor purge gas flow 2.8 bar(g)	<u> </u>				
nozzle inlet (d = $1.0 \text{ mm}$ )		28 slm (±	± 10 %)		

Technical Data		DRYVAC S	YSTEMS DS		
	44H(U) 65(S/C) b(T)	44HF 65(S/C) b(T)	70H(U) 65(S/C) b(T)	70HF 65(S/C) b(T)	
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)	4400 / 5280 m <sup>3</sup> /h	7040 m³/h	7040 / 8 400 m <sup>3</sup> /h	9800 m³/h	
Max. effective pumping speed (50/60 Hz) (± 5 %)	3600 / 4200 m³/h	5150 m³/h	5200 m³/h	6800 m³/h	
Ult. total pressure w/o rotor and inlet purge (± 10 %)		< 5 x 10	) <sup>-3</sup> mbar		
Maximum permissible inlet pressure		1013	mbar		
Maximum permissible discharge					
pressure (relative to ambient)		+200	mbar		
Integral leak rate		< 1 x 10 <sup>-4</sup>	mbar x l/s		
Water vapor tolerance with purge gas (SV40)		60 n ≥ 20 N	nbar Jl/min		
Water vapor capacity	25 kg/h				
Permissible ambient temperature	+5 + 35 °C				
Storage temperature		-10 +	- 60 °C		
Noise level (rigid exhaust pipe) <sup>6)</sup> Screw Boots	65 dB(A) ( $K_{pA} = 3dB$ ) < 63 dB(A)				
Belative atmospheric humidity		95%, non-c	condensing		
Installation location	up to 2000 m	up to 1000 m	up to 2000 m	up to 1000 m	
Cooling		Wa	ter		
Mains voltages and frequencies	380 – 440 V 50 Hz 420 – 480 V 60 Hz	380 – 480 V 50/60 Hz	380 – 440 V 50 Hz 420 – 480 V 60 Hz	380 – 480 V 50/60 Hz	
Frequency (± 5 %)		50 / 6	60 Hz		
Phases		3-	ph		
Rated power (400 V 50 Hz / 460 V 60 Hz) (± 0,8 kW) Screw Roots Roots with 18.5 kW (U) totalling	15 kW 11 kW 18,5 kW 26 kW 33,5 kW	15 kW 11 kW 26 kW	15 kW 11 kW 18,5 kW 26 kW 33,5 kW	15 kW 11 kW 26 kW	
Rated current (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	31 / 27 A 20 / 17 A 35 / 29 A 51 / 44 A 66 / 56 A	31 / 27 A 20 / 17 A 51 / 44 A	31 / 27 A 20 / 17 A 35 / 29 A 51 / 44 A 66 / 56 A	31 / 27 A 20 / 17 A 51 / 44 A	
Power consumption at ultimate pressure (50/60 Hz)	8.1 / 8.3 kW	8.9 kW	8.1 / 8.3 kW	8.6 kW	
Motor efficiency class, calculated and configured acc. to EN 60034-30		IE	2		
Electrical power rating (400 V 50 Hz / 460 V 60 Hz) Screw Roots Roots with 18.5 kW (U) totalling totalling with 18.5 kW (U)	21.8 / 19.1 kVA 14.2 / 12.1 kVA 24.6 / 20.4 kVA 36 / 31.2 kVA 46.4 / 39.5 kVA	21.8 / 19.1 kVA 14.2 / 12.1 kVA 36 / 31.2 kVA	21.8 / 19.1 kVA 14.2 / 12.1 kVA 24.6 / 20.4 kVA 36 / 31.2 kVA 46.4 / 39.5 kVA	21.8 / 19.1 kVA 14.2 / 12.1 kVA 36 / 31.2 kVA	
Speed Screw / Roots (50 Hz)	7200 / 3000 rpm	7200 / 4800 rpm	7200 / 3000 rpm	7200 / 4200 rpm	
Screw / Roots (60 Hz)	7200 / 3600 rpm	7200 / 4800 rpm	7200 / 3600 rpm	7200 / 4200/min	
Min. permissible speed Screw <sup>3)</sup> Min. permissible speed Roots (off) <sup>4)</sup>	1200 rpm off	1200 rpm 1200 rpm	1200 rpm off	1200 rpm 1200 rpm	
Protection class		IP	54		
Lubricant filling Screw Roots	LVO 210 / 410 LVO 210 / 400				

Technical Data	DRYVAC SYSTEMS DS					
	44H(U) 65(S/C) b(T)	44HF 65(S/C) b(T)	70H(U) 65(S/C) b(T)	70HF 65(S/C) b(T)		
Total lubricant quantity (± 5 %)						
Screw LVO 210		1.2	2			
Screw LVO 410		1.2	2			
Roots LVO 210		4.75	5 I			
Roots LVO 400		4.75	5 I			
Roots LVO 410						
Intake flange	DN 250 ISO-K DN 320 ISO-K					
Discharge flange	DN 63 ISO-K					
Materials (components in contact with gas	Grey cast iron /graphite cast iron / steel/stainless steel /epoxy paint / FKM					
in the pump chamber)						
Materials sealing the pump off in the pump		FKM, grey	cast iron			
chamber towards the outside						
Weight, approx. (± 40 kg)	1370 kg	1400 kg	1465 kg	1495 kg		
Dimensions (L x W x H)						
Conn. flange, w/o acc., side exhaust	1349 x 700 >	k 1074 mm	1460 x 70	0 x 1076		
Conn. flange, w/o acc., rear exhaust	1355 x 660 >	k 1074 mm	1460 x 660 x 1076			
w acc., side exhaust (cf. hint 2)						
w acc., rear exhaust (cf. hint 3)						
Water						
Water connection		G1/2" (i	female)			
Water temperature						
pumps with LVO 210		5 – 3	5 °C			
pumps with LVO 400 / 410		5 – 2	5 °C			
Minimum supply pressure (unobstructed		2 bar	(q) <sup>5)</sup>			
discharge, no backpressure)						
aximum supply pressure		6 bar	(g) <sup>5)</sup>			
Nominal flow						
Screw		7.5 1/	min			
Roots		5.7 1/	min			
total		13.2	/min			
Purge gas						
Connection		plug-in conn	ection D10			
Nominal setting pressure "Purge gas" (at nominal flow, valves open)		2.8 bar(g)	<sup>5)</sup> (± 5 %)			
Permissible setting pressure "Purge gas" (at purge gas flow)		2,.8 to 4.5 ba	r(g) <sup>5)</sup> (± 5 %)			
Permissible supply pressure "Purge gas"		4.0 to 10.0 ba	r(g) <sup>5)</sup> (± 5 %)			
Purge gas flow shaft seal 2.8 bar(g) nozzle out- / inlet (d = 0.9 / 2.0 mm)	22 / 92 slm					
Rotor purge gas flow 2.8 bar(g) nozzle inlet (d = 1.0 mm)		28 s	slm			
Additional information regarding the technic	al data					

- Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).
- 2) The frequency converter standard ratings are valid for an installation altitude up to 1000 m. If the altitude exceeds 1000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 3) In case of overvoltage (> 480 V), bad cooling and permanent operation at nominal power the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>
- 4) The minimum permissible frequency is 20 Hz for both the DRYVAC and the RUVAC. The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for 50Hz operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.



#### **Configuration matrix**

Part numbers for DRYVAC SYSTEMS are based on the matrix shown in the figure above and give hints on the individual configuration and features of the pump combination in question:

leybold

#### **Ordering Information**

#### **DRYVAC SYSTEMS**

Part No.	Description	Lubricants Screw	Lubricants Roots	Purge gas module	Exhaust / Check valve	Quick-release coupling (one-sided)
DS3411b0000	DS 20AU45S-b	LVO210	LVO210	triple	side / no	no
DS1411b0000	DS 20AU65S-b	LVO210	LVO210	triple	side / no	no
DS3301b0000	DS 25H45S-b	LVO210	LVO210	triple	side / no	no
DS1201b0000	DS 44H65S-b	LVO210	LVO210	triple	side / no	no
DS1211b0000	DS 44HU65S-b	LVO210	LVO210	triple	side / no	no
DS1212b0000	DS 44HU65S-b	LVO4x0	LVO4x0	triple	side / no	no
DS2512b0000	DS 20SU65C-b	LVO4x0	LVO4x0	triple	side / no	no
DS1511b0000	DS 20SU65S-b	LVO210	LVO210	triple	side / no	no
DS1301b0000	DS 25H65S-b	LVO210	LVO210	triple	side / no	no
DS1311b0000	DS 25HU65S-b	LVO210	LVO210	triple	side / no	no
DS1312b0000	DS 25HU65S-b	LVO4x0	LVO4x0	triple	side / no	no
DS3511b0000	DS 20SU45S-b	LVO210	LVO210	triple	side / no	no

... to be continued

#### **Accessories**

	Part No.
Synthetic Oil LEYBONOL LVO 210, 1 I	L21001
Synthetic Oil LEYBONOL LVO 210, 5 I	L21005
PFPE LEYBONOL LVO 400, 1 I	L40001
PFPE LEYBONOL LVO 410, 1 I	L41001
Roots pump adapter for DRYVAC for RUVAC WH 700 RUVAC WS(U) 1001	112005A03 112005A04
RUVAC WS(U) 2001	112005A05
RUVAC WH(U) 2500	112005A07
RUVAC WH(U) 4400/7000	112005A10
Non-return valve DRYVAC, DN 63 ISO-K	112005A15
Silencer DN 63 ISO-K for DRYVAC SYSTEMS	119002
Serviceable Silencer DN 63 ISO-K for DRYVAC SYSTEMS	119003V
External Display	155213V
Purge gas nozzle set for DRYVAC	112005A30
Permanent purge gas inlet kit	112005A32
Ground fixation	503637V001
Rotatable crane eyes (M 20 x 30; set of 4)	504397V901

GSD file and manual for the Profibus interface see the Leybold homepage.

## Dry Compressing Pump Systems DRYVAC Smart System Configuration



The two-stage DRYVAC SYSTEMS consist of a combination of dry compressing Roots pumps and screw pumps. The Roots pump installed on top of the backing pump serves as a booster for increasing the pumping speed.

Various types of pumps may be used with DRYVAC SYSTEMS:

#### **Roots Pumps**

RUVAC WA RUVAC WAU RUVAC WH RUVAC WHU RUVAC WS RUVAC WSU

#### **Backing Pumps**

DRYVAC DV S DRYVAC DV C All DRYVAC SYSTEMS (i versions) described hereinafter are equipped with:

- Microcontroller with touchscreen
- Connectivity options for gauge heads
- Harting connections (power supply)
- Digital I/O communication interface (DC37-P)
- Housing, castors and adjustable feet

They are water-cooled and lubricated either with synthetic oil or PFPE.

leybold


Dimensional drawing for DS 20A(U) 45(S/C) iT, DS 20A(U) 65(S/C) iT, DS 20S(U) 45(S/C) iT, DS 20S(U) 65(S/C) iT (Dimensions in mm)



Dimensional drawing for DS 25H(U) 45(S/C) iT, DS25H(U) 65(S/C) iT, DS 25HF 45(S/C) iT, DS 25HF 65(S/C) iT (Dimensions in mm)



Dimensional drawing for DS 44H(U) 45(S/C) iT, DS 44H(U) 65(S/C) iT, DS 44HF 65(S/C) iT (Dimensions in mm)



Dimensional drawing for DS 70H(U) 65(S/C) iT, DS 70HF 65(S/C) iT (Dimensions in mm)

#### Notes

Technical Data	DRYVAC SYSTEMS DS			
	20A(U) 45(S/C) iT	20S(U) 45(S/C) iT	20A(U) 65(S/C) iT	20S(U) 65(S/C) iT
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)		2000 / 24	100 m³/h	
Max. effective pumping speed (50/60 Hz) (± 5 %)	1600 / 18	350 m³/h	1750 / 2	050 m³/h
Ult. total pressure w/o rotor and inlet purge (± 10 %)		<u>≤</u> 5 x 10	<sup>-3</sup> mbar	
Maximum permissible inlet pressure		1013	mbar	
Maximum permissible discharge pressure (relative to ambient)		+200	mbar	
Integral leak rate	< 5 x 10 <sup>-4</sup> mbar x l/s	$s < 1 \times 10^{-4}$ mbar x l/s	< 5 x 10 <sup>-4</sup> mbar x l/	$s < 1 \times 10^{-4}  \text{mbar x l/s}$
Water vapor tolerance with purge gas (SV40)		60 m ≥ 20 N	nbar Il/min	
Water vapor capacity	15	<g h<="" td=""><td>25</td><td>kg/h</td></g>	25	kg/h
Permissible ambient temperature		+5 +	35 °C	
Lagerungstemperatur		-10 +	- 60 °C	
Noise level (rigid exhaust pipe) <sup>6)</sup> Screw Boots	< 80 dB(A)	65 dB(A) (k	$f_{pA} = 3 \text{ dB}$	< 72 dB(A)
Belative atmospheric humidity		95% non c	condensing	
Installation location		up to 2000	m (NHN) <sup>2)</sup>	
Cooling		Water	/ air	
Mains voltages and frequencies	380 – 440 V 50 Hz / 420 – 480 V 60 Hz			
Frequency (± 5 %)		50 / 6	i0 Hz	
Phases		3-r	bh	
Rated power at 400 V 50 Hz / 460 V 60 Hz at 400 V 50 Hz / 460 V 60 Hz with RUVAC 18,5 kW	18.5 kW	18.5 / 19.5 kW	22.5 kW	22.5 / 23.5 kW
Rated current at 400 V 50 Hz / 460 V 60Hz	38.1 / 33,5 A	39.5 / 36.5 A	45.1 / 39.5 A	46.5 / 42.5 A
Power consumption at ultimate pressure				
Motor efficiency class, calculated and configured acc. to EN 60034-30	IE2			
Electrical power rating 400V 50Hz 460V 60Hz	26.4 kVA 23.2 kVA	27.4 kVA 25.3 kVA	31.2 kVA 27.4 kVA	32.2 kVA 29.4 kVA
RUVAC rated current f. motor protection 380 – 440 V 50 Hz / 420 – 480 V 60 Hz	14 / 12 A	15 / 15 A	14 / 12 A	15 / 15 A
Speed Screw / Roots (50 Hz) Screw / Roots (60 Hz)		7200 / 3 7200 / 3	3000 rpm 3600 rpm	
Min. permissible speed Screw <sup>3)</sup> Min. permissible speed Roots (off) <sup>4)</sup>		1200 ot	rpm ff	
Protection class		IP2	20	

Technical Data	DRYVAC-SYSTEM DS			
	20A(U) 45(S/C) iT	20S(U) 45(S/C) iT	20A(U) 65(S/C) iT	20S(U) 65(S/C) iT
Lubricant filling				
Screw	LVO 210 / 410	LVO 210 / 410	LVO 210 / 410	LVO 210 / 410
Roots	LVO 210	LVO 210 / 400	LVO 210	LVO 210 / 400
Total lubricant quantity (± 5 %)				
Screw LVO 210	1.2	1.2	1.2	1.2
Screw LVO 410	1.2	1.2	1.2	1.2
Roots LVO 210	3.6	3.6	3.6	3.6
Roots LVO 400		2.7		2.7
Roots LVO 410				
Intake flange		DN 160	) ISO-K	
Discharge flange		DN 63	ISO-K	
Materials (components in contact with gas in the pump chamber)	Grey cast iron /	graphite cast iron / ste	eel/stainless steel /ep	oxy paint / FKM
Materials sealing the pump off in the pump chamber towards the outside		FKM, grey	r cast iron	
Weight, approx. (± 40 kg)	1156 kg	1215 kg	1156 kg	1215 kg
Dimensions (L x W x H) Conn. flange, w/o acc., side exhaust Conn. flange, w/o acc., rear exhaust w acc., side exhaust (cf. hint <sup>2</sup> ) w acc., rear exhaust (cf. hint <sup>3</sup> )	1532 x 708 x 1124 mm 1532 x 666 x 1124 mm			
Water				
Water connection	G1/2" (female)			
Water temperature				
pumps with LVO 210	5 – 35 °C			
pumps with LVO 400 / 410	5 – 25 °C			
Minimum supply pressure (unobstructed dischar- ge, no backpressure)	2 bar(g) <sup>5)</sup>			
Maximum supply pressure	6 bar(g) <sup>5)</sup>			
Nominal flow				
Screw	6 l/min	6 l/min	7.5 l/min	7.5 l/min
Roots				
total	6 l/min	6 l/min	7.5 l/min	7.5 l/min
Purge gas				
Connection	plug-in connection D10			
Nominal setting pressure "Purge gas"		2.8 bar(g)	<sup>5)</sup> (± 5 %)	
(at nominal flow, valves open)				
Permissible setting pressure "Purge gas"		2.8 to 4.5 ba	r(g) <sup>5)</sup> (± 5 %)	
(at purge gas flow)				
Permissible supply pressure "Purge gas"		4.0 to 10.0 ba	ar(g) <sup>5)</sup> (± 5 %)	
Purge gas flow shaft seal 2.8 bar(g)				
nozzle out- / inlet (d = 0.9 / 2.0 mm)		22 / 92 slr	n (± 10 %)	
Rotor purge gas flow 2.8 bar(g)				
nozzle inlet (d = 1.0 mm)	28 slm (± 10 %)			

Technical Data	DRYVAC-SYSTEM DS			
	25H(U) 45(S/C) iT	25H(U) 65(S/C) iT	25HF 45(S/C) iT	25HF 65(S/C) iT
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)	2500 / 3000	m³/h ± 5 %	5000 m³/	h ± 5 %
Max. effective pumping speed (50/60 Hz) (± 5 %)	2100 / 2400 m³/h	2150 / 2500 m³/h	3500 m³/h	3750 m³/h
Ult. total pressure w/o rotor and inlet purge (± 10 %)		< 5 x 10	-3 mbar	·
Maximum permissible inlet pressure		1013 r	mbar	
Maximum permissible discharge pressure (relative to ambient)		+200 1	mbar	
Integral leak rate		< 1 x 10 <sup>-4</sup>	mbar x l/s	
Water vapor tolerance with purge gas (SV40)		60 m ≥ 20 N	bar Il/min	
Water vapor capacity	15 kg/h	25 kg/h	15 kg/h	25 kg/h
Permissible ambient temperature		+5 +	35 °C	
Lagerungstemperatur		-10 +	00 °C	
Noise level (rigid exhaust pipe) <sup>6)</sup> Screw Roots	65 dB(A) (K <sub>pA</sub> = 3 dB) < 63 dB(A)			
Relative atmospheric humidity		95%, non c	condensing	
Installation location	up to 2000 m (NHN) <sup>2)</sup> up to 1000 m (NHN) <sup>2)</sup>			m (NHN) 2)
Cooling	Water			
Mains voltages and frequencies	380 – 440 V 50 Hz / 420 – 480 V 60 Hz 380 – 480 V 50/60 Hz			/ 50/60 Hz
Frequency (± 5 %)	50 / 60 Hz			
Phases		3-p	ph	
ated power at 400 V 50 Hz / 460 V 60 Hz at 400 V 50 Hz / 460 V 60 Hz with RUVAC 18,5 kW	17.2 / 18.5 kW	21.1/ 22.5 kW	22 kW	26 kW
Rated current at 400 V 50 Hz / 460 V 60 Hz	36.1 / 33.1 A	43.1 / 39.1 A	44.5 / 38.5 A	51.5 / 44.5 A
Power consumption at ultimate pressure	5.6 / 5.7 kW	7.8 / 7.9 kW	6.2 / 6.2 kW	8.4 / 8.4 kW
Motor efficiency class, calculated and configured acc. to EN 60034-30	IE2			
Electrical power rating 400V 50Hz 460V 60Hz	25 kVA 22.9 kVA	29.9 kVA 27.1 kVA	30.8 kVA 26.7 kVA	35.7 kVA 30.8 kVA
RUVAC rated current f. motor protection 380 – 440 V 50 Hz / 420 – 480 V 60 Hz	12 / 12 A	12 / 12 A		
Speed Screw / Roots (50 Hz) Screw / Roots (60 Hz)	7200 / 30 7200 / 36	000 rpm 600 rpm	7200 / 60 7200 / 60	000 rpm 000 rpm
Min. permissible speed Screw 3) Min. permissible speed Roots (off) 4)	1200 of	rpm ff	1200 1200	rpm rpm
Protection class	IP 20			

Technical Data	DRYVAC-SYSTEM DS			
	25H(U) 45(S/C) iT	25H(U) 65(S/C) iT	25HF 45(S/C) iT	25HF 65(S/C) iT
Lubricant filling			2 / 410	
Roots		LVO 210	) / 410 ) / 410	
Total lubricant quantity (± 5 %)				
Screw LVO 210		1.2	21	
Screw LVO 410		1.2		
Roots LVO 400		1.2	. 1	
Roots LVO 410		1.2	2	
Intake flange		DN 250	ISO-K	
Discharge flange		DN 63	ISO-K	
Materials (components in contact with gas in the pump chamber)	Grey cast iron /g	graphite cast iron / ste	el/stainless steel /ep	oxy paint / FKM
Materials sealing the pump off in the pump chamber towards the outside		FKM, grey	cast iron	
Weight, approx. (± 40 kg)	1160	) kg	119	) kg
Dimensions (L x W x H) Conn. flange, w/o acc., side exhaust Conn. flange, w/o acc., rear exhaust w acc., side exhaust (cf. hint <sup>2</sup> ) w acc., rear exhaust (cf. hint <sup>3</sup> )	1532 x 708 x 984 mm 1532 x 666 x 984 mm			
Water				
Water connection	G1/2" (female)			
Water temperature				
pumps with LVO 210	5 – 35 °C			
pumps with LVO 400 / 410	5 – 25 °C			
Minimum supply pressure (unobstructed dischar- ge, no backpressure)	2 bar(g) <sup>5)</sup>			
Maximum supply pressure	6 bar(g) <sup>5)</sup>			
Nominal flow				
Screw	6 l/min	7.5 l/min	6 l/min	7.5 l/min
Roots	2.2 l/min	2.2 l/min	2.2 l/min	2.2 l/min
lota	0.2 //11/11	9.7 //////	0.2 1/11111	9.7 1/11111
Purge gas				
Connection	plug-in connection D10			
Nominal setting pressure "Purge gas"		2.8 bar(g)	<sup>5)</sup> (± 5 %)	
(at nominal flow, valves open)				
Permissible setting pressure "Purge gas"		2.8 to 4.5 ba	r(g) <sup>5)</sup> (± 5 %)	
lar purge gas now) Permissible supply pressure "Purge gas"		10 to 100 br	r(a) = (+ 5 %)	
Purgo gos flow shoft soal 2.9 hor(a)		4.0 10 10.0 De	u (9) · (± 0 /0)	
nozzle out- / inlet (d = $0.9 / 2.0$ mm)		22 / 92 slm	n (± 10 %)	
Rotor purge gas flow 2.8 bar(g)			· - · · /	
nozzle inlet (d = $1.0 \text{ mm}$ )		28 slm (=	± 10 %)	

Technical Data	DRYVAC-SYSTEM DS			
	44H(U) 65(S/C) iT	44HF 65(S/C) iT	70H(U) 65(S/C) iT	70HF 65(S/C) iT
Max. pump speed w/o gas ballast (50/60 Hz) (± 5 %)	4400 / 5280 m <sup>3</sup> /h	7040 m³/h	7040 / 8400 m <sup>3</sup> /h	9 800 m³/h
Max. effective pumping speed (50/60 Hz) (± 5 %)	3600 / 4200 m <sup>3</sup> /h	5150 m³/h	5200 m³/h	6 800 m³/h
Ult. total pressure w/o rotor and inlet purge (± 10 %)		< 5 x 10 <sup>.3</sup> mbar		
Maximum permissible inlet pressure		1013	mbar	
Maximum permissible discharge		+200	mbar	
pressure (relative to ambient)				
Integral leak rate		< 1 x 10 <sup>-4</sup>	mbar x l/s	
Water vapor tolerance with purge gas (SV40)		60 m ≥ 20 N	nbar Il/min	
Water vapor capacity		25 k	:g/h	
Permissible ambient temperature		+5 +	35 °C	
Lagerungstemperatur		-10 +	- 60 °C	
Noise level (rigid exhaust pipe) 6)				
Screw Roots		65 dB(A) (H < 63 d	K <sub>pA</sub> = 3 dB) dB(A)	
Relative atmospheric humidity		95%, non (	condensing	
Installation location	up to 2000 m	up to 1000 m	up to 2000 m	up to 1000 m
Cooling		Wa	ter	
Mains voltages and frequencies	380 – 440 V 50 Hz 420 – 480 V 60 Hz	380 – 480 V 50/60 Hz	380 – 440 V 50 Hz 420 – 480 V 60 Hz	380 – 480 V 50/60 Hz
Frequency (± 5 %)	50 / 60 Hz			
Phases		3-	ph	
ated power at 400 V 50 Hz / 460 V 60 Hz at 400 V 50 Hz / 460 V 60H z with BLIVAC 18 5 kW				
Bated current at 400 V 50 Hz / 460 V 60 Hz	51.5 / 44.5 A	51.5 / 44.5 A	51.5 / 44.5 A	51.5 / 44.5 A
Power consumption at ultimate pressure	8.1 / 8.3 kW	8.9 kW	8.1 / 8.3 kW	8.6 kW
Motor efficiency class, calculated and configured acc. to EN 60034-30		IE	2	
Electrical power rating 400V 50 Hz 460V 60 Hz	35.7 kVA			
RUVAC rated current f. motor protection 380 – 440V 50Hz / 420 – 480V 60Hz	20 / 17 A		20 / 17 A	
Speed Screw / Roots (50 Hz) Screw / Roots (60 Hz)	35 / 29 A		35 / 29 A	
Min. permissible speed Screw <sup>3)</sup> Min. permissible speed Roots (off) <sup>4)</sup>	7200 / 3000 rpm 7200 / 3600 rpm	7200 / 4800 rpm 7200 / 4800 rpm	7200 / 3,000 rpm 7200 / 3,600 rpm	7200 / 4200 rpm 7200 / 4200 rpm
Protection class	1200 rpm 1200 rpm 1200 rpm 0ff 0ff		rpm f	
Schutzart	IP20			
Lubricant filling Screw Roots	LVO 210 / 410 LVO 210 / 400			
Total lubricant quantity (± 5 %) Screw LVO 210 Screw LVO 410 Roots LVO 210 Roots LVO 400 Roots LVO 410	1.2   1.2   4.75   4.75   4.75			

Technical Data	DRYVAC-SYSTEM DS			
	44H(U) 65(S/C) iT	44HF 65(S/C) iT	70H(U) 65(S/C) iT	70HF 65(S/C) iT
Intake flange	DN 250 ISO-K		DN 320 ISO-K	
Discharge flange		DN 63	ISO-K	
Materials (components in contact with gas in the pump chamber) Materials sealing the pump off in the pump chamber towards the outside	Grey cast iron /graphite cast iron / steel/stainless steel /epoxy paint / FKM FKM, grey cast iron			oxy paint / FKM
Weight, approx. (± 40 kg)	1370 kg	1400 kg	1465 kg	1495 kg
Dimensions (L x W x H) Conn. flange, w/o acc., side exhaust Conn. flange, w/o acc., rear exhaust w acc., side exhaust (cf. hint <sup>2</sup> ) w acc., rear exhaust (cf. hint <sup>3</sup> )	1532 x 708 > 1532 x 666 >	< 1074 mm < 1074 mm	1643 x 708 1643 x 666	x 1074 mm x 1074 mm
Water				
Water connection		G1/2" (	female)	
Water temperature pumps with LVO 210 pumps with LVO 400 / 410	5 – 35 °C 5 – 25 °C			
Minimum supply pressure (unobstructed dischar- ge, no backpressure)	2 bar(g) <sup>5)</sup>			
Maximum supply pressure	6 bar(g) <sup>5)</sup>			
Nominal flow Screw Roots total	7.5 l/min 5.7 l/min 13.2 l/min			
Purge gas				
Connection		plug-in conr	nection D10	
Nominal setting pressure "Purge gas" (at nominal flow, valves open)		2.8 bar(g)	<sup>5)</sup> (± 5 %)	
Permissible setting pressure "Purge gas" (at purge gas flow)	2.8 to 4.5 bar(g) $^{5)}(\pm 5 \%)$			
Permissible supply pressure "Purge gas"		4.0 to 10.0 ba	$ar(g)^{(5)}(\pm 5\%)$	
Purge gas flow shaft seal 2.8 bar(g) nozzle out- / inlet (d = 0.9 / 2.0 mm)		22 / 92 sln	n (± 10 %)	
Rotor purge gas flow 2.8 bar(g) nozzle inlet (d = 1.0 mm)		28 slm (:	± 10 %)	

#### Additional information regarding the technical data

 Noise levels of > 100 dB(a) may occur with cyclic operation conditions, e.g. with load-lock operations or plain pump-downs, In this case we recommend to use RUVAC pumps with a pressure balance line ("U"-pumps).

2) The frequency converter standard ratings are valid for an installation altitude up to 1000 m. If the altitude exceeds 1000 m both the input voltage and the rated output current must be derated for 1% per 100 m.

3) In case of overvoltage (> 480 V), bad cooling and permanent operation at nominal power the output power may be reduced in order to prevent thermal overload of the frequency converter. In case of undervoltage (< 380 V) the maximum power is not available by design.</p>

- 4) The minimum permissible frequency is 20 Hz for both the DRYVAC and the RUVAC. The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 5) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 6) Valid for 50Hz operations at ult. pressure conditions. Higher speeds, especially pressures >10 mbar, generate higher noise levels.



\*\*\*\* für abweichende Konfigurationen zur Werkseinstellung (nach Rücksprache mit Leybold) / for different configurations to the factory setting (after consultation with Leybold)

# **Configuration matrix**

Part numbers for DRYVAC SYSTEMS are based on the matrix shown in the figure above and give hints on the individual configuration and features of the pump combination in question:

### **DRYVAC SYSTEMS**

Part No.	Description	Lubricants	Lubricants	Purge gas	Exhaust /	Quick-release
		Screw	Roots	module	Check valve	coupling
						(one-sided)
DS3411iT00000	DS 20AU45S iT	LVO210	LVO210	triple	side / no	no
DS1411iT00000	DS 20AU65S iT	LVO210	LVO210	triple	side / no	no
DS2512iT00000	DS 20SU65C iT	LVO410	LVO400	triple	side / no	no
DS1512iT00000	DS 20SU65S iT	LVO410	LVO400	triple	side / no	no
DS1511iT00000	DS 20SU65S iT	LVO210	LVO210	triple	side / no	no
DS2302iT00000	DS 25H65C iT	LVO410	LVO410	triple	side / no	no
DS1303iT00320	DS 25H65S iT	LVO210	LVO410	triple	rear / yes	yes
DS1303iT00000	DS 25H65S iT	LVO210	LVO410	triple	side / no	no
DS4332iT00320	DS 25HF45C iT	LVO410	LVO410	triple	rear / yes	yes
DS3332iT00320	DS 25HF45S iT	LVO410	LVO410	triple	rear / yes	yes
DS3331iT00000	DS 25HF45S iT	LVO210	LVO210	triple	side / no	no
DS2332iT00320	DS 25HF65C iT	LVO410	LVO410	triple	rear / yes	yes
DS1333iT00320	DS 25HF65S iT	LVO210	LVO410	triple	rear / yes	yes
DS3313iT00320	DS 25HU45S iT	LVO210	LVO410	triple	rear / yes	yes
DS1313iT00320	DS 25HU65S iT	LVO210	LVO410	triple	rear / yes	yes
DS1311iT00000	DS 25HU65S iT	LVO210	LVO210	triple	side / no	no
DS2202iT00000	DS 44H65C iT	LVO410	LVO400	triple	side / no	no
DS1201iT00000	DS 44H65S iT	LVO210	LVO210	triple	side / no	no
DS2232iT00320	DS 44HF65C iT	LVO410	LVO400	triple	rear / yes	yes
DS1223iT00320	DS 44HU65S iT	LVO210	LVO400	triple	rear / yes	yes
DS1223iT00000	DS 44HU65S iT	LVO210	LVO400	triple	side / no	no
DS1212iT00000	DS 44HU65S iT	LVO410	LVO400	triple	side / no	no
DS1211iT00000	DS 44HU65S iT	LVO210	LVO210	triple	side / no	no
DS2132iT00320	DS 70HF65C iT	LVO410	LVO400	triple	rear / yes	yes

... to be continued

### Accessories

leybold

	Part No.
Synthetic Oil LEYBONOL LVO 210, 1 I	L21001
Synthetic Oil LEYBONOL LVO 210, 5 I	L21005
PFPE LEYBONOL LVO 400, 1 I	L40001
PFPE LEYBONOL LVO 410, 1 I	L41001
Silencer DN 63 ISO-K for DRYVAC SYSTEMS	119002
Serviceable Silencer DN 63 ISO-K for DRYVAC SYSTEMS	119003V
Harting plug for DRYVAC S-i/RS-i/DV-i/DVR-i	112 005A20
Active sensors / gauge heads	
Kit CTR 1 Torr	504391V901
Kit CTR 100 Torr	504392V901
Kit CTR 1000 Torr	504393V901
Kit DU 200	504394V901
Kit DU 2000	504395V901
Kit TTR 91	504396V901
Rotatable crane eyes (M 20 x 30; set of 4)	504397V901
Counter coupling water, BNP	504406V901
Counter coupling water, stainless-steel	504407V901

GSD file and manual for the Profibus interface see the Leybold homepage.

# Dry Compressing Pump Systems DRYVAC PowerBoost



The DRYVAC SYSTEM 44HUF65S iV (DS 4465-U2) consists of a combination of a dry compressing screw pump and a Roots pump. Its design has been specifically optimized for a fast load lock pump-downs, it is equipped with an automatic cycle detection system, and the Roots pump shows a special speed management. Thus, with an optimum utilization of the power, the mechanical stress due to pressure bursts was minimized, and the noise level during pump-downs was significantly reduced.

Furthermore the system described hereinafter is equipped with:

- integrated frequency converters
- Microcontroller with touchscreen
- digital I/O communication interface (DC37-P)
- Harting connections (power supply)
- housing, castors and adjustable feet

The system is water-cooled and lubricated with synthetic oil.



Dimensional drawing for PowerBoost DS 4465 U2 (Dimensions in mm)

# **Technical Data**

# DRYVAC SYSTEM DS 44HUF65S iV

Ultimate total pressure w/o purge gas or with purge gas for	. 5 × 10 <sup>3</sup> mbm
shaft seal outlet (± 10 %)	< 5 X 10° mbar
Maximum permissible inlet pressure	1050 mbar
Maximum permissible discharge pressure (relative to ambient)	+200 mbar
Integral leak rate	< 1 x 10 <sup>-4</sup> mbar x l/s
Permissible gas inlet temperature	+5 +40 °C
Permissible ambient temperature	+5 +30 °C
Storage temperature	-10 +60 °C
Noise level with rigid exhaust pipe, at ultimate pressure (acc. to DIN EN ISO 2151)	Screw = 65 dB(A) Roots = 63 dB(A) <sup>5)</sup> (K <sub>pA</sub> = 3 dB)
Relative atmospheric humidity	95%, non-condensing
Installation location	up to 1000 m (NHN) <sup>1)</sup>
Cooling	Water
Mains voltage	360 – 440 V 50/60 Hz <sup>2)</sup>
Frequency (± 5%)	50 / 60 Hz
Phasen	3-ph
Rated power at 400 V (± 0,8 kW)	57 kW
Rated current at 400 V	95 A
Power consumption at ultimate pressure (± 0,8 kW)	9 kW
Motor efficiency class, calculated and configured acc. to EN 60034-30	IE2
Min. permissible speed <sup>3)</sup>	1200 rpm
Protection class	IP20
Lubricant filling	LVO 210
Total lubricant quantity (± 5%)	5.7
Intake flange	DN 250 ISO-K
Discharge flange	DN 63 ISO-K
Materials (components in contact with gas in the pump chamber)	Grey cast iron /graphite cast iron / steel/stainless steel /epoxy paint / FKM
Materials sealing the pump off in the pump chamber towards the outside	FKM, grey cast iron
Weight, approx. (± 40 kg)	1500 kg
Dimensions (L x W x H) (± 10 mm)	1704 x 677 x 1140 mm
Water	
Water connection	G1/2" (female)
Water temperature	5 – 35 °C
Minimum supply pressure (unobstructed discharge, no backpressure)	2 bar(g) 4)
Maximum supply pressure	7 bar(g) 4)
Nominal flow	14 l/min

# **Technical Data**

# DRYVAC SYSTEM DS 44HUF65S iV

Purge gas				
Connection	G1/4" (female)			
Nominal setting pressure "Purge gas" (at nominal flow, valves open)	2.8 bar(g) 4)			
Permissible setting pressure "Purge gas" (at purge gas flow)	2.8 to 4.5 bar(g) 4)			
Permissible supply pressure "Purge gas"	4.0 to 10.0 bar(g) 4)			
Purge gas flow shaft seal inlet (d = 2.0 mm) / outlet (d = 0.9 mm) at nominal setting pressure (2.8 bar(g)) at max. setting pressure (3.5 bar(g))	92 slm / 22 slm 107 slm / 26 slm			

#### Additional information regarding the technical data

- 1) The frequency converter standard ratings are valid for an installation altitude up to 1000 m. If the altitude exceeds 1000 m both the input voltage and the rated output current must be derated for 1% per 100 m.
- 2) In case of undervoltage (< 380 V) the maximum power is not available by design.
- The minimum permissible frequency is 20 Hz for both the DRYVAC and the RUVAC.
   The minimum permissible speed is relevant for the oil lubrication of bearings and gears. Running the pump at less than the minimum speed for more than 1 hour can cause damage to the pump due to a lack of lubrication.
- 4) bar(g): bar (gauge) is the overpressure, i.e. atmospheric pressure = 0 bar(g)
- 5) The noise level is significantly higher due to flow generated noises during load lock operations. Its accurate value depends on the operational mode used as well as the intake line's design. The pump system DS 44HUF65S iV is equipped with an automatic cycle detection system. With detecting vacuum cycles the pump system will reduce the noise level to a minimum during pump-downs.



### **DRYVAC-SYSTEM DS**

# 44HUF65S iV

	Part No.
DRYVAC PowerBoost	
DS 4465 U2	DS1241iV01320
Harting plug for 100 A	504613V901
Counter coupling water, BNP	504406V901
DRYVAC PowerBoost Plus	
DS 4465 U2	DS1241iV01320
Harting plug for 100 A	504613V901
DV650 Plus Upgrade kit	504595V901
Harting plug for 65 A	112005A20
Counter coupling water, BNP (2x)	504406V901

### Accessories

	Part No.
Synthetic Oil LEYBONOL LVO 210, 1 litre	L21001
Floor mount (optional; set of 4 with foundation bolts)	503637V001
Rotatable crane eyes	6521504

# RUVAC RAV Roots Vacuum Pumps with Pre-Admission Cooling



#### Advantages to the User

#### - RUVAC RAV G

Operating pressure range of 150 mbar (112.5 Torr) against atmospheric pressure; total leak rate <  $10^{-1}$  mbar x l/s (7.5 x  $10^{-2}$  Torr x l/s)

#### - RUVAC RAV F

In combination with backing pumps the attainable operating pressures extend down into the medium vacuum range; leak rate <  $10^{-2}$  mbar x l/s (7.5 x  $10^{-3}$  Torr x l/s)

- When series-connected the operating pressures extend down into the medium vacuum range:
  - two-stages to 25 mbar (18.75 Torr)
     multiple stage to 10<sup>-3</sup> m
  - multiple stage to 10<sup>-3</sup> mbar (7.5 x 10<sup>-4</sup> Torr)
- Motors for special supply voltages and frequencies or protected types are available

### **Typical Applications**

- Short pump-down cycles on large volumes
- Oil-free compression of high volume flows of gases and vapors against atmospheric pressure
- Single-stage (G) or in combination with RAV F as backing pump
- Operating pressures in the rough vacuum range
- CE approval
- Pre-admission silencer and filter for the cooling gas inlet as well as silencers for the exhaust side (option/single-stage)
- Downstream gas cooler (option/ multistage)
- C version (chemical version/option)
- Special materials (option)
- Pressure burst resistant version (option)



Dimensional drawing for the RUVAC RAV pumps



#### Technical Data, 50 Hz

# **RUVAC RAV**

		250 G	500 G	1000 G	2000 G	4000 G	8000 <b>G</b>
Pumping speed 1)	m³/h (cfm)	250 (147)	500 (295)	1000 (589)	2000 (1178)	3700 (2179)	8100 (4771)
Nominal speed	min <sup>-1</sup> (rpm)	3000 (3000)	3000 (3000)	3000 (3000)	3000 (3000)	1500 (1500)	1500 (1500)
Max. permissible pressure difference <sup>2)</sup>	mbar (Torr)	850 (637)					
Connecting flange	DN	80	100	100	150	250	300
Max. permissible motor power							
for direct drive	kW (hp)	11.0 (15.0)	18.5 (25.2)	30.0 (40.8)	55.0 (74.8)	95.0 (129.3)	200.0 (272.1)
for belt drive	kW (hp)	11.0 (15.0)	18.5 (25.2)	30.0 (40.8)	55.0 (74.8)	95.0 (129.3)	200.0 (272.1)
Weight	kg (lbs)	95 (210)	160 (353)	225 (496)	310 (684)	720 (1588)	1230 (2712)

#### **Ordering Information**

#### **RUVAC RAV**

	250 G	500 G	1000 G	2000 G	4000 G	8000 <b>G</b>
	Part No.					
Roots vacuum pump RUVAC RAV G	upon request					

Technical Data, 50 Hz	RUVAC RAV						
		250 F	500 F	1000 F	2000 F	4000 F	8000 F
Pumping speed 1)	m³/h (cfm)	250 (147)	500 (295)	1000 (589)	2000 (1178)	3700 (2179)	8100 (4771)
Nominal speed	min <sup>-1</sup> (rpm)	3000 (3000)	3000 (3000)	3000 (3000)	3000 (3000)	1500 (1500)	1500 (1500)
Max. permissible pressure difference <sup>2)</sup>	mbar (Torr)			850	(637)		
Connecting flange	DN	80	100	100	150	250	300
Max. permissible motor power for direct drive for belt drive	kW (hp) kW (hp)	11.0 (15.0) 4.0 (5.4)	18.5 (25.2) 4.0 (5.4)	30.0 (40.8) 7.5 (10.2)	55.0 (74.8) 15.0 (20.4)	95.0 (129.3) 37.0 (50.3)	200.0 (272.1) 75 (102.0)
Gear oil, approx.	l (qt)	0.9 (0.95)	1.1 (1.6)	1.5 (1.59)	2.5 (2.64)	12.0 (12.68)	11.0 (11.63)
Weight	kg (lbs)	95 (210)	160 (353)	225 (496)	310 (684)	720 (1588)	1230 (2712)
Cooling water connection, fitting for tube		-	-	-	-	10 x 1	10 x 1
Cooling water requirement, approx.	l x h-1	-	-	-	-	60	60

# **Ordering Information**

	250 F	500 F	1000 F	2000 F	4000 F	8000 F
	Part No.					
<b>-</b> .						

Roots vacuum pump RUVAC RAV F

upon request upon request upon request upon request upon request

**RUVAC RAV** 

<sup>1)</sup> To DIN 28 400 and following numbers

 $^{\scriptscriptstyle 2)}~$  RUVAC ~ RAV G and RAV F with direct drive



Pumping speed diagram of RUVAC RAV at 50 Hz

נ ٢ 0

# TVD Pump Systems for Drying, Evaporation and Distillation Applications



#### TVD 200

#### Advantages to the User

- Operating agent may be reused, for example by returning cleaned water to the process
- Reduction of the quantities which need to be disposed of by 80%
- Low temperature distillation/drying
- Condensate may be drained during vacuum operation
- CE approval

#### **Typical Applications**

- Drying of powders and solids, for example
- Cleaning of waste water
- Vacuum distillation

b<sub>1</sub>

#### **Standard Equipment**

- Condenser at the intake side
- Receiver with condensate level indicator
- Manually operated valves on the receiver
- SOGEVAC rotary vane vacuum pump with integrated exhaust filters, anti-suckback valve and gas ballast valve



- Valve between condenser and rotary vane vacuum pump
- Pressure gauge for checking the condensate pressure
- Solenoid valves at the receiver
- Receiver with proximity switch for monitoring the condensate level
- Electric control for automatic operation of the pump system
- Mobile pallet with castors
- Cold water replacement for mobile applications



Dimensional drawing for the TVD pump systems

# Technical Data, 50 Hz

# TVD 40 TVD 65 TVD 100 TVD 200

Condenser,					
effective surface area, approx.	m²	1	2	3	5
Receiver, usable volume	l (qt)	30.0 (31.71)	50.0 (52.85)	50.0 (52.85)	50.0 (52.85)
Rotary vane vacuum pump SOGEVAC		SV 40	SV 65	SV 100	SV 200
Nominal pumping speed	n³/h (cfm)	46.0 (27.1)	65.0 (38.3)	100.0 (58.9)	180.0 (106.0)
Pumping speed at 50 Hz for air n	n³/h (cfm)	46.0 (27.1)	53.0 (31.2)	94.0 (55.4)	170.0 (100.1)
for water vapor at 50 mbar (37.5 Torr) n	n³/h (cfm)	280.0 (165.0)	560.0 (330.0)	840.0 (495.0)	1400.0 (825.0)
Ultimate total pressure with standard gas ballast m	bar (Torr)	< 1.5 (< 1.1)	< 1.5 (< 1.1)	< 1.5 (< 1.1)	< 0.7 (< 0.53)
Noise level <sup>1)</sup>	dB(A)	63	64	70	69
Condensing capacity for water	l/h	10	20	30	50
Installed motor power 400 V, 50 Hz	kW (hp)	1.1 (1.5)	1.5 (2.0)	2.2 (3.0)	4.0 (4.2)

Technical Data, 50 Hz SV 40	SV 65 SV 1	00 SV 200
-----------------------------	------------	-----------

Weight (with oil filling), approx.	kg (lbs)	125 (276)	150 (331)	200 (441)	300 (662)
Oil filling	l (qt)	2.0 (2.11)	2.0 (2.11)	3.5 (3.70)	5.0 (5.29)
Connecting flanges					
Inlet port	DN <sub>1</sub>	63 ISO-K	63 ISO-K	100 ISO-K	100 ISO-K
Outlet port	DN <sub>2</sub>	1 1/4"	1 1/4"	2"	2"

Ordering Information	<b>TVD</b> 40	<b>TVD 65</b>	TVD 100	<b>TVD 200</b>

	Part No.	Part No.	Part No.	Part No.
Pump system	021 01	021 02	021 03	021 04

<sup>1)</sup> Operating at ultimate pressure with gas ballast

# Accessories for oil sealed and dry compressing Pump Systems

# Sound Proofing

A sound proofing box is available as an optional extra so as to reduce the noise down to the permissible level.

Depending on the size of the pumping system, noise reductions between 15 and 20 dB(A) are obtained using our standard sound proofing arrangements.

Custom designs of the sound proofing box allow the noise level to be reduced by up to 35 dB(A).



RUTA RA 3001/S630F/G with sound proofing box

The maintenance side is designed as a door component. A window insert may be provided in the door or in the side walls to facilitate checking of the oil levels.

Ventilation is performed by means of an electric fan, the fresh air and exhaust ducts are located within the sound proofing box. Further optional extras which may be fitted include closed air circulation with integrated, water-cooled heat exchanger and a connection port for a central exhaust system.

# **Isolation against Vibrations**

RUTA vacuum pump systems produce only slight vibrations. To reduce these vibrations even further, vibration absorbers can be fitted under the pump system.

### **Dust Separators**

Vacuum processes where large amounts of particles or dusts are contributed by the process require special devices to protect the vacuum pumps.

Leybold has developed – even for high flow rate applications – special dust separators, which can be installed ahead of the intake of the RUTA vacuum pump systems. The dust separators have two stages. The first stage is a cyclone that collects dust particles of coarse and medium size, the fine dust are trapped in filter elements. Dust separators are customdesigned for the specific process and the required pumping speed.

# **Dust Filter without Cyclone**

See further down in this chapter.



Diagrammatic section through a dust separator

Filtering surface	m <sup>2</sup>	0.2	0.5	1.0	2.0	3.0	5.0
suitable for pumping speed	ls						
min.	m³/h (cfm)	100 (58.9)	300 (176.7)	600 (353.4)	1000 (589)	1500 (883.5)	3000 (1767)
max.	m³/h (cfm)	300 (176.7)	800 (471.2)	1500 (883.5)	3000 (1767)	4000 (2356)	8000 (4712)
Reduction of pumping spe	ed at						
≤ 1 mbar (< 0.75 Torr)	%	11	11	11	11	11	11
≤ 6 mbar (< 4.5 Torr)	%	9	9	9	9	9	9
≤ 20 mbar (< 15 Torr)	%	5	5	5	5	5	5
without dust load		I					

without dust load

### Frequency converter RUVATRONIC RT 5

The electronic frequency inverters RUVATRONIC RT 5/251 to 5/16000 have been designed specially for use in connection with Leybold Roots pumps of the RUVAC type. For each Roots vacuum pump size, a matching frequency converter is available.

# The main characteristics of the RUVATRONIC RT 5 are:

#### Simulation of a pressure equalization line

The software of the frequency inverters is adapted to each pump and ensures that the risk of mechanically overloading the pump can be excluded. In the case of too high pressure differences, the rotational speed will be decreased automatically until the load is reduced to within the pump's limits.

RUVAC Roots vacuum pumps of the types WA, WS and RA (without pressure equalization line) can be switched on together with the forepump at atmospheric pressure. Through this, the pumpdown time can be reduced drastically.

The minimum pumping speed of the backing pump needs to be considered in this case.

Pump	Required pumping speed				
	for the backing pump				
WA/WS 251	50 m³/h ( 29 cfm)				
WA/WS 501	100 m³/h ( 59 cfm)				
WA/WS 1001	200 m³/h ( 118 cfm)				
WA/WS 2001	410 m³/h ( 241 cfm)				
RA 3001	650 m³/h ( 383 cfm)				
RA 5001	930 m³/h ( 547 cfm)				
RA 7001	1250 m³/h ( 736 cfm)				
RA 9001	3240 m³/h (1907 cfm)				

# Operation at up to 3 predefined speeds

Via floating contacts, the pump can be operated at one of the 3 predefined speeds. Switching over to another pre-defined speed is possible during operation.

#### Operation at any rotational speed

With a 0 to 10 V signal, any speed can be pre-defined to operate the pump between the minimum and maximum rotational speed. The software reliably ensures that the rotational speed cannot drop below the minimum speed or exceed the maximum speed.

#### Increase in the pumping speed

By operating the Roots vacuum pumps at frequencies over 50 Hz, the nominal pumping speed of the pumps can be increased. Depending on the type of pump, an increase between 20 and 100% is possible.

#### Note

Please enquire about possible application limitations (process dependent).

#### **Electric Controller**

In order to drive all electrical appliances within the pump systems, the pump systems may be equipped with standard control cabinets which contain:

- Motor protection switch (rated for the pumps used in each case)
- Contactors
- Main switch interlocked in accordance with VDE 0113
- Relays for necessary control/ sub-systems
- ON/OFF push-button for each pump
- Power supply for the installed monitoring facilities
- Fault indicators arranged on a lamp panel
- Switch-over (through an external contact) from local to remote operation.

The control cabinet may be fitted either to the frame of the pump system or it may be wallmounted.

Beside the standard systems, we manufacture control systems for much more complex systems:

- Remote control module as a 19" rack module (1/4 width, 3 HU). The start/stop push-buttons and the related indicators for operation and fault are located on the front panel
- Pre- and post-operation control
- Pressure dependent control
- Time-dependent control
- Program control
- Control for explosion hazard areas
- Combinations of the aforementioned versions
- Programmable control (PC)
- Vacuum gauge with pressure readout in the control cabinet.

#### **Pressure Control**

Basically there are several ways in which to control the pressure.

The equipment which is supplied as standard for the **DOWNSTREAM** or **BYPASS** control systems selected by Leybold consists of:

- Pressure measurement
- Controller with control unit
- Control valve with position indicator
- Engineering.

The **Downstream Control System** throttles the pumping speed of the vacuum pump by changing the conductance of the valve. The advantages offered by this arrangement are:

- No supply of other gases
- Closed system
- The intake pressure of the pump system is lower than its operating pressure (thus saving energy, among other things).

The second method is the **Bypass Control System**. Here the pressure is maintained at a constant level by admitting an additional quantity of gas.

The advantages offered by this arrangement are:

- Simple design
- Much smaller valve
- No reduction of the intermediate pressure within the pump.

In order to design a pressure control system we need the following information:

- Amount of gas
- Type of gas
- Pressure
- Length of the piping
- Type of auxiliary energy (electric/ pneumatic)
- Explosion protection required yes/no.

Additional complex control arrangements are available, for example with:

- Adjustable pressure characteristic
- Adjustable timing
- Speed control
- Combination with other control facilities.



Control panel on RUTA WAU1001/SV200/G

leybold

# Dust Filter F-xxx-C

The highly efficient dust filters F-xxx-C are fitted to the inlet of the RUVAC pumps. The filter protects the Roots vacuum pumps against the intake of dust.

The dust filters are equipped with an easy to replace filter element. In the case of the filters F-1001-C or larger, the gas enters into the housing above the filter element. Thus the likelihood of puncturing the filter is reduced.

In the case of the dust filter F-501-C, the filter element is protected by a baffle.

All vacuum dust filters are rated for pressures up to 1200 mbar (900 Torr) abs. max.



components

<sup>2)</sup> The hole pattern corresponds to PN 10

Dimensional drawing for the dust filters F-xxx-C

#### **Technical Data**

### **Dust Filter F-xxx-C**

		Polyester filter cartridge	Paper filter cartridge			
Separation at 10 µm	%	> 99,9	_			
Separation at 5 µm	%	> 99,0	> 99,9			
Separation at 2 µm	%	-	> 99,0			
Temperature	°C (°F)	-25 to +100 (-13 to +212)				
Dust Filter for WA/WS/WAU/WSU 501 WA/WS/WAU/WSU 1001, WH 700 WA/WS/WAU/WSU 2001, WH 2500 RA 3001, RA 5001, WH 4400, WH 7000 RA 7001 RA 9001		F-50 F-10 F-2001-C / F F-50 F-70 F-90 F-90	01-C 01-C -2001-C plus 01-C 01-C 01-C			
RA 13000		F-130	001-C			

Technical Data		Dust Filter						
		F-501-C	F-1001-C	F-2001-C	F-2001-C plus			
Surface area, approx.								
Polyester	m²	0.4	1.0	1.5	2.6			
Paper	m²	1.3	3.0	4.0	6.3			
Weight, approx.	kg (lbs)	7.0 (15.45)	29.0 (64.02)	50.0 (110.38)	51.0 (112.58)			

Technical Data		Dust Filter				
		F-5001-C	F-7001-C	F-9001-C	F-13001-C	
Surface area, approx.						
Polyester	m²	4.5	9.0	9.0	14.0	
Paper	m²	11.5	26.0	26.0	37.0	
Weight, approx.	kg (lbs)	83.0 (138.22)	171.0 (377.48)	171.0 (377.48)	209.0 (461.37)	

#### **Ordering Information**

# **Dust Filter F-xxx-C**

	Part No.	Part No.
Dust Filter	Polyester filter element	Paper filter element
F-501-C	500 001 403	500 001 404
Replacement filter element FE-501-C	500 005 629	500 005 630
F-1001-C	500 000 301	500 000 302
Replacement filter element FE-1001-C	500 000 313	500 000 314
F-2001-C	500 000 303	500 000 304
Replacement filter element FE-2001-C	500 000 315	500 000 316
F-2001-C plus <sup>1)</sup>	500 001 367	500 001 368
Replacement filter element FE-2001-C plus	500 000 631	500 000 632
F-5001-C	500 000 305	500 000 306
Replacement filter element FE-5001-C	500 000 317	500 000 318
F-7001-C	500 000 307	500 000 308
Replacement filter element FE-7001/9001-C	500 000 319	500 000 320
		(2 pieces are required)
F-9001-C	500 000 309	500 000 310
Replacement filter element FE-7001/9001-C	500 000 319	500 000 320
		(2 pieces are required)
F-13001-C	500 000 311	500 000 312
Replacement filter element FE-13001-C	500 000 321	500 000 322
	(2 pieces are required)	(2 pieces are required)

<sup>1)</sup> For increased quantities of dust

# **Bellows with Vibration Absorbers**



The bellows serve the purpose of connecting pipes to vacuum pumps without introducing any mechanical tensions.

Bellows with vibration absorbers

#### **Technical Data**

#### **Bellows with Vibration Absorbers**

		KIT DN 63 ISO-K	KIT DN 100 ISO-K	KIT DN 160 ISO-K
Length	mm (in.)	132 (5.20)	132 (5.20)	150 (5.91)
Lateral movement, max.	mm (in.)	7.5 (0.30)	9.5 (0.37)	3.5 (0.14)
Axial movement, max.	mm (in.)	20 (0.79)	28 (1.10)	22 (0.87)

### **Ordering Information**

#### **Bellows with Vibration Absorbers**

#### KIT DN 63 ISO-K KIT DN 100 ISO-K KIT DN 160 ISO-K

		Part No.	Part No.	Part No.
Bellows with Vibration Absorbers		503 189 V001	503 189 V002	503 189 V003
consisting of				
Bellows	Quantity	1	1	1
Centering ring	Quantity	2	2	2
Clamp (set of 4 pieces)	Quantity	2	2	2
Support bracket	Quantity	4	8	8
Rubber/metal absorber	Quantity	2	4	4
Hexagon nut M 12	Quantity	12	24	24
Threaded rod M 12				
105 mm long	Quantity	4	8	8
Washer	Quantity	12	24	24

### **Technical Data**

### **Bellows with Vibration Absorbers**

		KIT DN 200 ISO-K	<b>KIT DN 250 ISO-K</b>	KIT DN 320 ISO-K
Length	mm (in.)	150 (5.91)	200 (7.87)	250 (9.84)
Lateral movement, max.	mm (in.)	3.5 (0.14)	4.5 (0.18)	4.5 (0.18)
Axial movement, max.	mm (in.)	20 (0.79)	30 (1.18)	50 (1.97)

#### **Ordering Information**

#### **Bellows with Vibration Absorbers**

#### KIT DN 200 ISO-K KIT DN 250 ISO-K KIT DN 320 ISO-K

		Part No.	Part No.	Part No.
Bellows with Vibration Absorbers		503 189 V004	503 189 V005	503 189 V006
consisting of				
Bellows	Quantity	1	1	1
Centering ring	Quantity	2	2	2
Clamp (set of 4 pieces)	Quantity	3	3	4
Support bracket	Quantity	12	12	16
Rubber/metal absorber	Quantity	6	6	8
Hexagon nut M 12	Quantity	36	36	48
Threaded rod M 12	-			
90 mm long	Quantity	12	12	_
105 mm long	Quantity	-	-	16
Washer	Quantity	36	36	48

# Bus Interfaces for Monitoring



Wi-Fi and Profibus interface kit for SP-GUARD

#### Advantages to the User

- Interface box for assembly on screw pump SCREWLINE SP 250 and SP 630
- Read out of vibration levels, oil temperatures, warning and failure functions
- The interface box is mounted next to the SP-GUARD

#### **Ordering Information**

 Interface box needs a 24 V DC supply on-site (24 V DC supply of the SP-GUARD can be used)

#### **Available Interfaces**

- Profibus
- Wi-Fi

Bus interfaces for remote reading of the SP-GUARD monitoring system for the screw pumps SCREWLINE SP 250 and SP 630. Item can be ordered as retrofit kit or together with the pump unit.

#### Further interfaces upon request:

- Profinet
- DeviceNet
- Ethernet
- CAN bus
- Interbus
- etc.

# Interface Kit SP-GUARD

	Part No.
Interface kit SP-GUARD Profibus	502 898 V001
Profibus interface kit and Wi-Fi for SP-GUARD	upon request
SCREWLINE SP 630 screw pump with Profibus interface	502 899 V001
Further combinations	upon request



Various indications on the mobile equipment



Profibus interface kit for SP-GUARD



Smart phone / tablet PC for readout (Wi-Fi)

# Miscellaneous to oil sealed and dry compressing Pump Systems

# **Checklist for Inquiries**

### To Leybold GmbH

From company: \_

Dept. Systems Fax: +49 (0)221/347 - 31206 e-Mail: vacuum.solutions@leybold.com Name/Department: \_\_\_\_

Phone: \_\_\_\_

Fax: \_\_\_\_

Date: \_\_\_

First page of: \_\_\_\_

# MAKE USE OF OUR KNOW-HOW !

Simply fax the completed checklist to us. Our engineers will design a pump system which exactly matches your requirements. You will receive an offer shortly.

In what kind of application will the pump system be used (e.g. drying, distillation)?	6. How high is the ambient temperature? - when installed in the building: min°C / max°C - when installed out in the open	<ul> <li>d) Viscosity</li> <li>e) Melting point</li> <li>f) Special characteristics</li> <li>f) Must explosion hazard</li> </ul>
<ul> <li>Is the process run</li> <li>continuously in batches:</li> </ul>	How high is the intake temperature?	if yes, which?
<b>3.</b> What is the volume of the vacuum chamber?	8. What is the composition of the gas which is to be pumped.         Designation:         a)b)         c)d)         e)f)	<ul> <li>12. What kind of electrical supplies are available?</li> <li>a) Voltage</li> <li>b) Frequency</li> <li>13. What kind of mechanical</li> </ul>
What pump-down times are required/desired?	Quantity (kg/h or Nm³/h), traces (%):           a)b)           c)d)	connection specifications are planned? a) Length of the intake line b) Diameter of the intake line
<b>5.</b> What operating pressures are planned? mbar	<ul> <li>e) f)</li> <li><b>10.</b> In case of materials not commonly listed in the tables please state:</li> </ul>	<b>14.</b> Which cooling media are available (water, brine, etc.)? Which temperature?
	a) Molecular mass b) Thermal capacity c) Vapor pressure	min°C max°C

# General to High Vacuum Pump Systems TMP

The requirements of production or research engineers concerning the vacuum technology they have to employ are usually widely different. In most cases pumping speed and operating pressure must be accurately matched to suit a particular process. The wide range of vacuum pumps and standard accessories available offers many options. Sometimes it is just this flexibility which causes difficulties when having to decide between the various configurations of a particular pump system. Based on our experience and by listening to our customers' demands, we have therefore compiled a range of turn-key vacuum systems based on standard components. Before leaving the factory they are subjected to both functional tests and leak tests. By adding components from our standard range or special of accessories they may be easily adapted to meet specific requirements.

# **Application and Accessories**

PUTTS HEARTS	/<	JABO	ABO	1AB 25	AR 350 AR
Application					
Microbalances					
Sputtering					
Spectroscopy					
Production of TV and monitor picture tubes					
Surface refining					
Evaporation coating systems					
Beam guidance systems					
Laboratory pump systems					

#### Accessories

Control unit for turbomolecular pump systems		
Air cooling unit		
Flange heater		
Venting valve		
Power failure venting valve		
Purge gas and venting valve		
Water cooling unit		

Possible

# **Products** Dry Pump Systems

# Turbomolecular Pump Systems TURBOLAB 90 i, 250 i, 350 i, 450 i



Turbomolecular pump system TURBOLAB 350 i (top left), TURBOLAB 90 i (down left) and TURBOLAB 350 i Cart (right)

# **Basic Equipment**

#### Turbomolecular pump

TURBOVAC i models from 90 l/s to 450 l/s including frequency converter

#### Backing pump

Dry or oil-sealed, 1 m<sup>3</sup>/h - 20 m<sup>3</sup>/h, 24 V DC/110-230 V

#### Backlight display

Every TURBOLAB comes with the Turbo Pressure Unit TPU for control, configuration and monitoring of the pump system

#### Built-in support for accessories

- Purge
- Vent
- Air or water cooling unit
- Flange heaters
- Two pressure gauges (1000 mbar to 1 x 10<sup>-9</sup> mbar)
- Foreline safety valve

#### Built-in webserver

- Condition monitoring
- Data analysis
- Software updates

- Control, monitor and configure your TURBOLAB system

#### Easily relocate pump

away from the frame and on your chamber

#### Remote control

via the X1 Interface

- Configurable X1 Digital/Analog I/O
- Start/Stop
- Error
- Warning
- Analog Output

#### Advantage to the User

- Enhanced pump performance
- Compact mobile design
- Small foot print
- Easy to relocate pumps out and

This new smart TURBOLAB generation is built on one basic design platform with the opportunity to create two different variants (Tabletop or Cart-System).

Each version can be customized to individual needs regarding add-ons like vacuum measurement devices, a choice of accessories, e.g. valves and heaters.

away from the frame

- Backlight display (control/monitoring/configuration)
- Monitored data like frequency, temperature, current, pressure are automatically stored to a data log file in the TURBOLAB. Users easily view the log file with the TURBOLAB data viewer software tool which can be downloaded for free from the Leybold website or the last 512 data points can be viewed from the TURBOLAB data viewer in the web server
- Covering more applications with a full range of high vacuum and dry or wet forevacuum pumps to cover more high vacuum applications
- Benchmark turbostation offering dedicated ports for the connection of
  - six different accessories
  - two gauges
- Benchmark functionality, reliability and design
- Prepared for worldwide voltage coverage
- Price-to-performance ratio

# **Typical Applications**

- Analytical Instruments
- Spectroscopy
- Tube manufacturing
- Beam guidance systems
- Micro balances
- Sputtering and evaporation systems
- Surface physics
- Laboratory pump systems

#### Options

- Alternatively ISO-K or CF connection
- The Cart version comprises a baseplate, mounting column, castors or a benchtop frame with rubber feet
- Relocation kits available to relocate the pumps away from the frame and onto your chamber

# The pump system can be upgraded with further components:

- Vacuum gauges: TTR 91 (N), TTR 101 (N), PTR 91 (N).
   Simultaneous operation of two gauges is possible
- Adsorption trap
- Exhaust filter
- Air cooling unit
- Water cooling unit
- Flange heater
- Venting valve
- Purge gas valve
- Foreline venting valve
- Vacuum safety valve SECUVAC DN 15/25/40 ISO-KF

#### Scope of delivery

- Transport lock at the high vacuum flange by way of a Plexiglas disc
- Covering caps for the threads of the transport lock
- Exhaust side: centering ring and clamping ring
- Documentation
- The TRIVAC and SOGEVAC are filled with LVO oil





Schematic diagram of the turbomolecular pump systems TURBOLAB (left basic version, right equipment with accessories (TPU not shown)



Dimensional drawing TURBOLAB 90 i, dimensions in mm



Dimensional drawing TURBOLAB 90 i Cart, dimensions in mm



Dimensional drawing TURBOLAB 250 i, dimensions in mm



Dimensional drawing TURBOLAB 250 i Cart, dimensions in mm

Vacuum Pump Systems



Dimensional drawing TURBOLAB 350 i / 450 i, dimensions in mm



Dimensional drawing TURBOLAB  $\,$  350 i / 450 i Cart, dimensions in mm



Maximum rise in pressure

Technical Data	TURBOLAB								
Pump system		90 i		250 i		350 i		450 i	
Inlet flange	DN	63 ISO-K	63 CF	100 ISO-K	100 CF	100 ISO-K	100 CF	160 ISO-K	160 CF
Forevacuum connection	DN	16 ISO-KF		16 ISO-KF		25 ISO-KF		25 ISO-KF	
Pumping speed	l/s	90		225		290		430	
Ultimate pressure	mbar	< 8 x 10 <sup>-8</sup>	< 5 x10 <sup>-10</sup>	< 8 x 10 <sup>-8</sup>	< 5 x10 <sup>-10</sup>	< 8 x 10 <sup>-8</sup>	< 5 x10 <sup>-10</sup>	< 8 x 10 <sup>-8</sup>	< 5 x10 <sup>-10</sup>
Mains Supply 50/60 Hz	V AC	110 ± 10% / 230 ± 10%							
Power consumption, max.	VA	1760 / 3680							
Weight (ISO-KF / CF)	kg								
Table top unit		20		20		35		35	
Cart		100		100		110		110	
Number of accessories, max.		6		6		6		6	
Number of gauges, max.		2		2		2		2	
СВМ		Internal condition monitoring							
Software		Internal webserver (no software to install)							

#### Technical Data Backing pumps

Diaphragm vacuum pump	DIVAC	3.0			
Pumping speed	m³/h	3.0			
Exhaust connection	DN	Silencer			
Noise level	dB(A)	54			
Scroll vacuum pump SCR	ROLLVAC	SC 7 plus	SC 15 plus		
Pumping speed	m³/h	6.1	14.5		
Exhaust connection	DN	25 KF	25 KF		
Noise level	dB(A)	55	55		
Rotary vane vacuum pump	TRIVAC	D 4 B	D 8 B		
Pumping speed	m³/h	4.8	9.7		
Exhaust connection	DN	16 ISO-KF	16 ISO-KF		
Noise level	dB(A)	52	52		
Rotary vane vacuum pump	SOGEVAC	SV 16 D			
Pumping speed	m³/h	16.0			
Exhaust connection	DN	1/2"			
Noise level	dB(A)	59			

#### **TURBOLAB 90 i**

	Part. No.	Part. No.	
Pump system with TURBOVAC 90 i	230 V, 50/60 Hz	110 V, 50/60 Hz	
Table top unit with DIVAC 3.0 DN 63 ISO-K DN 63 CF	501592V0 501592V0	00001000 01001000	
Cart with SCROLLVAC SC 7 plus DN 63 ISO-K DN 63 CF	501592V00021000 501592V01021000		
Cart with SCROLLVAC SC 15 plus DN 63 ISO-K DN 63 CF	501592V00041000 501592V01041000		
Cart with TRIVAC D 4 B DN 63 ISO-K DN 63 CF	501592V00120000 501592V01120000	501592V00080000 501592V01080000	
Cart with TRIVAC D 8 B DN 63 ISO-K DN 63 CF	501592V00130000 501592V01130000	501592V00090000 501592V01090000	
Cart with SOGEVAC SV 16 D DN 63 ISO-K DN 63 CF	501592V00100000 501592V01100000		
Table top unit without Forevacuum pump DN 63 ISO-K DN 63 CF	501592V0 501592V0	00200000 01200000	
Cart without Forevacuum pump DN 63 ISO-K DN 63 CF	501592V0 501592V0	00210000 01210000	

#### **TURBOLAB 250 i**

	Part. No.	Part. No.	
Pump system with TURBOVAC 250 i	230 V, 50/60 Hz	110 V, 50/60 Hz	
Table top unit with			
DIVAC 3.0			
DN 100 ISO-K	501592V0	8001000	
DN 100 CF	501592V09001000		
Cart with			
SCROLLVAC SC 7 plus			
DN 100 ISO-K	501592V08021000		
DN 100 CF	501592V09021000		
Cart with			
SCROLLVAC SC 15 plus			
DN 100 ISO-K	501592V08041000		
DN 100 CF	501592V09041000		
Cart with			
TRIVAC D 4 B			
DN 100 ISO-K	501592V08120000	501592V08080000	
DN 100 CF	501592V09120000	501592V09080000	
Cart with			
TRIVAC D 8 B			
DN 100 ISO-K	501592V08130000	501592V08090000	
DN 100 CF	501592V09130000	501592V09090000	
Cart with			
SOGEVAC SV 16 D			
DN 100 ISO-K	501592V08100000		
DN 63 CF	501592V09100000		
Table top unit without			
Forevacuum pump			
DN 100 ISO-K	501592V08200000		
DN 100 CF	501592V09200000		
Cart without			
Forevacuum pump			
DN 100 ISO-K	501592V08210000		
DN 100 CF	501592V09210000		

#### TURBOLAB 350 i

	Part. No.	Part. No.	
Pump system with TURBOVAC 350 i	230 V, 50/60 Hz	110 V, 50/60 Hz	
Table top unit with DIVAC 3.0 DN 100 ISO-K DN 100 CF	501592V0 501592V0	4001000 5001000	
Cart with SCROLLVAC SC 7 plus DN 100 ISO-K DN 100 CF	501592V04021000 501592V05021000		
Cart with SCROLLVAC SC 15 plus DN 100 ISO-K DN 100 CF	501592V04041000 501592V05041000		
Cart with TRIVAC D 4 B DN 100 ISO-K DN 100 CF	501592V04120000 501592V05120000	501592V04080000 501592V05080000	
Cart with TRIVAC D 8 B DN 100 ISO-K DN 100 CF	501592V04130000 501592V05130000	501592V04090000 501592V05090000	
Cart with SOGEVAC SV 16 D DN 100 ISO-K DN 100 CF	501592V04100000 501592V05100000		
Table top unit without Forevacuum pump DN 100 ISO-K DN 100 CF	501592V0 501592V0	4200000 5200000	
Cart without Forevacuum pump DN 100 ISO-K DN 100 CF	501592V0 501592V0	4210000 5210000	
### **Ordering Information**

### TURBOLAB 450 i

	Part. No.	Part. No.
Pump system with TURBOVAC 450 i	230 V, 50/60 Hz	110 V, 50/60 Hz
Table top unit with		
DIVAC 3.0		
DN 160 ISO-K	501592V0	6001000
DN 160 CF	501592V0	7001000
Cart with		
SCROLLVAC SC 7 plus		
DN 160 ISO-K	501592V0	6021000
DN 160 CF	501592V0	7021000
Cart with		
SCROLLVAC SC 15 plus		
DN 160 ISO-K	501592V0	6041000
DN 160 CF	501592V0	7041000
Cart with		
TRIVAC D4B		
DN 160 ISO-K	501592V06120000	501592V0608000
UN 160 CF	501592V07120000	501592V07080000
Cart with		
TRIVAC D 8 B		
DN 160 ISO-K	501592V06130000	501592V06090000
DN 160 CF	501592V07130000	501592V07090000
Cart with		
SOGEVAC SV 16 D		
DN 160 ISO-K	501592V0	6100000
DN 160 CF	501592V0	7100000
Table top unit without		
Forevacuum pump		
DN 160 ISO-K	501592V0	6200000
DN 160 CF	501592V0	7200000
Cart without		
Forevacuum pump		
DN 160 ISO-K	501592V0	6210000
DN 160 CF	501592V0	7210000

### **Ordering Information**

#### TURBOLAB 90 i TURBOLAB 250 i TURBOLAB 350 i / 450 i

			4501
	Part. No.	Part. No.	Part. No.
Accessories			
Mains cable TURBOLAB			
230 V, 5.0 m		800103V0030	
110 V, 5.0 m		800103V0031	
230 V, UK, 5.0 m		800103V0037	
Accessory cable TURBOVAC i			
(air cooling & valve connection)			
M 8 - M 8, 0.3 m		800103V0001	
M 8 - M 8, 2.0 m		800110V0016	
Y cable TURBOVAC i, M 8		800110V0020	
Start stop switch			
for connection to X1 Remote		800110V0021	
USB cable 2.0, Type A/B, 1.8 m		800110V0108	
Accessory cable TURBOLAB			
M 8 - M 8, 0.3 m (air cooling & valve connection)		800103V0001	
M 8 - M 8, 5.0 m (air cooling & valve connection) M 12 M 12 5 0 m (DIVAC 0.8 2.0)		80010300003	
M 12 - M 12, 5.0 m (DIVAC 0.8, 5.0) C13 - C14 5.0 m (SOGEVAC)		800103V0005 800103V0017	
C14 - NEMA, 5.0 m (SCBOLLVAC)		800103V0008	
C14 - Schuko, 5.0 m (SCROLLVAC 230 V)		800103V0011	
C14 - C16-1 (230 V), 5.0 m (TRIVAC 230 V)		800103V0014	
C14 - C16-1 (110 V), 5.0 m (TRIVAC 110 V)		800103V0016	
Accessory cable TURBOLAB			
TURBOVAC i, 5.0 m (24 V DC voltage supply)		800103V0020	
Communication TURBOLAB – TMP			
5.0 m		800103V0029	
1.0 m		80010300027	
Connection cable Type A		8004021/0020	
5.0 m		12426	
Connection cable C14 – valve plug 1.8 m		12420	
(Control 110/230 V AC SECUVAC valve)		800103V0033	
Connection cable C14 – valve plug, 5 m			
(Control 110/230 V AC SECUVAC valve)		800103V0035	
Connection cable C14 – valve plug, 1.8 m			
(Control 24 V DC SECUVAC valve)		800103V0034	
Connection cable C14 – valve plug, 5 m			
		80010300036	
		230439V01	
Air cooling TURBOVAC 90 i radial	800136V0007	•	-
Air cooling TURBOVAC 200 i / 250 i radial	-	800136V0009	-
Air cooling TURBOVAC 350 i / 450 i radial	-	-	800136V0005
water cooling TURBOVAC 35017 4501 with G 1/8" connections	-	_	800135V0005
Water cooling TURBOVAC 350 i / 450 i			
with G 1/8" connections	-	-	800135V0006

### **Ordering Information**

### TURBOLAB 90 i / 250 i / 350 i / 450 i

	Part. No.
Accessories	
Venting valve 24 V DC, G 1/8"	800120V0012
Power failure venting valve 24 V DC, G 1/8"	800120V0022
Purge gas valve 24 V DC, G 1/8", 24 sccm	800120V0013
Purge gas throttle G 1/8", 24 sccm	800120V0014
Air filter for TMP G 1/8"	800110V0022
Flange heater DN 63 CF, 230 V	800137V0003
DN 63 CF, 115 V	800137V0004
DN 100 CF, 230 V	800137V0005
DN 100 CF, 115 V	800137700006
DN 160 CF, 230 V DN 160 CF, 115 V	800137V0007 800137V0008
Vibration absorber	00010740000
DN 63 ISO-K	upon request
DN 63 CF	upon request
DN 100 ISO-K	800131V1100
DN 160 CE	upon request
Centering ring	upon request
with protection screen	
DN 63 ISO-K	800133V0011
DN 100 ISO-K	800133V0021
DN 160 ISO-K	800133V0031
Centering ring	
with splinter guard	
DN 63 ISO-K	800133V0012
DN 100 ISO-K	800133V0022
DN 160 ISO-K	80013300032
Splinter guard	0001001/0010
DN 63 CF	800132V0012
DN 100 ISO-K (coarse)	80013270101
DN 100 CF (0.8 mm)	800132V0022
DN 160 CF (0,8 mm.	800132V0032
Protection screen	
DN 63 CF	800132V0011
DN 100 CF (3.2 mm)	800132V0021
DN 160 CF (3.2 mm)	800132V0031

## Accessories for High Vacuum Pump Systems TMP

## Adsorption Traps with Aluminium Oxide Insert



Adsorption traps are installed in all those cases where an oil-free vacuum is to be produced with oilsealed vacuum pumps.

Adsorption trap (left) and insert (right)

### Advantages to the User

- Backstreaming of oil is reduced \_ by 99%
- Long service life
- High conductance \_
- Filling can be easily exchanged
- Improvement in the ultimate pres-\_ sure attained by backing pumps by one order of magnitude
- Stainless steel housing and insert \_
- NBR gasket

### **Typical Applications**

- Product of an oil-free vacuum

### **Supplied Equipment**

- Complete with insert
- Without adsorbent



Residual gas spectrum; top ahead of a rotary vacuum pump, bottom ahead of a rotary vacuum pump with adsorption trap

### **Technical Data**



Dimensional drawing for the adsorption traps

### **Adsorption Traps**

		16 ISO-KF	25 ISO-KF	40 ISO-KF
Conductance at 10 <sup>-2</sup> mbar (Torr)	l/s	4	6	12
Service live with AI oxide	Months	3		
Al oxide filling	l (qts)	0.5 (0.53)	1.0 (1.06)	2.0 (2.1)
Weight, approx.	kg (lbs)	1.3 (2.9)	1.3 (2.9)	4.0 (8.8)

### **Ordering Information**

### **Adsorption Traps**

### 16 ISO-KF 25 ISO-KF 40 ISO-KF Adsorption trap Activated aluminum oxide in ti

1.6 l (approx. 1.2 kg (2.65 lbs))

	Part No.	Part No.	Part No.
	854 14	854 15	854 16
in			
)		854 10	

### **UNIVEX High Vacuum Experimentation Systems**

### General

The UNIVEX system family was developed by Leybold for applications in research and development as well as for setting up pilot production units.

Their range of applications focuses chiefly on vacuum coating technology as well as vacuum process engineering experiments.

The multi-purpose experimentation systems from Leybold are modular and can be specified according to specific customer requirements. For this purpose, a corresponding questionnaire is provided on the last pages of this chapter.





## Contents

General
Contents
Systems
Box Coating Systems
Glove Box Systems
Cluster-Tool Systems
Dactyloscopy Systems
Space Simulation Systems
Process Accessories
Thermal Evaporation of High Melting Point Materials (metals)
Thermal Evaporation of Low Melting Point Materials (organic)
Electron Beam Evaporation
Sputtering
lon Sources
Process Gas Inlet
Film Thickness Measurement
Substrate Rotation
Planetary Drives
Heating, Cooling, Tempering, Bias
Load Lock Systems
General Accessories
Blank-Off Screw Fitting
Low Pressure Safety Switch
Overpressure Safety Valve
Vacuum Feedthrough
Pneumatically Actuated Swivelling Shutter
UNIVEX Questionnaire

### **Systems**

# Box Coating Systems

### Multi-purpose Vacuum Coating System for the Laboratory

#### Design

- Compact unit with direct access to the process chamber
- The UNIVEX box coaters systems consist of a process and a control module
- The process module includes the vacuum chamber, the coating components and the pump system
- The control module includes the PLC, respectively PC controller including the visualisation as well as the power supplies for the process components

### Vacuum Chamber

- Box-shaped stainless steel vacuum chambers UNIVEX 250-600
- Octagonal stainless steel vacuum chamber UNIVEX 900
- Hinged front door for simple chamber access
- Viewing window with coating protection
- Removable stainless steel coating protection panels
- Flexible connections for chamber bottom and chamber top
- Connecting flanges for pump system and process components
- Coolable and heatable chamber walls optional

#### Vacuum System

- Mechanical forevacuum pump (dry compressing or oil sealed)
- High vacuum pump (turbomolecular or cryo pump)
- Vacuum valves
- Pressure measurement devices

#### Advantages to the User

- Modular system design
- Application-wise optimised pump system
- Multi-purpose vacuum chamber
- Convenient access to the chamber installations
- Very simple to operate and use via programmable control
- Suited for retrofitting of process components (configuration dependent)
- For installation into clean-room walls

### Basic Models

### **UNIVEX 250**



### **UNIVEX 400**



#### **UNIVEX 600**



#### **UNIVEX 900**



## UNIVEX 250



The UNIVEX 250 is a cost-effective and compact entry-level coating system for the laboratory.

Owing to its low height of only approximately 1.2 meters it is ideally placed on a benchtop or installed in a frame. In the vacuum chamber which is 270 mm wide, substrates up to an overall diameter of 220 mm max. can be rotated and coated.

The integrated PLC controller allows you to run manual, respectively semiautomatic coating processes.

Design example UNIVEX 250

### Examples of equipped vacuum chambers





Electron beam evaporator with fourfold rotating crucible as well as additional double thermal evaporator, each with source shutter



Effusion cell as well as spare blank flanges for subsequent retrofits

Chamber bottom: double thermal evaporator with source shutter Chamber top:

rotating substrate table with substrate shutter

### **Technical Data**

### **UNIVEX 250**

Vacuum chamber	
Material	
Chamber body	Stainless steel
Chamber door	Aluminum
Dimensions	
Inside width mn	270
Inside depth mn	370
HInside height mn	400
Connections <sup>1)</sup>	
Front side	Door with window
Rear side DN	1 x 160 ISO-K (pump system connection), 2 x 16 ISO-KF, 1 x 25 ISO-KF, 2 x 40 ISO-KF
Bottom plate	Variable connections
Cover plate	Variable connections
High vacuum pump <sup>1)</sup>	TURBOVAC 350 i
Nominal pumping speed for N <sub>2</sub>	290
Backing pump 1)	SOGEVAC SV 10 B
Nominal pumping speed m <sup>3</sup> /I	n 11
Controller	PLC with graphic touchscreen
Required supplies	
Voltage	400 V, 3 phases / N / 50 Hz 2)
Cooling water	
Inlet pressure bar (abs.	4 to 6
Consumption, approx. I/min	Dependent on chamber installations
Feed temperature °C	+18 to +25
Compressed air bar (abs.	4 to 6
Weight, approx. kg	300 <sup>3)</sup>

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

<sup>2)</sup> Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### **UNIVEX 250**

Part No.

upon request

#### UNIVEX 250





Dimensional drawing for the UNIVEX 250

### UNIVEX 400



Design example UNIVEX 400

The UNIVEX 400 is a compact coating system for laboratory tasks, respectively pilot production runs.

Due to its chamber dimensions, it is ideal for coating of small to medium-sized substrates.

In the vacuum chamber which is 420 mm wide, substrates respectively substrate holders up to an overall diameter of 350 mm max. can be rotated and coated.

The integrated PC/PLC controller allows you to run manual, semiautomatic and fully automatic coating processes.



UNIVEX 400 with loadlock

### Examples of equipped vacuum chambers



Two magnetron sputter sources, confocal aligned to the substrate holder rotating at the chamber top. Spare flanges for two further sputter sources



At the foreground: two double thermal evaporators with source shutters In the background: two organics evaporators with source shutters and two film thickness gauge heads

154



### **Technical Data**

### **UNIVEX 400**

Vacuum chamber		Water-cooled
Material		
Chamber body		Stainless steel
Chamber door		Stainless steel
Dimensions		
Inside width	mm	420
Inside depth	mm	480
HInside height	mm	550
Connections <sup>1)</sup>		
Front side		Door with window
Rear side	DN	1x 200 ISO-K (pump system connection), 2 x 16 ISO-KF, 2 x 40 ISO-KF, 2 x 40 ISO-KF
Bottom plate		Variable connections
Cover plate		Variable connections
High vacuum pump 1)		TURBOVAC 450 i
Nominal pumping speed for $N_2$	l/s	430
Backing pump 1)		SOGEVAC SV 25 B
Nominal pumping speed	m³/h	26
Controller		PLC with graphic touchscreen
Required supplies		
Voltage		400 V, 3 phases / N / PE / 50 Hz $^{2)}$
Cooling water		
Inlet pressure	bar (abs.)	4 to 6
Consumption, approx.	l/min	Dependent on chamber installations
Feed temperature	°C	+18 to +25
Compressed air	bar (abs.)	4 to 6
Weight, approx.	kg	500 3)

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

<sup>2)</sup> Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### **UNIVEX 400**

UNIVEX 400





Vacuum Pump Systems

Part No. upon request

1100

## UNIVEX 600



The UNIVEX 600 is a compact coating system for the laboratory, respectively pilot production runs. Because of its chamber size it is suited for medium to large substrate sizes. The attainable substrate throughput meets the general requirements for small series production runs. In the vacuum chamber which is 600 mm wide, substrates respectively substrate holders up to an overall diameter of 550 mm max. can be rotated and coated.

The integrated PC/PLC controller allows you to run manual, semiautomatic and fully automatic coating processes.

Design example UNIVEX 600

### Examples of equipped vacuum chambers







Chamber bottom: rotating substrate table with four heating stations

Chamber top: four magnetron sputter sources



Multiple targets for ion sputtering

### **Technical Data**

### **UNIVEX 600**

Vacuum chamber	Water-cooled
Material	
Chamber body	Stainless steel
Chamber door	Stainless steel
Dimensions	
Inside width mm	600
Inside depth mm	600
HInside height mm	800 (550 sputter version)
Connections <sup>1)</sup>	
Front side	Door with window
Rear side DN	1x 250 ISO-K (pump system connection), 2 x 16 ISO-KF, 2 x 25 ISO-KF, 2 x 40 ISO-KF
Bottom plate	Variable connections
Cover plate	Variable connections
High vacuum pump 1)	TURBOVAC MAG W 1300 iP
Nominal pumping speed for $N_2$ I/s	1100
Backing pump 1)	SOGEVAC SV 65 B
Nominal pumping speed m <sup>3</sup> /h	59
Controller	PLC with graphic touchscreen
Required supplies	
Voltage	400 V, 3 phases / N / PE / 50 Hz $^{\scriptscriptstyle 2)}$
Cooling water	
Inlet pressure bar (abs.)	4 to 6
Consumption, approx. I/min	Dependent on chamber installations
Feed temperature °C	+18 to +25
Compressed air bar (abs.)	4 to 6
Weight, approx. kg	1000 3)

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

 $^{\scriptscriptstyle 2)}~$  Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### UNIVEX 600

UNIVEX 600 upon request





Dimensional drawing for the UNIVEX 600

Vacuum Pump Systems

### UNIVEX 900



The UNIVEX 900 is the sophisticated solution for medium to large substrate sizes, respectively for higher substrate throughputs.

In the octagonal vacuum chamber which is 900 mm wide, substrates respectively substrate holders up to an overall diameter of 800 mm max. can be rotated and coated.

The integrated PC/PLC controller allows you to run manual, semiautomatic and fully automatic coating processes

Design example UNIVEX 900

### Examples of equipped vacuum chambers



Chamber bottom: electron beam evaporator, thermal evaporator, ion source

Chamber top: rotating substrate dome with turnover device



Rotating substrate table at the chamber top for 10 substrates (in situ combinable with five masks) + 4 high-temperature thermal radiation heaters on the rear



Confocal sputter-up arrangement with rotating high-temperature substrate heater

### **Technical Data**

### **UNIVEX 900**

Vacuum chamber	Water-cooled	
Material		
Chamber body	Stainless steel	
Chamber door	Stainless steel	
Dimensions		
Inside width mm	900 (octagonal)	
Inside depth mm	900 (octagonal)	
HInside height mm	1100	
Connections <sup>1)</sup>		
Front side	Door with window	
Rear side DN	2x 250 ISO-K (pump system connection), 2 x 16 ISO-KF, 2 x 25 ISO-KF, 2 x 40 ISO-KF,	
	1 x DN 63 ISO-KF	
Bottom plate	Variable connections	
Cover plate	Variable connections	
High vacuum pump <sup>1)</sup>	TURBOVAC W 2200 iP	
Nominal pumping speed for N <sub>2</sub> I/s	2100	
Backing pump 1)	SOGEVAC SV 100 B	
Nominal pumping speed m <sup>3</sup> /h	97.5	
Controller	PLC with graphic touchscreen	
Required supplies		
Voltage	400 V, 3 phases / N / PE / 50 Hz $^{2)}$	
Cooling water		
Inlet pressure bar (abs.)	4 to 6	
Consumption, approx. I/min	Dependent on chamber installations	
Feed temperature °C	+18 to +25	
Compressed air bar (abs.)	4 to 6	
Weight, approx. kg	1500 <sup>3)</sup>	

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

 $^{\scriptscriptstyle 2)}\,$  Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### **UNIVEX 900**

UNIVEX 900 upon request

Vacuum Pump Systems

## Glove Box Systems

### Multi-purpose Vacuum Coating System for Fitting to a Glove Box

The UNIVEX glove box systems were developed to coat materials which are sensitive with respect to the environmental conditions like oxygen or humidity, for example

Design

- The UNIVEX glove box systems consist of a process module and a separate electrical cabinet
- The process module includes the vacuum chamber, the coating components and the pump system
- The control module includes the PLC, respectively PC controller including the visualisation as well as the power supplies for the process components

### Vacuum Chamber

- Box-shaped stainless steel vacuum chambers UNIVEX 250 G – 450 G
- Sliding front door for easy chamber access through the glove box
- Swivelling rear door for simple chamber access
- Viewing window with coating protection
- Removable stainless steel coating protection panels
- Flexible connections for chamber bottom and chamber top
- Connecting flanges for pump system and process components

### Vacuum System

- Mechanical forevacuum pump (dry compressing or oil sealed)
- High vacuum pump (turbomolecular or cryo pump)
- Vacuum valves
- Pressure measurement devices

### Advantages to the User

- Modular system design
- Application-wise optimised system
- Flexible utilisation of the vacuum chamber
- Space saving installation to the rear of the glove box
- Convenient process access through

the glove box by means of a front sliding door

- Easy access to the chamber unit through the rear service door
- Very simple to operate and use
- Suited for retrofitting of process

components (configuration dependent)

- All system components with exception of the sliding door are accessible from outside the glove box



Design example

UNIVEX 350 G, consisting of electrical cabinet (left) and coating module (right)



View through the vacuum chamber: front sliding door and rear swivelling door open Design example with sputter source (right) and heated substrate table (top)





Dimensional drawing of the glove box units, shown without process installations

### Complete Solutions, including Glove Box

Upon request Leybold will also arrange the delivery of turnkey solutions consisting of the UNIVEX 350 G coating system and a glove box from a single source.

### For this, please ask us for a quotation.



UNIVEX 350 G rear side



Glove box system with UNIVEX 350 G coating modules fitted to the rear

## UNIVEX 250 G

The UNIVEX 250 G is a convenient and cost-effective solution for coating tasks requiring not much space.

Substrates, respectively substrate holders up to an overall diameter of

approximately 220 mm can be processed.

### **Technical Data**

### UNIVEX 250 G

Vacuum chamber	
Material	
Chamber body	Stainless steel
Front sliding door	Stainless steel
Rear swivelling door	Aluminum
Dimensions	
Inside width mm	270
Inside depth mm	370
HInside height mm	400
Connections <sup>1)</sup>	
Front side	Sliding door for glove box access; manually operated and pneumatically closing
Rear side	turning door for service access; manually locked
Bottom plate	Variable connections
Cover plate	Variable connections
Left side DN	1x 160 ISO-K (pump system connection), 2 x 16 ISO-KF, 1 x 25 ISO-KF
High vacuum pump 1)	TURBOVAC 350 i
Nominal pumping speed for N <sub>2</sub> I/s	290
Backing pump 1)	SOGEVAC SV 10 B
Nominal pumping speed m <sup>3</sup> /h	11
Controller	PLC with graphic touchscreen
Required supplies	
Voltage	400 V, 3 phases / N / PE / 50 Hz $^{2)}$
Cooling water	
Inlet pressure bar (abs.)	4 to 6
Consumption, approx. I/min	Dependent on chamber installations
Feed temperature °C	+18 to +25
Compressed air bar (abs.)	4 to 6
Weight, approx. kg	350 <sup>3)</sup>

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

<sup>2)</sup> Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### UNIVEX 250 G

UNIVEX 250 G

Part No. upon request

## UNIVEX 350 G

The UNIVEX 350 G combines a compact design with plenty of chamber space.

For many coating tasks the UNIVEX

350 G offers optimum space conditions and operator convenience as to process components and substrate processing. Substrates, respectively substrate holders up to an overall diameter of approximately 300 mm can be processed.

### **Technical Data**

### UNIVEX 350 G

Vacuum chamber	
Material	
Chamber body	Stainless steel
Front sliding door	Stainless steel
Rear swivelling door	Stainless steel
Dimensions	
Inside width mm	370
Inside depth mm	380
HInside height mm	500
Connections <sup>1)</sup>	
Front side	Sliding door for glove box access; manually operated and pneumatically closing
Rear side	turning door for service access; manually locked
Bottom plate	Variable connections
Cover plate	1x 200 ISO-K, 4 x installation bore ø 34,5 mm
Left side DN	1 x 160 ISO-K (pump system connection), 2 x 16 ISO-KF, 1 x 25 ISO-KF, 1 x 40 ISO-KF
High vacuum pump 1)	TURBOVAC 450 i
Nominal pumping speed for N <sub>2</sub> I/s	430
Backing pump 1)	SOGEVAC SV 25 B
Nominal pumping speed m <sup>3</sup> /h	26
Controller	PLC with graphic touchscreen
Required supplies	
Voltage	400 V, 3 phases / N / PE / 50 Hz $^{\scriptscriptstyle 2)}$
Cooling water	
Inlet pressure bar (abs.)	4 to 6
Consumption, approx. I/min	Dependent on chamber installations
Feed temperature °C	+18 to +25
Compressed air bar (abs.)	4 to 6
Weight, approx. kg	400 3)

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

 $^{\mbox{\tiny 2)}}$  Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### UNIVEX 350 G

 Part No.

 UNIVEX 350 G
 upon request

## UNIVEX 450 G

Owing to its chamber dimensions, the UNIVEX 450 G is suited for all coating tasks requiring much space Substrates, respectively substrate holders up to an overall diameter of over 400 mm can be processed.

With a height of 650 mm, the vacuum chamber is also suited for lift-off applications.

### **Technical Data**

### UNIVEX 450 G

Vacuum chamber	
Material	
Chamber body	Stainless steel
Front sliding door	Stainless steel
Rear swivelling door	Aluminum
Dimensions	
Inside width mm	500
Inside depth mm	500
HInside height mm	650
Connections <sup>1)</sup>	
Front side	Sliding door for glove box access; manually operated and pneumatically closing
Rear side	turning door for service access; manually locked
Bottom plate	Variable connections
Cover plate	1x 250 ISO-K, 4 x installation bore ø 34,5 mm
Left side DN	1 x 250 ISO-K (pump system connection), 2 x 16 ISO-KF, 1 x 25 ISO-KF, 1 x 40 ISO-KF
High vacuum pump 1)	TURBOVAC MAG W 700 iP
Nominal pumping speed for N <sub>2</sub> I/s	590
Backing pump 1)	SOGEVAC SV 40 B
Nominal pumping speed m <sup>3</sup> /h	44
Controller	PLC with graphic touchscreen
Required supplies	
Voltage	400 V, 3 phases / N / PE / 50 Hz $^{2)}$
Cooling water	
Inlet pressure bar (abs.)	4 to 6
Consumption, approx. I/min	Dependent on chamber installations
Feed temperature °C	+18 to +25
Compressed air bar (abs.)	4 to 6
Weight, approx. kg	500 <sup>3)</sup>

<sup>1)</sup> Standard configuration, other hole patterns / flanges / viewing windows / pumps upon request

<sup>2)</sup> Other voltages and frequencies upon request

<sup>3)</sup> Total weight without chamber installations/process components

### **Ordering Information**

### UNIVEX 450 G

UNIVEX 450 G

Part No. upon request

### Notes

## Cluster-Tool Systems UNIVEX C



Design example:

UNIVEX 450 C with coating module and electrical cabinet (example photograph).

The coating module consists of two process chambers (left and right) as well as the loadlock and transfer chamber in between

The substrate transfer between the chambers is effected with the aid of a vacuum robot



Design example:

UNIVEX 450 C with two process chambers as well as load lock chamber arranged at the centre. The substrates are moved using linear transfer rods (left and right) For special applications we can also supply cluster systems based on the UNIVEX concept. These clusters are equipped according to customer requirements and incorporate separate processing, load lock and transfer chambers.

Frequently sputter applications are involved since sputter targets remain in place for a long time and because of this, the process chambers need to be vented rarely.

Generally, each vacuum chamber will have its own high vacuum system. The load lock chamber is in the simplest case loaded manually with individual substrates. In addition, magazine processing of several substrates per batch is possible.



For transporting the substrates between the individual vacuum chambers, commonly motor driven robot arms or linear transfer drive units are used.

The UNIVEX control software is customised according to the specific application requirements and will generally allow fully automatic running of the process including recipe processing. Additional features like data logging, password protected and priority dependent user access as well as remote access for servicing can be optionally integrated.

Design example: Automatically controlled substrate magazine with robot arm access



#### Design example:

Load lock chamber with central vacuum robot for substrate transportation into radially arranged process chambers



Design example:

Coating module (centre) with decentralised pump systems (left and right) and control console

## Dactyloscopy Systems UNIVEX D

Leybold has developed a coating system, which relies on a recognized metal evaporation process to reveal fingerprints on items containing fingerprint evidence.

### Benefits of this method

- Easily controllable thermal coating process
- Coating of large areas is possible up to 800 x 400 mm
- Short cycle times are possible (depending on the material with the fingerprint evidence)
- Good contrast on multicolor surfaces
- The material containing the fingerprint evidence remains undamaged



#### Design example:

UNIVEX 450 D, consisting of vacuum coating module (right) and separate electrical cabinet (left)



Opened coating chamber with retracted substrate receiver



View into the chamber with thermal evaporator and positioned substrate receiver

## Space Simulation Systems UNIVEX S

We are offering the UNIVEX S line for simulation of space conditions as well as other thermal vacuum experiments. It generally consists of a cylindrical vacuum chamber with high vacuum system and supply module with process controller.

The simulation chamber is typically equipped with temperature controllable trays and shrouds, which may be both heated and cooled, in a vacuum. The process module is moved manually along rails so that the simulation chamber can be opened for loading





Opened chamber of the UNIVEX 1000 S with temperature controllable shrouds and substrate tray

Design example: UNIVEX 1000 S with closed simulation chamber



Design example: UNIVEX 700 S



UNIVEX S XTT



### **Process Accessories**

### Thermal Evaporation of High Melting Point Materials (metals)

### Single Thermal Evaporator

Consisting of two water-cooled high voltage feedthroughs with terminal blocks for 34.5 mm dia. holes.



Single thermal evaporator

### **Dual Thermal Evaporator**

Consisting of three water-cooled high voltage feedthroughs with terminal blocks for 34.5 mm dia. holes.



Dual thermal evaporator

### **High Current Cable**

For single and dual thermal evaporators, equipped with terminals and clamping pieces.

### **Technical Data**

Rating per conductor	V	max. 100
	Α	500
Seals		FPM
Water connection	mm	Hose 4/6 ∅
Weight	kg	2.5

### **Ordering Information**

#### **Single Thermal Evaporator**

**Dual Thermal Evaporator** 

**Single Thermal Evaporator** 

	Part No.
Single thermal evaporator	upon request

### **Technical Data**

Rating per conductor	V	max. 100
	Α	500
Seals		FPM
Water connection	mm	Hose 4/6 Ø
Weight	kg	3.9

### **Ordering Information**

### **Dual Thermal Evaporator**

**High Current Cable** 

	Part No.
Dual thermal evaporator	upon request

### **Technical Data**

Length	m	2 1)
Rating	V	max. 100
	Α	500
Cross section	mm²	120
Weight	kg	3.5

### **Ordering Information**

#### **High Current Cable**

	Part No.
Power supply cable	upon request <sup>2)</sup>

<sup>1)</sup> Standard length. Other lengths can be specified

<sup>2)</sup> For the single thermal evaporator, two high current cables are required For the dual thermal evaporator, three high current cables are required

### leybold

### AS 153 High current power supply unit

For supplying thermal evaporators.



AS 153 high current power supply unit

### **Technical Data**

### **Power Supply Unit**

Cabinet	19" rack module, 2 HU
	Installation depth 520 mm
Output voltage/current, max.	8 V, 400 A
Inputs	Remote control unit for controlling the evaporation power (0 to 10 V)
Main power supply	230 V, 50/60 Hz, 10 A
Weight, approx. kg	10

### **Ordering Information**

### **Power Supply Unit**

AS 153 high current power supply unit

Part No. upon request Vacuum Pump Systems

### Thermal Evaporation of Low Melting Point Materials (organics)

Organic material evaporators are special instruments based on the thermal principle developed to evaporate mostly temperature sensitive organic materials. process at precisely controlled heating temperatures in the range between 50 °C and 600 °C.

For installation within the UNIVEX systems, Leybold supplies organic

material evaporators as a complete package, consisting of evaporator source, automatic evaporator shutter and 19" rack mount controller.

Such instrumentation ensures a coating



Four organic material evaporators, arranged in a semicircle



Power supply unit for two organic material evaporators

Upon request we shall be pleased to provide an offer which specifically matches the requirements of your application.



Single organic material evaporator with shutter, fitted to a DN 40 CF flange

## **Electron Beam Evaporation**

Various models of electron beam evaporators and power supplies are available for installation in the UNIVEX systems.

### **Electron Beam Evaporator**

The selection of a suitable electron beam evaporator will primarily depend on the amount of available space, the desired evaporation rate and the film thickness as well as the number and type of materials which need to be evaporated. Single crucible as well as rotatable multi-crucible evaporators are available.



Electron beam evaporator with single crucible



### pocket crucible

### **Power Supplies**

The power supply unit for the individual electron beam evaporators is selected depending on the maximum evaporation power which is required, as well as the demanded properties for X/Y beam deflection. Models with output power ratings ranging from 3 kW to 10 kW are available.

Upon request we shall be pleased to provide an offer which specifically matches the requirements of your application.

## Sputtering

### **Magnetron Sputter Sources**

The magnetron sputter sources, which can be built into the UNIVEX systems, are DC/RF compatible. This means, they may be operated either with a DC or also with a RF power supply. In addition, pulsed DC power supplies are possible.

Here as standard round planar sputter sources with target diameters ranging from 2-in. to 6-in. are available. Selection and equipping here depends on the substrate size to be coated, the specified sputtering process and the target material as well as the available installation space.

Other target sizes and magnetron types (rectangular sources, for example) are available upon request.



2-in. magnetron with in-situ tiltable sputter head, pneumatically actuated target shutter and gas feed



4-in. magnetron with in-situ tiltable sputter head, pneumatically actuated target shutter and gas feed



Confocal arrangement of 3-in. sputter sources, aligned for sputter-up

### **DC Power Supplies**

For DC sputtering, power supply units with a rated output power ranging between 500 W and 3 kW are available. These are 19-in. rack mount units which can be installed in the UNIVEX cabinets.

### **RF Power Supplies**

For RF sputtering, power supply units with a rated output power ranging between 300 W and 2 kW are available. These are 19-in. rack mount units which can be installed in the UNIVEX cabinets.

Moreover, automatically controlled RF matchboxes are supplied for impedance matching between the RF power supply and the magnetron.

### **Gas Inlet**

Sputtering sources can only be operated with a process gas present. For this, manually operated variable leak valves or automatically controlled mass flow controllers are available options.

### Throttling the Pumping Speed and Process Pressure Control

In order to protect the high vacuum pump against the high pressures present during plasma operation and to control the process pressure, the UNIVEX systems are fitted with suitable components for throttling the high vacuum pumping speed. These may be butterfly valves, control gate valves or also speed controlled turbomolecular pumps

Upon request we shall be pleased to provide an offer which specifically matches the requirements of your application.

### Ion Sources

Ion sources are frequently used to either clean or etch the substrates before running the actual coating process, or to optimise the thin film properties during deposition. In the case of the latter process, the ion source serves to support the coating process (IBAD – Ion Beam Assisted Deposition). However, there are also some PVD processes, during which the ion source is directly needed to produce the thin films, for example during ion beam sputtering As to design and operating principle, different types of ion sources are available, for example

- Gridded and gridless ion sources
- DC ion sources and RF ion sources
- Flange mounted ion sources and ion sources built in/aligned in the vacuum



Gridless DC ion source with filament for plasma neutralisation



Filamentless RF grid type ion source

We shall be pleased to assist you in connection with your UNIVEX application. For this, please ask us for a quotation.

### Process Gas Inlet

In plasma supported processes (sputtering, etching, glow discharge, bias) or reactive deposition methods, generally a gas supply from the outside is necessary. The gas may be supplied either manually with a gas-dosing valve or program-controlled by way of a gas

#### Mass Flow Controller (MFC)

For controlled inlet of gas in connection with automated plasma processes (sputtering, etching, glow discharge). The MFC is controlled by a PC or a PLC provided from the side of the customer.



### Variable Leak Valve with **Isolation Valve**

For manually controlled inlet of gas in connection with plasma processes (sputtering, etching and glow discharge).



Please ask us for detailed information.

flow controller (MFC - Mass Flow Controller). The MFC control range is depending on the requirements between approximately 0 to 10 sccm and 0 to 500 sccm.

The available MFC models are equipped either with a 0 to 5 V ana-

logue interface or a EtherCAT interface. The possible gases respectively gas mixtures within a UNIVEX system depend on the type of required application and the installed system hardware (in particular the pump system).

#### **Mass Flow Controller (MFC)**

Gas flow, max.	sccm	selectable between 10 and 500
Supply voltage	V DC	24
Control interface		analog 0 – 5 V or EtherCAT

#### **Ordering Information**

**Technical Data** 

#### **Mass Flow Controller (MFC)**

	Part No.
Mass flow controller	upon request

_			_	
Tec	hni	cal	D	ata

#### Variable Leak Valve with Isolation Valve

Gas inlet rate $q_L$	mbar x l/s	5 x 10 <sup>-6</sup> to 1 x 10 <sup>3</sup>
Connection flange	DN	16 ISO-KF

#### **Ordering Information**

#### Variable Leak Valve with Isolation Valve

	Part No.	
Variable leak valve with isolation valve	215 010	

see also Catalog Part "Valves"

## Film Thickness Measurement

Various thin film thickness measuring instruments may be installed in the UNIVEX units.

The selection depends on the measurements needed and the required degree of automation. As standard, oscillating crystal systems are used. These may consist of one or several sensing heads with or without shutter, and upon request are available for UHV operation (i.e. are suitable for degassing).

The sensor head is driven either by a monitor (allowing only the measurement of deposition rate and film thickness) or by a controller (allowing measurement of the film parameters and control of the deposition rate).

Upon request we can provide an offer which specifically matches the requirements of your application.

Example of a thin film controller



Examples of thin film measurement gauge heads

## Substrate Rotation

To attain the desired film properties, a rotary movement of the substrates is very often necessary in deposition processes.

The Leybold UNIVEX system is availa-

ble with a wide range of substrate rotation accessories.

A simple, manually operated rotation axis can be implemented just as a continuously revolving motor shaft or an angle positionable solution (for placement or transfer tasks). In addition, coaxial drives with two independently operated rotating tables can be offered.



Motor driven rotary drive with a detachable substrate holder (bayonet coupling). View from the bottom onto the closed substrate shutter



Coaxial hollow shaft drive for eccentric rotation and positioning of several substrates, with separate shutter table

### **Planetary Drives**

For high demands regarding thickness uniformity of the deposited film, planetary drives are suitable. Here the substrates, which are to be coated, are placed on so-called planets. The planets revolve eccentrically about a central axis but they additionally rotate about their own centre point.





Planetary drive with gear drive and three planets, firmly installed, but where the angle is adjustable



Planetary drive with central friction disc and five free-running planets

Our consulting experts are available to inform you about substrate movement options. For these please ask us for a quotation.

## Heating, Cooling, Tempering, Bias



The thermal manipulation of substrates is an important method to optimise coating results. For this, Leybold Vacuum offers within the scope of its UNIVEX systems numerous solutions. Depending on requirements and technical feasibility, thermal solutions may also be combined with other properties for example rotation or substrate bias.

Rotatable thermal radiation heater with quartz lamps



Rotatable thermal radiation heater with quartz lamps during heating operation

#### **Substrate Heating**

For temperature-controlled heating, different contact and thermal radiation heaters are available. The selection of the optimal solution depends above all on the desired temperature range, the substrate size and the substrate material.



Rotating contact heater based on the resistance heating principle



Rotating high temperature thermal radiation heater with SIC heating element

### **Substrate Cooling**

Heat sensitive substrates or substrate coatings necessitate during the deposition process some kind of cooling. Leybold offers both inactively as well as actively cooled substrate holders. As cooling media, water, liquid nitrogen  $(LN_2)$  or special cooling liquids can be used.



Rotating and water-cooled substrate table

### **Substrate Tempering**

Through the utilisation of a special temperature control liquid, it is possible to heat or also cool a substrate. The possible temperature range lies between approximately -50 °C and +150 °C for static substrate holders, respectively -20 °C and +100 °C for rotating substrate holders.



Rotatable and temperature controllable substrate holder with substrate shutter

### **Substrate Bias**

Pre-cleaning of the substrate with RF or DC biasing prior to deposition can improve the adhesive properties of the film. Leybold offers insulated substrate holders and upon request matching power supplies.



Insulated substrate fork with RF bias connection
# Load Lock Systems

To improve the process conditions and to increase coating throughput, frequently additional load lock chambers are used. These are connected to the process chamber and are vacuum-wise separated by a gate valve. By means of a transport facility (linear transfer rod, vacuum robot or alike) the substrate is transported between the chambers. The load lock system offers the advantage to save time during pumpdown and the ability to attain significantly better vacuum pressures in the process chamber, since it will not have to be vented when changing the substrates. Usually the load lock chamber will be significantly smaller compared to the process chamber.

Selection of the load lock chamber and

the pump system as well as the design for the substrate transport facility depend on the specific kind of application.

We shall be pleased to assist you as to the possibilities offered by a load lock system in your UNIVEX application.



Manually operated load lock chamber with substrate magazine



Load lock chamber for a single substrate with automatically operated linear transfer unit



View into the opened load lock chamber onto the substrate end effector

# **General Accessories**

### Blank-Off Screw Fitting

For 34.5 mm dia. hole.



Blank-off screw fitting

# PS 113 A Low Pressure Safety Switch

Safety interlock arrangements in connection with the UNIVEX system controller, respectively optionally connected power supply equipment (for sputtering or electron beam evaporation, for example).



PS 113 A Safety Switch

# **Overpressure Safety Valve**

For protecting the vacuum chamber against atmospheric overpressure during gas inlet



Dimensional drawing for overpressure safety valve

### **Technical Data**

Material	Stainless steel
Seal	FPM (FKM)
Weight kg	0.1

### **Ordering Information**

### **Blank-Off Screw Fitting**

Low Pressure Safety Switch

Low Pressure Safety Switch

Part No.

230 011

**Overpressure Safety Valve** 

**Blank-Off Screw Fitting** 

	Part No.
Blank-Off screw fitting	030 40

### **Technical Data**

mbar	approx. 6 below atmospheric pressure
mbar	3 below atmospheric pressure
mbar	2
	Changeover contacts, gold-plated,
	for prog. controls
mA / V AC	100 / 24
mA / V AC	30 / 24
DN	16 ISO-KF
	mbar mbar mbar mA / V AC mA / V AC DN

# **Ordering Information**

Low Pressure Safety Switch	
PS 113 A, DN 16 ISO-KF;	
complete with 3 m long cable	

see also Catalog Part "Measuring, controlling"

# **Technical Data**

#### Responding pressure mbar $1150 \pm 40$ , over-pressure l/h Flow at 140 mbar 500 Valve disk Spring loaded, with O-ring seal Leak rate in the closed state mbar x l/s < 1 x 10<sup>-8</sup> (Torr x I/s) (< 0.75 x 10<sup>-8</sup>) Connection 16 ISO-KF DN

# **Ordering Information**

	Part No.
Overpressure Safety Valve	890 39

see also Catalog Part "High Vacuum Pumps"

# **Overpressure Safety Valve**

# Vacuum Feedthrough for the Transfer of Electrical Signals

For installation in a 34.5 mm diameter installation bore.

Connection on the side of the atmosphere through a six-way plug (included in the delivery).

Connection on the vacuum side through a plug with soldered contacts (included in the delivery).



Vacuum feedthrough

# Pneumatically Actuated Swivelling Shutter

For covering substrates or coating sources like thermal, respectively electron beam evaporators.

With pneumatic drive unit and shutter panel; for installation within installation bores having a diameter of 34.5 mm.

# **Technical Data**

Rating per conductor	V	max. 700
	Α	16
Seal		FPM (FKM)
Weight	kg	0.3

# **Ordering Information**

# Vacuum Feedthrough

**Vacuum Feedthrough** 

	Part No.
Vacuum feedthrough	upon request

# Technical DataPneumatically Actuated<br/>Swivelling ShutterControl voltageV DCDimensions of the shutter panelmmupon consultation

# **Ordering Information**

### Pneumatically Actuated Swivelling Shutter

Part No.

Pneumatically actuated swivelling shutter

upon request

# **UNIVEX** - Experimental vacuum coaters

Questionnaire

Leybold
---------

Customer [		
Substrate		
Max. substrate d Substrate materi Substrate per ba	limensions al(s) itch	pcs.
Substrate heating Substrate cooling Substrate rotation Substrate shutter		yes, max. temp. yes, min. temp. yes yes
Substrate pre-to Substrate bias lon beam Sputter etching	reatment (clea	aning) RF DC yes yes
Deposited film		
Coating material Layers per subst	(s) trate	pcs.
Any materials inc	compatible wit	h your coating process (i.e. aluminum, copper, viton, etc.)
yes, thes	e materials ar	e
Deposition proc	cess	
Thermal evapor Number of sourc Number of powe Source shutter(s	r <b>ation</b> ces r supplies )	yes pcs. pcs. yes
Electron beam Number of guns Number and size Evaporating pow Source shutter(s	evaporation e of pockets /er /)	yes pcs. (e.g. 1 x 8cc, 4 x 8cc, 6 x 20cc) 3 kW 5 kW 6 kW 10 kW yes
Thickness mea	surement	monitor controller
<b>Magnetron spu</b> t Target to substra Source shutter(s	<b>ttering</b> ate alignment	yes confocal face to face yes
Number of DC sp Target diameter Targets with spe Number of DC pov	utter sources cial size ver supplies	pcs. 2" 3" 4" 6" pcs.
Number of RF sp Target diameter Targets with spe Number of RF pov	utter sources cial size ver supplies	pcs. 2" 3" 4" 6" pcs.
Ion assisted dep	osition	yes

page 1

# **UNIVEX - Experimental vacuum coaters**

Questionnaire

# Leybold

Gas inlet (required for all pl	asma processes)		
Required gases Gas inlet system	MEC manual leak valve		
Vacuum chamber			
If not, then special size	yes		
Chamber wall tempering	cooling heating (by water, max. 65 °C)		
Additional load lock system	manual automatic with magazine for substrates		
Pump system			
Fore-vacuum pump High vacuum pump	dry oil-sealed cryo turbomolecular		
Process pressure Ultimate pressure	mbar/ Torr mbar/ Torr		
System control (Standard is PLC with automatic	atic pump system control and manual deposition control)		
Manual process control Semi-automatic proc. control Automatic process control	yes (i.e. manual deposition steps) yes (i.e. automatic single deposition steps) yes (i.e. automatic coating batches, recipe-processing)		
Installation			
<b>Location</b> in a clean room completely in the clean room wall	yes yes		
Main power supply			
Voltage			
Frequency	Hz		
Description of other process or system issues, if required			
Commercial aspects			
Estimated budget	currency EUR USD		

page 2

leybold

Vacuum Pump Systems

# **Calibration Systems**

# General

# **CS** Calibration Systems

The requirements imposed on vacuum engineering with regard to accuracy of the measurements, reproducibility and unambiguity of the determined vacuum pressures have increased steadily over the last years

Routine calibrations of vacuum gauges are an important component of quality assurance schemes. The calibration systems from Leybold put the customer in a position to check and recalibrate on his own the specified and necessary accuracy of his vacuum gauges. Calibration systems are available for this



Calibration system CS3 Standard



Calibration system CS3 Advanced

-.11 1800 mm (71 in.) 0 depth approx. 1150 mm (42 in.) 2100 mm (87 in.)

purpose which cover a calibration range from 1000 mbar to 1 x 10<sup>-7</sup> mbar (750 to 0.75 x 10<sup>-7</sup> Torr).

Each system is equipped with several certified reference pressure sensors (transmitter standards), which each cover a part of the specified range of calibration pressures. In the pump system, TURBOVAC turbomolecular pumps with DIVAC diaphragm pumps are used. A variable leak valve is used to let the gas into the calibration chamber. In the case of the calibration system CS7, the gas inlet line is, moreover, equipped with it's own pump system.

The CS3 Advanced is a compact, wheeled version and therefore movable. In addition, the CS3 Advanced has a manual pump bypass, which allows a continuous dynamic calibration across the entire pressure range.

The CS7 is equipped with a heater for the vacuum chamber, for the purpose of attaining lower chamber pressures more rapidly. The temperature of the heating collars can be controlled whereby the maximum degassing temperature will depend on the components installed (flanges, pressure sensors, valves).

# Advantages to the User

- Vacuum gauges and measurement systems of any make may be calibrated
- Designed in accordance with DIN 28 418 resp. ISO/DIS 3567
- Transfer standards with PTB-, DAkkS- or factory certificate
- Easier DIN/ISO 9000 approval
- Reliable and reproducible measurements
- Quick start-up
- Measurement system free of hydrocarbons through the utilisation of dry compressing vacuum pumps
- Simple operation
- CE approval

CS7 calibration system

leybold

# **Products**

Technical Data		Calibration System		
		CS3 Standard	CS3 Advanced	CS7
Calibration range	mbar	1000 to 1 x 10 <sup>-3</sup> *	1000 to 1 x 10 <sup>-3</sup> *	1000 to 1 x 10 <sup>-7</sup>
	(Torr)	(750 to 0.75 x 10 <sup>-3</sup> )	(750 to 0.75 x 10 <sup>-3</sup> )	(750 to 0.75 x 10 <sup>-7</sup> )
Pressure measurement range	mbar	1000 to 2 x 10 <sup>-6</sup>	1000 to 2 x 10 <sup>-6</sup>	1000 to 2 x 10 <sup>-9</sup>
	(Torr)	(750 to 1.5 x 10 <sup>-6</sup> )	(750 to 1.5 x 10 <sup>-6</sup> )	(750 to 1.5 x 10 <sup>-9</sup> )
Vacuum chamber connections		5 (3) x DN 16 ISO-KF	5 (3) x DN 16 ISO-KF	3 (0) x DN 16 CF
(in brackets: disposable for user)		1 (0) x DN 25 ISO-KF	1 (0) x DN 25 ISO-KF	7 (5) x DN 40 CF
Pump system		Turbomolecular pump and	Turbomolecular pump, two-	Two turbomolecular pumps
		diaphragm vacuum pump	stage rotary vane vacuum	and diaphragm vacuum
			pump and pump bypass	pump
			(manual valves)	
Fixed / mobile		fixed	mobile (with castors)	fixed
Gas inlet		via variable leak valve	via variable leak valve	via variable leak valve
Dynamic collibration	mbar	1 x 10 <sup>-3</sup> to 2 x 10 <sup>-1</sup>	1 x 10 <sup>-3</sup> to 1000	1 x 10 <sup>-7</sup> to 1000
	(Torr)	((0.75 x 10 <sup>-3</sup> to 1.5 x 10 <sup>-1</sup> )	(0.75 x 10 <sup>-3</sup> to 1.5 x 10 <sup>-1</sup> )	(0.75 x 10 <sup>-3</sup> to 1.5 x 10 <sup>-1</sup> )
Extra pump system for admitting gas		no	no	yes
Heater for the vacuum chamber		no	no	yes

\* other calibration ranges are available down to 1 x 10<sup>-4</sup> mbar, by individual combination of CTR reference gauges.

# Application examples: Which pressure sensors may be calibrated with which system?

Type of Sensor	Calibrat	Calibration System		
	CS3	CS7		
Diaphragm sensors				
BOURDONVAC				
Capsule vacuum gauges				
DIAVAC DV 1000				
DI/DU 200/201/2000/2001				
CTR 90, CTR 91, CTR 100 (1000 – 1 Torr full scale)				
CTR 91 (0.1 Torr full scale) / CTR 101				
THERMOVAC sensors				
TR 301, TR 306				
TR 211, TR 216, TTR 211, TTR 216, TTR 90, TTR 91, TTR 96, TTR 100, TTR 101				
SRG/VISCOVAC sensor (spinning rotor gauge)				
VK 201, SRG				
PENNINGVAC sensors PR 25, PR 26, PR 27, PR 35, PR 36, PR 37, PTR 90, PTR 225				
IONIVAC sensors ITR 90, ITR 100, ITR 200				
IE 414, IE 514				

# **Ordering Information**

# Part No. CS3 Standard 504768V001 CS3 Standard 100 to 1 x 10<sup>-4</sup> mbar 504768V002 CS3 Advanced 504874V001 CS7 upon request

**Calibration System** 

Notes

# Notes

# Sales and Service

#### Germany

#### Leybold GmbH

Leybold Gmbri Bonner Strasse 498 D-50968 Cologne T: +49-(0)221-347 1234 F: +49-(0)221-347 31234 sales@leybold.com www.leybold.com

#### Leybold GmbH

Sales Area North Branch Office Berlin Industriestrasse 10b D-12099 Berlin +49-(0)30-435 609 0 +49-(0)30-435 609 10 T: sales.bn@leybold.com

# Leybold GmbH Sales Office South

Branch Office Munich Karl-Hammerschmidt-Strasse 34 D-85609 Aschheim-Dornach T: +49-(0)89-357 33 9-10 F: +49-(0)89-357 33 9-33 sales.mn@leybold.com service.mn@leybold.com

#### Leybold Dresden GmbH

Service Competence Center Zur Wetterwarte 50, Haus 304 D-01109 Dresden Service: +49-(0)351-88 55 00 +49-(0)351-88 55 041 Ť: F info.dr@leybold.com

#### Europe

#### Belgium

#### Levbold Nederland B.V. Belgisch bijkantoor

Leuvensesteenweg 542 B-1930 Zaventem Sales: T: . +32-2-711 00 83 +32-2-720 83 38 F sales.zv@leybold.com Service: T: +3 +32-2-711 00 82 +32-2-720 83 38 E service.zv@leybold.com

#### France

Leybold France S.A.S. Parc du Technopolis, Bâtiment Beta 3, Avenue du Canada F-91940 Les Ulis cedex Sales and Service: T: +33-1-69 82 48 00 F: +33-1-69 07 57 38 sales or@levbold.com orsay.sav@leybold.com

#### Leybold France S.A.S.

 
 Leybold
 France S.A.S.

 Valence Factory
 640, Rue A. Bergès

 B.P. 107
 F-26501 Bourg-lès-Valence Cedex

 T:
 +33-4-75 82 33 00

 F:
 +33-4-75 82 92 69
 marketing.vc@leybold.com

#### **Great Britain**

#### Leybold UK LTD.

Unit 9 Silverglade Business Park Leatherhead Road Chessington Surrey (London) KT9 2QL Sales: +44-13-7273 7300 T: F٠ +44-13-7273 7301 sales.ln@leybold.com

Service: +44-13-7273 7320 +44-13-7273 7303 T: service.In@leybold.com

#### Italy

**Leybold Italia S.r.l.** Via Filippo Brunelleschi 2 I-20093 Cologno Monzese Sales: .. +39-02-27 22 31 +39-02-27 20 96 41 T: F

sales.mi@leybold.com Service: T: +39-02-27 22 31 F: +39-02-27 22 32 17 service.mi@leybold.com

Netherlands

Levbold Nederland B.V. Floridadreef 102 NL-3565 AM Utrecht Sales and Service: +31-(30) 242 63 30 +31-(30) 242 63 31 sales.ut@leybold.com service.ut@leybold.com

#### Russia

Levbold Russia Vashutinskoe Road 15, Khimki, Moscow region, 141402 Russia +7 495 933 55 50 LeyboldRussia@leybold.com

### Switzerland

Leybold Schweiz AG Hinterbergstrasse 56 CH-6312 Steinhausen Warehouse and shipping address: Riedthofstrasse 214 CH-8105 Regensdorf Sales: +41-44-308 40 50 +41-44-308 40 60

sales.zh@leybold.com Service: +41-44-308 40 62 +41-44-308 40 60 F٠ service.zh@leybold.com

#### Spain

#### Leybold Hispánica, S.A.

C/. Huelva, 7 E-08940 Cornellá de Llobregat (Barcelona) Sales: +34-93-666 43 11 +34-93-666 43 70 F٠ sales.ba@leybold.com Service: +34-93-666 46 11 +34-93-685 43 70 F service.ba@levbold.com

# America

### **USA**

Levbold USA Inc. 6005 Enterprise Drive Export, PA 15632 USA Sales and Service: T: +1-800-764-5369 F: +1-800-325-4353 F: +1-800-215-7782 sales.ex@leybold.com service.ex@leybold.com

#### Brazil

Leybold do Brasil Ltda. Av. Tamboré, 937, Tamboré Distrito Industrial CEP 06460-000 Barueri - SP Sales und Service: T: +55 11 3376 4604 info.ju@leybold.com

#### Asia

#### P. R. China

Leybold (Tianjin) International Trade Co. Ltd. Beichen Economic Development Area (BEDA), No. 8 Western Shuangchen Road Tianjin 300400 China Sales and Service: T: +86-400 038 8989 T: +86-800 818 0033 +86-22-2697 4061 +86-22-2697 2017 E F sales.tj@leybold.com service.tj@leybold.com



#### India

Levbold India Pvt Ltd. T-97/2, MIDC Bhosari Pune-411 026 Indien Sales and Service: T: +91-80-2783 9925 F: +91-80-2783 9926 sales.bgl@leybold.com service.bgl@leybold.com

#### Japan

Leybold Japan Co., Ltd. Shin-Yokohama A.K.Bidg., 4th floor 3-23-3, Shin-Yokohama Kohoku-ku, Yokohama-shi Kanagawa-ken 222-0033 Japan Sales: +81-45-471-3330 +81-45-471-3323 T: F: sales.yh@leybold.com

#### Malaysia

# Leybold Malaysia

Leybold Singapore Pte Ltd. No. 1 Jalan Hi-Tech 2/6 Kulim Hi-Tech Park Kulim, Kedah Darul Aman 09090 Malaysia Sales and Service: T: +604 4020 222 F: +604 4020 221 sales.ku@leybold.com service.ku@leybold.com

#### South Korea

Leybold Korea Ltd. 25, Hwangsaeul-ro 258 beon-gil, undang-gu, Seongnam-si, Gyeonggi-do, (7F Sunae Finance Tower) 13595 Bundang Sales: +82-31 785 1367 +82-31 785 1359 T: F sales.bd@leybold.com Service: T: +82-41 589 3035 F: +82-41 588 0166 service.cn@leybold.com

#### Singapore

Leybold Singapore Pte Ltd. 42 Loyang Drive Loyang Industrial Estate Singapore 508962 Singapore Sales and Service: +65-6303 7030 +65-6773 0039 T F info.sg@leybold.com

#### Taiwan

#### Leybold Taiwan Ltd.

10F., No. 32, Chenggong 12th St., Zhubei City, Hsinchu County 302 Taiwan, R.O.C. Sales and Service: +886-3-500 1688 +886-3-550 6523 т· info.hc@leybold.com

#### Leybold GmbH

Bonner Strasse 498 D-50968 Cologne T: +49-(0)221-347-0 F: +49-(0)221-347-1250 info@leybold.com

